


Operating instructions


Washing machine



To avoid the risk of accidents or damage to the appliance, it is **essential** to read these instructions before it is installed and used for the first time.


Contents

Caring for the environment	6
Warning and Safety instructions	7
Operating the washing machine	14
Control panel	14
Touch display and sensors	15
Main menu	15
Examples on how to operate the appliance	17
Before using for the first time	19
Running the first programme	20
TwinDos	21
Inserting cartridges/containers	22
Using cartridges	22
Using containers	23
Setting the electronic unit to liquid detergent and/or fabric softener	24
Settings for UltraPhase 1 and UltraPhase 2	25
Settings for other types of detergent	26
Running the first programme	27
Washing environmentally and economically	28
Energy and water consumption	28
Detergent consumption	28
When drying with a tumble dryer	28
ECO Feedback	29
1. Preparing the laundry	30
2. Selecting a programme	31
3. Selecting programme settings	32
4. Loading the washing machine	35
5. Adding detergent	37
TwinDos	37
CapDosing	37
Detergent dispenser drawer	39
6. Starting the programme - the end of the programme	40
Degree of soiling	41
Spinning	42

Programme chart	44
Programme sequence	50
Garment care label symbols	52
Changing the programme sequence	53
Cancelling a programme	53
Interrupting a programme	53
Changing a programme and settings	53
Adding or removing laundry after a programme has started	54
Safety lock	55
ProgrammeManager	56
Intensive	56
ECO	56
Extra gentle	56
Extra quiet	56
AllergoWash	56
Extra options	58
Steam smoothing 	58
Short	58
Rinse hold	58
Pre-wash	58
Water plus	58
Extra rinse	58
Delay start	60
Favourite programmes	62
Washing assistant	64
Mixed items	65
Detergent	66
The correct detergent	66
Detergent dispensing aids	66
Fabric softeners and liquid starch	66
Miele recommended detergents	67
Cleaning and care	71
Cleaning the drum (Hygiene info)	71
External casing and fascia panel	71
Cleaning the detergent dispenser drawer	71

Contents

Cleaning the TwinDos system	73
Cleaning the water inlet filter	74
Problem solving guide	75
Problem solving guide	75
The programme does not start	75
The following fault message appears in the display and the programme has been cancelled	76
The following fault message appears in the display at the end of a programme..	77
Problems with TwinDos	79
General problems with the washing machine	80
An unsatisfactory wash result	82
The door will not open	83
Opening the door in the event of a blocked drain outlet and/or power cut	84
After sales service	86
Repairs	86
Warranty	86
Optional accessories	86
Installation and connection	87
Front view	87
Rear view	88
Installation surface	89
Transporting the washing machine to its installation site	89
Removing the transit bars	89
Refitting the transit bars	91
Levelling the machine	92
Screwing out and adjusting the feet	92
Building under a continuous worktop / in a kitchen run	93
Washer and dryer stack	93
The Miele water protection system	94
Connection to the water supply	96
Drainage	99
Electrical connection	100
Technical data	101
Consumption data	102
Consumption data for the nominated energy labelling programme according to AS/NZS 2040.1 & AS/NZS 2040.2	102
Settings	104
Selecting and changing settings	104

Exiting the Settings menu	104
Language 	105
TwinDos.....	105
Degree of soiling.....	105
Time.....	105
Buzzer volume.....	106
Keypad tone	106
Total consumption	106
PIN Code.....	106
Temperature unit.....	106
Display brightness	107
Display switch-off status	107
Appliance switch-off status.....	107
Display maximum load	107
Memory	107
Water intake	108
Longer pre-wash Cottons.....	108
Soak duration	108
Gentle action	108
Reduce temp.	109
Water plus level	109
Maximum rinse level.....	109
Suds cooling.....	109
Anti-crease	109
Delay start	110
Optional accessories	111
Detergent.....	111
Specialist detergents.....	111
Fabric care.....	112
Additives.....	112

Caring for the environment


Disposal of the packing material

The packaging is designed to protect the washing machine from damage during transportation. The packaging materials used are selected from materials which are environmentally friendly for disposal and should be recycled.

Recycling the packaging reduces the use of raw materials in the manufacturing process and also reduces the amount of waste in landfill sites. Ensure that any plastic wrappings, bags etc. are disposed of safely and kept out of the reach of babies and young children. Danger of suffocation.

Disposing of your old appliance

Electrical and electronic appliances often contain materials which, if handled or disposed of incorrectly, could be potentially hazardous to human health and to the environment. They are, however, essential for the correct functioning of your appliance. Therefore, please do not dispose of your old appliance with your household waste.



Please dispose of it at your local community waste collection / recycling centre.

Ensure that your old appliance presents no danger to children while being stored for disposal.

Warning and Safety instructions

This washing machine complies with current safety requirements. Inappropriate use can, however, lead to personal injury and damage to property.

To avoid the risk of accidents and damage to the machine, please read these instructions carefully before using it for the first time. They contain important information on its safety, use and maintenance.

Keep these instructions in a safe place and ensure that new users are familiar with the content. Pass them on to any future user.

Correct application

- ▶ This washing machine is designed for domestic use and for use in similar environments by guests in hotel or motel rooms, bed & breakfasts and other typical living quarters. This does not include common/shared facilities or commercial facilities within hotels, motels or bed & breakfasts.
- ▶ The washing machine is not suitable for outdoor use.
- ▶ It must only be used to wash garments which have been declared suitable for washing by the manufacturer indicated on the garment care label. Any other use is not permitted. Miele cannot be held liable for damage resulting from incorrect or improper use or operation.
- ▶ This washing machine is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning its use by a person responsible for their safety.

Warning and Safety instructions

Safety with children

- ▶ Young children must not be allowed to use this appliance.
- ▶ Older children may only use the appliance when its operation has been clearly explained to them and they are able to use it safely, recognising the dangers of misuse.
- ▶ Cleaning work may only be carried out by older children under the supervision of an adult.
- ▶ Please supervise children in the vicinity of the washing machine and do not let them play with it.

Technical safety

- ▶ Please observe the instructions in "Installation and connection" and "Technical data".
- ▶ Before setting up the washing machine, check it for any externally visible damage. Do not install or use a damaged machine.
- ▶ Before connecting the washing machine, ensure that the connection data on the data plate (fuse rating, voltage and frequency) matches the mains electricity supply. If in any doubt, consult a qualified electrician.
- ▶ Reliable and safe operation of this washing machine can only be assured if it has been connected to the mains electricity supply.

Warning and Safety instructions

- ▶ The electrical safety of this washing machine can only be guaranteed when continuity is complete between it and an effective earthing system which complies with current local and national safety regulations. It is most important that this basic safety requirement is present and regularly tested and, where there is any doubt, the household wiring system should be inspected by a qualified electrician. Miele cannot be held liable for the consequences of an inadequate earthing system (e.g. electric shock).
- ▶ Do not connect the washing machine to the mains electricity supply by a multi-socket adapter, extension lead or similar. These do not guarantee the required safety of the machine (fire hazard due to the risk of overheating).
- ▶ Faulty components must only be replaced by genuine Miele spare parts. Miele can only guarantee the safety of the appliance when Miele replacement parts are used.
- ▶ The electrical socket must be easily accessible after installation so that the machine can be disconnected from the electricity supply if necessary.
- ▶ Unauthorised repairs could result in unforeseen dangers for the user, for which Miele cannot accept liability. Repairs should only be undertaken by a Miele authorised service technician, otherwise any subsequent damage will not be covered by the warranty.
- ▶ If the connection cable is faulty, it must only be replaced by a Miele approved service technician to protect the user from danger.

Warning and Safety instructions

- ▶ In the event of a fault or for cleaning purposes, the washing machine is only completely isolated from the electricity supply when:
 - it is switched off at the wall socket and the plug is withdrawn, or
 - it is switched off at the mains circuit breaker.
- ▶ The Miele Waterproof system protects from water damage provided the following conditions have been met:
 - The machine is correctly plumbed in and connected to the electricity supply.
 - If a fault or damage has been identified, the machine must be examined by a competent person before further use, and repaired if necessary.
- ▶ The water flow pressure must be at least 100 kPa and should not exceed 1000 kPa.
- ▶ This washing machine must not be installed and operated in mobile installations (e.g. on a ship).
- ▶ Do not make any alterations to the machine, unless authorised to do so by Miele.
- ▶ In areas which may be subject to infestation by cockroaches or other vermin, pay particular attention to keeping the machine and its surroundings in a clean condition at all times. Any damage which may be caused by cockroaches or other vermin will not be covered by the machine warranty.

Correct use

► Do not install the washing machine in a room where there is a risk of frost. Frozen hoses may burst or split. The reliability of the electronic control unit may be impaired at temperatures below freezing point.

► Before using the machine for the first time, check that the transit bars at the rear of the machine have been removed (see "Installation and connection - Removing the transit bars"). During spinning, a transit bar which is still in place may result in damage to both the machine and adjacent furniture or appliances.

► Turn off the tap if the machine is to be left for any length of time (e.g. holiday), especially if there is no floor drain (gully) in the immediate vicinity.

► Flooding danger.

If hooking the drain hose into a wash basin, check that the water can drain off quickly enough to prevent the sink from overflowing. Make sure the drain hose is secure, so that the force of the water flowing out of the hose does not dislodge it.

► Take care to ensure that foreign objects (e.g. nails, pins, coins, paper clips) do not find their way into the machine with the laundry. These may damage components of the machine (e.g. suds container, drum), which in turn can result in damage to the laundry.

Warning and Safety instructions

- ▶ Take care when opening the drum door after using the steam function. There is a danger of burning due to escaping steam and the high temperature of the surface of the drum as well as the porthole glass. Stand back away from the machine and wait until the steam has dissipated.
- ▶ The maximum load for this washing machine is 9 kg (dry weight). See the "Programme chart" for the maximum recommended loads for individual programmes.
- ▶ If the correct amount of detergent is dispensed, the machine should not need to be descaled. If, however, you do wish to descale it, only use a proprietary natural citric acid based descaling agent. Miele recommends using Miele descaler for washing machines which is available to order online at www.miele-shop.com (depending on country) or from Miele. Strictly observe the instructions on the packaging.
- ▶ Textiles which have been pre-treated in solvent based cleaning agents must be thoroughly rinsed in clean water before being washed in the machine.
- ▶ Do not use solvent based cleaning agents, e.g. those containing benzene, in this machine, as this may result in damage to component parts and create toxic fumes. Such agents also pose a fire and explosion hazard.
- ▶ Do not use solvent based cleaning agents, e.g. those containing benzene, to clean the external surfaces of the machine. They can cause damage to plastic surfaces.
- ▶ Only use dyes specified by the manufacturer as being suitable for use in a domestic washing machine. Always observe the manufacturer's instructions carefully.

Warning and Safety instructions

- ▶ Colour run and dye removers contain sulphur compounds which can cause damage such as corrosion. Do not use these products in this machine.
- ▶ If detergent comes into contact with the eyes, rinse them thoroughly with lukewarm water immediately. If swallowed, seek medical assistance immediately and retain the packaging or label for reference. Those with skin problems or sensitive skin should avoid their skin coming into contact with detergent.


Accessories

- ▶ Only use genuine Miele spare parts and accessories with this appliance. If spare parts or accessories from other manufacturers are used, this will invalidate the warranty, and Miele cannot accept liability.
- ▶ A Miele tumble dryer can be stacked on top of a Miele washing machine using the appropriate stacking kit (available as an optional accessory). Please make sure you order the correct one for the Miele washing machine and Miele tumble dryer.

Miele cannot be held liable for damage caused by non-compliance with these Warning and Safety instructions.

Operating the washing machine

Control panel



① Touch display

See the next page for more information.

② Start/Stop sensor

For starting the programme selected and cancelling a programme once it has started. The programme selected can be started as soon as the sensor starts flashing.

③ i sensor

The sensor lights up when information about the menu in the display is available.

④ Home sensor

For returning to the main menu. Values set previously are not saved.

⑤ Optical interface



For service technicians.

⑥ On button

For switching the washing machine on and off. To save energy, the washing machine will switch off automatically 15 minutes after the end of the programme / Anti-crease phase or after being switched on if no other selection is made.

Operating the washing machine

Touch display and sensors

The ,  and *Start/Stop* sensors and the sensors in the display react to fingertip contact.

The display can be scratched by pointed or sharp objects, e.g. pens. Only touch the touch display with your fingertips.


Touching the sensors in the display reveals a list of options or a sub-menu and also takes you to another menu.


In some instances, if you do not touch one of the sensors for several seconds, the display will revert to the previous menu. You may then need to enter the settings again.

Main menu

After switching on the washing machine, the main menu will appear in the display.

You access all the important sub-menus from the main menu.

You can return to the main menu at any time by touching the  sensor. Values set previously are not saved.



① Programmes

For selecting the wash programme.

② Favourite programmes

You can save up to ten of your own customised wash programmes.

See "Favourite programmes" for more information.

Operating the washing machine

③ Washing assistant

The Washing assistant guides you step by step so that you can select the optimum wash programme for your laundry.

See "Washing assistant" for more information.

④ Scroll bar

The scroll bar indicates that further options or more text follows.

The width of the scroll bar changes depending on the length of the option list or information.

The position of the scroll bar indicates where you are in a list or block of text.

⑤ Navigation sensors

You can use the < and > sensors to scroll through a list or block of text.

Touch the > sensor to scroll to the second page of the main menu.


⑥ Mixed items

Use this programme if you do not have enough laundry to run a standard programme but you want to wash a few lightly soiled items with different garment care instructions.


The washing machine will use the list of items to put together a suitable wash programme.

See "Mixed items" for more information.

⑦ Settings

You can alter the washing machine's electronics to suit changing requirements in the Settings  menu.

See "Settings 




Operating the washing machine

Examples on how to operate the appliance

Option lists

Programmes menu (single option list):



Touching the < or > sensor scrolls to the left or right of the list.


The scroll bar indicates that further options follow.

Touch a programme name to select the wash programme.

The load for the programme selected will appear in the display.

After a few seconds or if you confirm with the OK sensor, the display will change to show the standard menu for the programme selected.

Extra options menu (multiple option list):



Touching the < or > sensor scrolls to the left or right of the list.

The ↶ sensor takes you back a menu level.

The scroll bar indicates that further Extra options follow.

Touch one or several Extra options to select it/them.

The Extra option currently selected will be marked with a ✓.


Touch the Extra option again to deselect it.

The OK sensor activates or saves the marked Extra option.

Operating the washing machine

Setting numerical values

You can set numerical values in some menus.



The image shows a digital display for the 'Temperature' menu. The display is divided into two main sections. The top section shows the current temperature setting '30 °C' in a white box, with 'Cold - 90 °C' displayed below it. The bottom section contains four touch-sensitive buttons arranged in a 2x2 grid: a minus sign (-) button, a plus sign (+) button, a back arrow button, and an 'OK' button.


The numerical value is highlighted in white. Touching the – sensor decreases the value and touching the + sensor increases it. The OK sensor is used to adopt the selected value.

Useful tip: The values will count upwards and downwards automatically if you touch the + or - sensor continuously.


Removing the protective foil and stickers

■ Please remove

- the protective foil from the door.
- any stickers from the front and the lid (Exception: warning labels must not be removed).

 Please do not remove any labels (e.g. the data plate) which are visible when you open the door.

After installation

 Before using the machine for the first time, ensure that it is correctly installed and connected. See "Installation and connection". Also check that the filters are securely tightened to prevent the risk of water leaks during use.

This washing machine has undergone a complete functional test at the factory and there will be some residual water in the drum from this process.


For safety reasons, spinning is not possible until the machine has been prepared for use for the first time. To activate the spinning function, you must run a wash programme without laundry and without additional detergent.

Using additional detergent could result in an excessive build-up of foam.

- Press the  button.

Setting the language

You will be asked to select the language you want for the display. It is possible to change the language at any time after setting it via "Settings".




- Touch the < or > sensor until the language you want appears.
- Touch the sensor for the language you want.

The language selected will be marked with a tick ✓ and the display for setting the Clock format will appear.

Before using for the first time

Setting the clock format




Clock format

24 h clock ✓	12 h clock
--------------	------------

- Select the clock format you want.

The clock format selected will be marked with a tick ✓ and the display for setting the Time will appear.

Setting the time of day



Time

12 : 00

– +

OK

- Use the – and + sensors to set the current hour and confirm with OK.
- Set the minutes in the same way and confirm with OK.

Useful tip: If you have selected the 12-hour clock format, you can then select am or pm.

The display will change to show Setting up.

Setting up the machine

More information will appear.

- Follow the instructions and confirm the information with OK.

The display will change to show the main menu.

Running the first programme

The TwinDos unit needs to be activated before running the first programme.

- Please see "TwinDos".

The washing machine has an integrated detergent dispensing unit.

The detergent dispensing unit can be used with

1. the Miele 2 Phase System
or
2. any other liquid detergent and/or fabric softener

The Miele 2 Phase System

The Miele 2 Phase System uses a base detergent (UltraPhase 1) and a detergent enhancer (UltraPhase 2). In order to achieve optimum results, the agents are dispensed separately during the wash process. The 2 Phase System cleans both white and coloured textiles thoroughly. UltraPhase 1 and UltraPhase 2 single use cartridges are available to order from Miele or via the internet at www.miele-shop.com.

Liquid detergent/Fabric softener

The washing machine is supplied with two refillable containers which you can fill with liquid detergent and/or fabric softener.

How TwinDos works

When a programme is selected, the TwinDos programme setting can be activated for this wash process.

To use the TwinDos function, you need to specify the following information for the electronic unit:


1. The **detergent type** and/or **fabric softener** with which the containers are filled.
2. The **dosage amount** of the liquid detergent and/or fabric softener. The dosage amount for Miele products is preset at the factory.


Do not fill the containers with any specialist detergents. Use cap dosing or the detergent dispenser drawer for these.

Automatic dispensing cannot be selected with some programmes, depending on the detergent present in the TwinDos system. For example, automatic dispensing cannot be activated for the Woollens programme if the Miele 2 Phase System is being used. This prevents woollen garments being damaged by a detergent which is not suitable for washing wool.

TwinDos


Inserting cartridges/containers

 Keep filled containers or cartridges out of the reach of children. Observe the instructions for use and warning instructions given by the detergent manufacturer.



- Press the TwinDos container access panel.


The panel will spring open.




- Drop the panel down.

Using cartridges


UltraPhase 1 and UltraPhase 2 are supplied in single use cartridges.



- Press the yellow release button (1.) and pull the container out (2.).



- Remove the cap from the cartridge.



- Push the **UltraPhase 1** cartridge into **Compartment 1** until it locks into position.
- Remove container 2 and push the **UltraPhase 2** cartridge into **Compartment 2** until it locks into position.

Keep the containers in a safe place. They can be used for other types of detergent.

Using containers

- Take the containers out of the compartments.
- Open the yellow stopper and fill the container with your detergent of choice.
- Close the stopper and push the container back into the compartment. Make sure that the lock engages.

Useful tip: Make a note of which detergents you have filled the containers with so that you then enter the correct settings in the electronics later on.

The following liquid detergents and/or fabric softeners can be used in the containers:

- Miele UltraColor
- Miele WoolCare
- Miele fabric softener
- Universal detergent
- Colour detergent
- Delicates detergent
- Woollens detergent
- Fabric softener


TwinDos


Setting the electronic unit to liquid detergent and/or fabric softener

- Switch on the washing machine and wait until the main menu appears in the display.
- Use the > sensor to scroll to the second page of the main menu.



- Touch the Settings  sensor.

The display will change to show the Settings  menu.



- Touch the TwinDos sensor.

The display will change to the TwinDos setting.

TwinDos

Detergent type/ amount	Maintenance
---------------------------	-------------

- Touch the Detergent type/ amount sensor.

The display will change to show the Detergent type menu.

Detergent type

Compartment 1	Compartment 2
---------------	---------------

- Touch the Compartment 1 sensor.

The display will change to the screen for selecting the type of detergent.

Settings for UltraPhase 1 and UltraPhase 2

The dosage amounts for UltraPhase 1 and UltraPhase 2 are preset for normal soiling and need only be confirmed.

Compartment 1

No entry ✓	Miele UltraPhase 1
Miele UltraColor	Miele WoolCare

<
>

↶

- Touch the Miele UltraPhase 1 sensor.

The detergent type selected will be marked with a tick ✓ and the display will change to the screen for setting the Dosage amount.

Dosage amount

48 ml

Normal soiling

–

+

↶

OK

- Use the OK sensor to confirm the preset dosage amount or use the – and + sensors to change the amount. Then confirm the new amount.

The washing machine will automatically assign UltraPhase 2 to compartment 2. You just need to confirm or change the dosage amount.

Dosage amount

36 ml

Normal soiling

–

+

↶

OK

- Use the OK sensor to confirm the preset dosage amount or use the – and + sensors to change the amount. Then confirm the new amount.
- Touch the ↶ sensor to return to the main menu.

Settings for other types of detergent

The dosage amounts for Miele products (UltraColor liquid, WoolCare etc.) are preset for normal soiling and need only be confirmed.

Compartment 1

No entry	✓	Miele UltraPhase 1
Miele UltraColor		Miele WoolCare

- Use the < or > sensor to scroll through the display until the type of detergent you want appears.
- Touch the sensor for the detergent type you want.

The detergent type selected will be marked with a tick ✓ and the display will change to the screen for setting the Dosage amount.

Dosage amount

95 ml

Normal soiling

-

+


↶

OK

Useful tip: If you need to set a different dosage amount for Miele products due to lighter or heavier soiling, refer to the label on the Miele detergent bottle. Please note that one cap is equal to 40 ml.

- Use the OK sensor to confirm the preset dosage amount or use the – and + sensors to change the amount. Then confirm the new amount.
- Set compartment 2 as described above.

When adding universal liquid detergent or liquid colour detergent, do not load more than 9 kg of laundry, and when adding liquid detergent for wool and delicates, do not load more than 3 kg of laundry.

- Touch the  sensor to return to the main menu.

Running the first programme

The TwinDos system needs to be primed before you can use the washing machine.


To do this, you **must** run a wash programme **without laundry**.

- Turn on the tap.

Make sure that the washing machine door is closed properly.


- Touch the Programmes sensor.
- Select the Cottons programme.

First the load will appear and then the display will change to show the standard menu for the programme.



- Select TwinDos.

The display will change to show the Degree of soiling menu.



- Use the Heavy sensor to select the Heavy soiling setting and confirm your selection with OK.

If the Miele 2 Phase System is being used:

- Confirm For white items by touching the For white items sensor.

If using other detergents:

- Confirm the marked detergent by touching the relevant sensor.

If using detergent and fabric softener:

- Confirm with the OK sensor.
- Touch the flashing Start/Stop sensor.
- Switch the washing machine off at the end of the programme.

The TwinDos unit is now ready for use.

Washing environmentally and economically

Energy and water consumption

- Water consumption and energy usage are determined by the size of the load.
To make the most out of your machine, load the maximum dry load for the programme you are using.
- When smaller amounts of laundry are washed, the automatic load recognition system will reduce the amount of water and energy used.
- Use the *Express 20* programme for small, lightly soiled loads.
- Modern detergents make it possible to wash at lower temperatures (e.g. 20°C). Washing using lower temperature settings will save energy.
- To maintain the hygiene of the machine, carry out a hot wash (above 60°C) using powder detergent at regular intervals. Hygiene info will appear in the display to remind you to carry out a hot wash.

Detergent consumption

- For precise dispensing, use automatic detergent dispensing.
- Adjust the dosage to the degree of soiling of the laundry.
- Do not exceed the amounts of detergent recommended by the manufacturer on the packaging.

When drying with a tumble dryer

Selecting the highest possible spin speed for the wash programme will save energy when drying in a tumble dryer afterwards.

Washing environmentally and economically

ECO Feedback

You can view information about the energy and water consumption of your washing machine with the ECO feedback sensor.


The following information will appear in the display:

- An estimate of the energy and water consumption before the programme begins.
- The energy and water consumption and the cost during the programme or at the end of the programme.

1. Estimate

- After selecting a programme, touch the ECO feedback sensor.

The estimated energy and water consumption levels will be displayed as bar charts.



The more bars (■) visible, the higher the energy or water consumption.

The estimate will vary depending on the wash programme, temperature and any Extra options selected.

2. Actual consumption

You can view the actual energy and water consumption and the cost during the programme and at the end of the programme. See "Settings - Total consumption" for further information on setting the cost.


- Touch the Change sensor.
- In the standard menu of the programme, select the ECO feedback sensor.



The consumption and cost will alter as the programme progresses.

If the door is opened or the washing machine has switched off automatically at the end of the programme, the data will revert to the estimated consumption.

1. Preparing the laundry



- Empty all pockets.

⚠ Foreign objects (e.g. nails, coins, paper clips, etc.) can cause damage to garments and components in the machine.

Sorting the laundry

- Sort the laundry by colour and by care label. Most garments have a textile care label in the collar or side seam.

Useful tip: Dark textiles often contain excess dye and should be washed separately several times before being included in a mixed load. Always wash white and coloured items separately.

Pre-treating stains

- Badly soiled areas, stains etc. should be cleaned as soon as possible, preferably while still fresh. Spillages should be carefully dabbed off using a soft, colourfast cloth. Do not rub.

Useful tip: Stains can be pre-treated using some handy tricks, which can be found in "Miele's guide to laundry care". Please contact Miele to obtain a copy of this booklet.

⚠ If you use a solvent-based cleaning agent (e.g. one containing benzene) to pre-treat a stain, make sure that any plastic parts (e.g. buttons) are protected, and that the cleaning agent is rinsed off before washing the garment in the machine.

⚠ Do not use solvent-based cleaning agents in or on this machine.

General tips

- Curtains: Remove lead weights first or place in a laundry bag.
- Underwiring and collar stiffeners: Any loose wiring in bras, shirt collar stiffeners, etc. should be removed or sewn in.
- Close any zips, attach velcro fasteners, fasten hooks and eyes etc. before washing.
- Fasten duvet covers and pillow cases to prevent small items from being rolled up inside them.

Do not wash any items in this machine which are specified by the manufacturer as **not washable** on the care label (☒ symbol).

2. Selecting a programme

Switching on the washing machine

In order for the load display to function correctly, the drum must be empty before the washing machine is switched on.

- Press the ① button.


The interior drum lighting will come on.

The drum lighting will go out automatically after five minutes.

The main menu will appear in the display.

Selecting a programme


- Touch the Programmes sensor.



- Scroll with the < or > sensor until the programme you want appears in the display.
- Touch the sensor for the programme.

The load for the programme selected will appear in the display.

- Confirm with the OK sensor or wait a few seconds until the display changes to show the standard menu for the programme.



Alternatively you can select a programme via

- Favourite programmes,
- the Washing assistant,
- Mixed items.

3. Selecting programme settings

Temperature

You can alter the preset temperature of a wash programme.

- Touch the **Temperature sensor**.
- Set the temperature you want with – and + and confirm with **OK**.

Spin speed

You can alter the preset spin speed of a wash programme.

- Touch the **Spin speed sensor**.
- Set the spin speed you want with – and + and confirm with **OK**.

TwinDos

You can switch on automatic dispensing.

- Touch the **TwinDos sensor**.

The display will ask you to enter the degree of soiling of the laundry.

See "Degree of soiling" for more information.

- Set the degree of soiling with the **Light** or **Heavy** sensor and confirm your selection with **OK**.

If the Miele 2 Phase System is being used, a query about the colour mix of the items will also appear.

- **Select** **For white items** or **For coloured items**.

If other types of detergent or fabric softener are being used, these will appear in the display.

The most suitable detergent will appear in the display, marked with a tick (✓).
If both the detergent and the fabric softener are suitable (e.g. detergent for coloured items and fabric softener), then both will be selected.

- **Confirm** or change the selection.

Automatic dispensing is now switched on.

3. Selecting programme settings

ProgrammeManager

The ProgrammeManager Extra option can be used to customise the washing programmes to suit your requirements.

- Touch the Prog. manager sensor.
- Select the option you want.

ProgrammeManager is switched on.

See "ProgrammeManager" for more information.

Extra options

You can use the Extra options to augment the wash programmes.

- Touch the Extras sensor.
- Select one or several Extra options.
- Confirm with the OK sensor.

The Extra option is selected.

See "Extra options" for further information.

Stains

In order to clean stained laundry more effectively, you can choose from a list of various types of stains. The wash programme will then adapt to the types of stains selected.

- Touch the Stains sensor.
- Select the type of stains from the list.

You can select a maximum of three types of stain per wash cycle.

With some stains, helpful information will also appear in the display when they are selected.

- Confirm the information with OK.
- Confirm selection of the stains with the OK sensor.

More information may appear in the display which must be confirmed with OK.

The selection is saved.

Switching on Delay start

You can use Delay start to set the finish time or the start time for a wash programme.

- Touch the Finish at sensor.
- Use the – and + sensors to set the time you want and confirm with the OK sensor.

The Delay start time is saved. See "Delay start" for more information.

3. Selecting programme settings

CapDosing

You can use CapDosing with this wash programme.

- Touch the CapDosing sensor.

The types of capsules which can be used with the programme will appear in the display.

- Select the type of capsule you want.

CapDosing is activated.

See "5. Adding detergent - CapDosing" for more information.

ECO Feedback

You can view information about the energy and water consumption of your washing machine with the ECO feedback sensor.

- Touch the ECO feedback sensor.

The estimated consumption will appear in the display.

See "Washing environmentally and economically - ECO Feedback" for more information.

Load / Dosage

After loading the washing machine you can check the load quantity, the degree of soiling set and the detergent dosage.

- Touch the Load / Detergent sensor.

The actual load will appear in the display.

- Confirm with OK.

The display will change to show the Degree of soiling menu.

If necessary, you can change the degree of soiling once more.

See "Degree of soiling" for more information.


- Confirm with OK.

The display will change to show the Detergent menu.

Detergent will not appear if TwinDos or CapDosing has been selected for the main wash cycle.


4. Loading the washing machine

Opening the door



- Take hold of the door and pull it open.

The load display will now appear.



The display shows the amount of laundry loaded in the drum as a % (in 25% steps) of the maximum load permissible for the programme selected.


- Unfold the laundry and load loosely in the drum.

Mixing both large and small items gives better wash results and also helps distribute the load evenly during spinning.


The most efficient use of energy and water is achieved when a full load is washed. However, do not overload as this reduces cleaning efficiency and causes creases.

4. Loading the washing machine

Closing the door



- Make sure that no items are caught between the door and the seal.




- Shut the door with a gentle swing.

The display will ask you to enter the degree of soiling of the laundry.

- Set the degree of soiling with the **Light** or **Heavy** sensor and confirm your selection with **OK**.

See "Degree of soiling" for more information.

The dosage display will now appear.



- Confirm with **OK**.

Detergent will not appear if **TwinDos** or **CapDosing** has already been selected for the main wash cycle.

5. Adding detergent

There are several options for adding detergent.

TwinDos

If you selected **TwinDos** when setting the programme, detergent will be dispensed automatically for this wash programme.




The detergent dispensed will depend on which agents have been added to the TwinDos unit.

CapDosing

If you selected **CapDosing** when setting the programme, detergent will be dispensed via the capsule for this wash programme.

Only one capsule can be selected per wash programme.


Three different types of capsule are available:

-  = Fabric care (e.g. fabric softener)
-  = Additives (e.g. detergent enhancers)
-  = Detergent (for the main wash only)

Depending on the setting selected, the detergent, additive or fabric care agent will be dispensed via the capsule.


Each capsule contains the correct amount for one wash cycle.



You can order the capsules online at www.miele-shop.com (depending on country) or from Miele (see the end of this booklet for contact details).


 Keep capsules out of the reach of children.

Inserting a capsule

- Open the detergent dispenser drawer.




- Open the lid of the /  compartment.



- Press the capsule in firmly.


5. Adding detergent




- Close the lid and press it firmly shut.
- Close the detergent dispenser drawer.

The capsule is opened by the act of inserting it in the detergent dispenser drawer. The contents can run out of the capsule if you then remove it from the drawer before it is used. In this case, dispose of the capsule and do not re-use it.

The wash programme will dispense the contents of the capsule at the correct time.

Water intake to the  compartment is solely via the capsule.

No additional fabric softener may be added to the  compartment when using a capsule.

- Remove the empty capsule at the end of the programme.

For technical reasons a small amount of water will remain in the capsule.

5. Adding detergent

Detergent dispenser drawer

Add detergent in accordance with the value in the dosage display.

The percentage shown relates to the amount of detergent recommended by the manufacturer on the packaging.

- 40% = Add slightly less than half the amount recommended
- 50% = Add half the amount recommended
- 60% = Add slightly more than half the amount recommended
- 75% = Add three quarters of the amount recommended
- 100% = Add the full amount of the detergent recommended


Take the hardness level of your water into account.

Too little detergent results in:

- laundry not getting properly clean and with time it may become grey and hard to the touch.
- greasy particles clinging to the laundry.
- limescale deposits on the heater elements.



Too much detergent results in:

- excessive foam which causes a low level of agitation and poor wash, rinse and spin results.
- high water consumption (an additional rinse cycle will automatically switch in).
- a greater burden to the environment.



- Pull out the detergent drawer and add detergent to the compartments.



Detergent for the pre-wash (divide the total recommended amount as follows: add $\frac{1}{3}$ to compartment  and $\frac{2}{3}$ to compartment )



Detergent for the main wash, including Soak if selected



Fabric softener, liquid starch or capsules

See "Detergent" for further information.


6. Starting the programme - the end of the programme

Starting the programme

- Touch the flashing *Start/Stop* sensor.

The door will lock (🔒) will appear in the display to show this) and the programme will start.

The programme status will appear in the display.



The washing machine lets you know which section of the programme has been reached ① and the programme duration remaining ②. If a Delay start time has been selected, then this will appear in the display.

The drum lighting switches off once the programme has started.

At the end of the programme

The door is still locked during the Anti-crease phase and the following will appear alternately in the display: Anti-crease and Finished.


The following information will also appear: Press the Stop button, then unload the drum

- Touch the *Start/Stop* sensor. This will unlock the door.

The door unlocks automatically at the end of the Anti-crease phase.


- Pull open the door.
- Remove the laundry.

Check that all items have been removed from the drum. Items left in the drum could discolour other items in the next wash or become discoloured themselves.



- Check the folds in the door seal for any small articles, e.g. buttons, which might be lodged there.
- Switch the washing machine off with the ① button.
- Close the door. Otherwise there is a danger of objects being placed inadvertently in the drum. If these remained unnoticed and were washed in the next load, they could damage the laundry. An open door is also a danger to pets and children.
- If applicable, remove the used capsule from the detergent dispensing drawer.

If you have selected automatic dispensing or loaded the washing machine, the display will then prompt you to enter the degree of soiling.



You can set the degree of soiling with the **Light** or **Heavy** sensor. Your selection is confirmed with the **OK** sensor.

Lightly soiled

No visible dirt or stains. Possibly slight body odour.

Normally soiled

Visibly dirty and/or just a few slight stains.

Heavily soiled

Stains and soiling clearly visible.

The following parameters will change, depending on the degree of soiling selected:




- detergent dosage
- rinse water level
- The programme durations (with light soiling the programme duration will be shorter).

The degree of soiling cannot be selected for some programmes. These programmes are designed for moderately soiled laundry.

Useful tip: You can alter the default setting for the degree of soiling or switch off the degree of soiling query in Settings (see "Settings - Degree of soiling").

Spinning

Final spin speed

Programme	rpm
Cottons 	1600
Cottons	1600
Minimum iron	1200
Delicates	900
Woollens 	1200*
Denim	900
Shirts	900
Steam care	–
Express 20	1200
QuickPowerWash	1600
Automatic plus	1400
Freshen up	–
Dark garments	1200
Down duvets	1200
Outerwear	800
Proofing	1000
Separate rinse	1600*
Starch	1400*
Silks 	600*
Sportswear	1200
Down Items	1200
Curtains	600
First wash	1200
Pillows	1200
Drain/Spin	1600
Clean machine	900

Final spin speed in the programme

When a programme is selected, the optimum spin speed for that programme will appear in the display. For programmes marked with a * in the chart, the optimum spin speed is not the maximum spin speed.

You can reduce the final spin speed.

However, you cannot select a final spin speed higher than that shown in the chart.

Rinse and interim spin

There is a spin after the main wash and between the rinses. A reduction in the final spin speed will also reduce the interim spin speed. If a spin speed of less than 700 rpm is selected for the *Cottons* programme, an additional rinse is introduced.

Omitting the final spin (Rinse hold)

- Select the Rinse hold option. The laundry is not spun after the final rinse and remains in the final rinse water. This helps prevent creasing if the laundry is not going to be removed from the drum immediately after the end of the programme.

To start the final spin:

- Touch the Change sensor.
- Select Spin speed and set the spin speed you want.
- Start the final spin with the *Start/Stop* sensor.

To end the programme:

- Touch the Change sensor.
- Select Spin speed and set the spin speed to 0 rpm (no spin).
- Touch the *Start/Stop* sensor.

The water will drain away.







Omitting rinse and interim spin and the final spin

- Touch the Spin speed sensor.
- Select the 0 rpm setting.






After the last rinse, the water will be pumped away and the Anti-crease phase will switch in.

In some programmes an additional rinse is introduced with this setting.





Programme chart

Cottons 		 40°C	Max. load 9.0 kg
Items	Normally soiled cotton garments.		
Notes	These settings are the most efficient in terms of energy and water consumption for washing cottons.		
Energy labelling programme according to AS/NZS 2040.1 & AS/NZS 2040.2			
Cottons 		 60°C	Max. load 9.0 kg
Items	Cottons, linens or cotton mix fabrics, e.g. table linen, towelling, underwear, T-shirts etc.		
Notes	With  60°C the actual wash temperature reached will be lower than 60°C although the wash performance is the same as with the standard Cottons 60°C programme.		
Cottons		Cold to 90°C	Max. load 9.0 kg
Items	Cottons, linens or cotton mix fabrics, e.g. table linen, towelling, underwear, T-shirts etc.		
Note	Where particularly high levels of hygiene are required, please select a temperature of 60°C or higher.		
Minimum iron		Cold to 60°C	Max. load 4.0 kg
Items	Synthetic, mixed fibre and easy care cotton.		
Note	Reduce the spin speed for fabrics which crease easily.		
Delicates		Cold to 60°C	Max. load 3.0 kg
Items	Delicate garments made from synthetic fibre, mixed fibre, rayon and viscose.		
Note	For items which crease easily, deselect the spin.		
Woollens 		Cold to 40°C	Max. load 2.0 kg
Items	Machine-washable or hand-washable wool or wool blend fabric. If the care label does not specify a temperature, wash using the cold setting.		
Note	Reduce the spin speed for items which crease easily.		

Programme chart

Denim		Cold to 60°C	Max. load 3.0 kg
Notes	<ul style="list-style-type: none"> – Wash denim inside-out. – Denim often contains excess dye and may run during the first few washes. Wash light and dark coloured items separately. – Close any zips, do up buttons etc. before washing. 		
Shirts		Cold to 60°C	Max. load 2.0 kg
Items	Shirts and blouses made of cotton and mixed fibre.		
Notes	<ul style="list-style-type: none"> – Pre-treat collars and cuffs if necessary. – Wash silk shirts and blouses in the <i>Silks</i>  programme. 		
Steam care			Max. load 2.0 kg
Items	<p>Reduces the amount of creasing in damp, freshly washed and spun cotton or linen garments.</p> <p>The garments must be suitable for drying in a tumble dryer   and suitable for ironing  .</p>		
Notes	<ul style="list-style-type: none"> – 5-6 shirts make up a load of approx. 2.0 kg. – Smaller loads give a better result. – Remove garments as soon as the programme has finished and then tumble dry using the Gentle smoothing programme or place on a hanger to dry. – Not suitable for garments made of wool or wool blend fabric. 		
Express 20		Cold to 40°C	Max. load 3.5 kg
Items	Cotton garments that have hardly been worn or are only very lightly soiled.		
Note	The <i>Short Extra</i> option is activated automatically.		
QuickPowerWash		40°C – 60°C	Max. load 5.0 kg
Items	Moderately soiled garments which are also suitable for washing in the <i>Cottons</i> programme.		
Note	A special saturation process and wash rhythm ensure that the laundry is cleaned particularly quickly and thoroughly.		


Programme chart

Automatic plus		Cold to 40°C	Max. load 6.0 kg
Items	Mixed loads of garments suitable for the <i>Cottons</i> and <i>Minimum iron</i> programmes. Sort according to colour.		
Note	The wash parameters (e.g. water level, wash rhythm and spin speed) are adjusted automatically in this programme to ensure the best possible care and wash result for each item.		
Freshen up			Max. load 1.0 kg
Items	<p>Dry, clean cotton, linen or mixed fibre garments which are slightly creased.</p> <p>The garments must be suitable for drying in a tumble dryer   and suitable for ironing  .</p>		
Notes	<ul style="list-style-type: none"> – Smaller loads give a better result. – Remove garments as soon as the programme has finished and then tumble dry using the Gentle smoothing programme or place on a hanger to dry. – Not suitable for garments made of wool or wool blend fabric. 		
Dark garments		Cold to 60°C	Max. load 3.0 kg
Items	Black and dark items made of cotton or mixed fibres.		
Note	Wash inside-out.		
Down duvets		Cold to 60°C	Max. load 2.5 kg 1 down duvet 2.20 m x 2.00 m
Items	Quilts, duvets and pillows with feather or down filling.		
Notes	<ul style="list-style-type: none"> – Remove air from the items before washing to prevent an excessive build-up of foam. To do this, either push the items into a narrow laundry bag to compress them or tie the items together with a washable strap. – Please observe the instructions on the wash care label. 		

Programme chart

Outerwear		Cold to 40°C	Max. load 2.5 kg
Items	Performance outerwear (e.g. jackets and trousers) made from membrane fabric such as Gore-Tex®, SYMPATEX®, WINDSTOPPER® etc.		
Notes	<ul style="list-style-type: none"> – Zip up or close jackets before washing. – Do not use fabric softener. – If required, these garments can also be re-proofed using the <i>Proofing</i> programme. Proofing should not be done every time the garment is washed. 		
Proofing		40°C	Max. load 2.5 kg
Items	Treating microfibre fabric, skiwear and table linen made from mainly synthetic fibres to provide a water and dirt resistant finish.		
Notes	<ul style="list-style-type: none"> – The items should be freshly laundered and spun or dried before proofing. – For best results, the items should be heat-treated afterwards either in a tumble dryer or by ironing. 		
Separate rinse			Max. load 9.0 kg
Items	For rinsing hand-washed items.		
Note	Reduce the spin speed for items which crease easily.		
Starch			Max. load 9.0 kg
Items	Starching table cloths, serviettes and workwear.		
Notes	<ul style="list-style-type: none"> – Reduce the spin speed for items which crease easily. – Laundry that is to be starched should be washed but not treated with fabric softener. 		








Programme chart




Silks 		Cold to 30°C	Max. load 1.0 kg
Items	Silks and other hand-washable fabrics with no wool content, e.g. satin, lace and silk.		
Note	Place tights, bras etc. in a washing bag.		
Sportswear		Cold to 60°C	Max. load 3.0 kg
Items	Sportswear such as singlets and leggings as well as microfibre and fleece garments.		
Notes	<ul style="list-style-type: none"> – Do not use fabric softener. – Observe the manufacturer's care label. 		
Down Items		Cold to 60°C	Max. load 2.0 kg
Items	Jackets, sleeping bags, pillows and other down-filled items.		
Notes	<ul style="list-style-type: none"> – Remove air from the items before washing to prevent an excessive build-up of foam. To do this, either push the items into a narrow laundry bag to compress them or tie the items together with a washable strap. – Please observe the instructions on the wash care label. 		
Curtains		Cold to 40°C	Max. load 2.0 kg
Items	Curtains, including net curtains, specified as machine-washable by the manufacturer.		
Notes	<ul style="list-style-type: none"> – To remove dust, the <i>Pre-wash</i> option is selected automatically. – For curtains which crease easily, reduce the spin speed or deselect the spin. – Remove weights from curtains. 		
First wash		Cold to 40°C	Max. load 3.0 kg
Items	New items made of cotton, towelling and polyester fabric.		
Note	Use this programme to wash any manufacturing residues out of new items.		

Programme chart

Pillows		Cold to 60°C	2 pillows (40 x 80 cm) or 1 pillow (80 x 80 cm)
Items	Synthetic filled washable pillows.		
Notes	<ul style="list-style-type: none"> – Remove air from the items before washing to prevent an excessive build-up of foam. To do this, either push the items into a narrow laundry bag to compress them or tie the items together with a washable strap. – Please observe the instructions on the wash care label. 		
Drain/Spin			–
Notes	<ul style="list-style-type: none"> – Drain only: Select 0 rpm for the spin speed. – Make sure you select the appropriate spin speed. 		
Clean machine		75°C	No load
<p>With frequent washing at low temperatures there is a danger of a build-up of bacteria in the washing machine.</p> <p>Cleaning the washing machine will significantly reduce bacteria, fungus and biofilm and prevent the build-up of unpleasant odours.</p>			
Notes	<ul style="list-style-type: none"> – Optimum results can be achieved by using Miele dishwasher and washing machine cleaner. Alternatively, a universal powder detergent can be used. – Dispense the machine cleaner or universal detergent directly in the drum. – Do not load any laundry. The drum must be empty for this machine maintenance wash. 		

Programme sequence

	Main wash		Rinse		Spin
	Water level	Wash rhythm	Water level	Rinses	
Cottons 		(A)		2-5 ²⁾³⁾	✓
Cottons		(A)		2-5 ¹⁾²⁾³⁾	✓
Minimum iron		(B)		2-4 ²⁾³⁾	✓
Delicates		(C)		2-4 ²⁾³⁾	✓
Woolens 		(E)		2	✓
Denim		(B)		2-4 ²⁾³⁾	✓
Shirts		(C)		3-4 ³⁾	✓
Express 20		(A)		1	✓
QuickPowerWash		(A)		1	✓
Automatic plus		(A) (B)		2-4 ²⁾³⁾	✓
Dark garments		(B)		3-5 ²⁾³⁾	✓
Down duvets ⁴⁾		(C)		3-4 ³⁾	✓
Outerwear		(C)		3-4 ³⁾	✓
Proofing	–	(B)		1	✓
Separate rinse	–	–		2	✓
Starch		(B)	–	–	✓
Silks 		(E)		2	✓
Sportswear		(C)		2-3 ³⁾	✓
Down Items ⁴⁾		(C)		3-4 ³⁾	✓
Curtains		(C)		3-4 ³⁾	✓
First wash		(B)		2-3 ³⁾	✓
Pillows ⁴⁾		(C)		3-4 ³⁾	✓
Drain/Spin	–	–	–	–	✓
Clean machine		(A)		3	✓

-  = Low water level
 = Medium water level
 = High water level
Ⓐ = Intensive rhythm
Ⓑ = Normal rhythm
Ⓒ = Sensitive rhythm
Ⓓ = Ultra sensitive rhythm
Ⓔ = Handwash rhythm
✓ = Carried out
– = Not carried out

The washing machine has fully electronic controls with automatic load recognition. It takes in the right amount of water required for the programme depending on the amount of laundry and its absorbency rate.

The programme sequences outlined in the chart are based on the basic programme with a full load.

The washing machine programme sequence display shows which stage of the programme has been reached.

Special features in the programme sequence

Anti-crease:

At the end of the programme the drum continues to turn at intervals for up to 30 minutes to help prevent creasing.

Exception: There is no Anti-crease phase in the *Woolens* and *Silks* programmes.

The door can be opened at any time during the Anti-crease phase.


¹⁾ A second rinse is carried out when a temperature of 60°C or above is selected. A third rinse is carried out when a temperature below 60°C is selected.

²⁾ An additional rinse is carried out if:

- there is too much foam in the drum.
- a spin speed lower than 700 rpm has been selected.
- the spin speed has been deselected.

³⁾ An additional rinse is carried out if:

- the Extra rinse option is selected.

⁴⁾ Run-up to spin: A run-up to spin is carried out before the wash process begins to deflate down filled items. Subsequent water intake for the main wash is through compartment .

Garment care label symbols

Washing	
The figure quoted in the bucket is the maximum temperature at which the garment can be washed. The number of bars under the symbol indicates the level of agitation permitted.	
	No bar under the symbol = normal agitation
	One bar under the symbol = reduced agitation
	Two bars under the symbol = much reduced agitation
	Hand wash (If no temperature is specified, use the lowest temperature or cold)
	Do not wash

Programme selection examples

Programme	Garment care label symbols
Cottons	
Minimum iron	
Delicates	
Woollens	
Silks	
Express 20	
Automatic plus	

Drying	
The number of dots indicates the drying temperature.	
	Normal temperature
	Low temperature
	Do not tumble dry

Ironing	
The number of dots indicates the ironing temperature.	
	approx. 200°C
	approx. 150°C
	approx. 110°C
	Do not steam iron garments carrying this symbol as this could cause irreversible damage.
	Do not iron

Professional cleaning	
	Dry clean only. The letters indicate the type of cleaning agent required.
	Professional Wet Clean only
	Do not dry clean

Bleaching	
	Any oxidising bleaching agent can be used
	Only use an oxygen based bleach or a non-chlorine bleach
	Do not bleach

Changing the programme sequence

Cancelling a programme

You can cancel a programme at any time after it has started.

- Touch the *Start/Stop* sensor.
- Select *Cancel programme*.

The suds will be pumped away. The programme is now cancelled. The door lock will be released.

- Pull open the door.
- Remove the laundry.

If you want to select a different programme:

- Close the door.
- Select the programme you want.
- Add detergent to the detergent dispenser drawer, if necessary.
- Touch the *Start/Stop* sensor.

The new programme will begin.

Interrupting a programme

- Switch the washing machine off with the ① button.
- Switch the washing machine back on with the ① button to continue with the same programme.

Changing a programme and settings

Programme

After the start of a programme, it is no longer possible to select a different programme.

Temperature

The temperature can be changed within the first five minutes, except in the *Cottons* programme.

- Touch the *Change* sensor.
- Touch the *Temperature* sensor.
- Set the temperature you want with – and + and confirm with OK.

Spin speed

Once a programme has started, you can change the spin speed up until the final spin begins.

- Touch the *Change* sensor.
- Touch the *Spin speed* sensor.
- Set the spin speed you want with – and + and confirm with OK.

Extra options

It is possible to select or deselect certain Extra options up to five minutes after the programme has started.

It is not possible to make any changes to the programme or to cancel it if the safety lock has been activated.


Changing the programme sequence

Adding or removing laundry after a programme has started

You can add or remove items during the first few minutes after the programme has started.

- Touch the *Start/Stop* sensor.

The following will appear in the display:



- Touch the *Add laundry* sensor.

The programme will stop and the door will unlock.

- Pull open the door.
- Add laundry or remove individual items.
- Close the door.
- Touch the *Start/Stop* sensor.

The programme will continue.

Please note the following:

Once a programme has started, the washing machine cannot recognise any adjustment to the load.

For this reason, if laundry is added or removed after the start of a programme, the machine will always complete the programme cycle assuming a full load.

The door cannot be opened if:

- the suds temperature is above **55°C**.
- the water is above a certain level.
- the programme has reached the *Spin* stage.

If you want to open the door when the above conditions are present, you will need to cancel the programme.

The safety lock will remain activated if the temperature in the drum is above 55°C. The lock will not deactivate until the temperature has dropped to below 55°C.

Safety lock

The safety lock prevents the temperature, spin speed or options being altered during a wash programme.

Activating the safety lock

- Touch the *Start/Stop* sensor.
- Select *Activate safety lock*.

Locked appears in the display.

The safety lock is activated.

Deactivating the safety lock

- Touch the *Start/Stop* sensor.

Deactivate safety lock? appears in the display.

- Confirm that you want to deactivate the safety lock with the *Deactivate* sensor.

Unlocked appears in the display.

The safety lock is now deactivated.

ProgrammeManager

The ProgrammeManager Extra option can be used to customise the washing programmes to suit your requirements.

Intensive

For hard-wearing laundry that is very heavily soiled. Cleaning efficiency is increased through more intense mechanical action and the application of more heat energy.

ECO

This option reduces energy consumption whilst maintaining cleaning efficiency. This is achieved by increasing the wash duration and at the same time reducing the wash temperature selected.





Extra gentle

This option decreases mechanical action in order to reduce creasing.

Extra quiet

This option reduces noise levels during the programme. Use this if you want to wash during quiet periods (for instance, when children are sleeping). The machine will activate the "Rinse hold" option and not spin. The programme duration is longer.




AllergoWash

This option should be used where high standards of hygiene are required. More energy is used to lengthen temperature holding times and more water is used to increase rinsing efficiency. The items must be suitable for drying in a tumble dryer   and suitable for ironing  .

Not all ProgrammeManager options are suitable for use with every programme. Please refer to the "Wash programme chart - ProgrammeManager" on the following page for a list of suitable programmes.

Wash programme chart - ProgrammeManager





ProgrammeManager cannot be selected with programmes which are **not** listed in the chart below.

	Intensive	ECO	Extra gentle	Extra quiet	Allergo-Wash
Cottons 	–	–	X	X	X
Cottons	X	X	X	X	X
Minimum iron	X	X	X	X	X
Delicates	X	X	X	X	X
Woolens 	–	–	–	X	–
Denim	X	X	X	X	X
Shirts	X	X	X	X	X
Express 20	–	–	–	X	–
Automatic plus	X	X	X	X	X
Dark garments	X	X	X	X	X
Down duvets	X	X	X	–	X
Outerwear	X	X	X	X	X
Proofing	–	–	–	X	–
Separate rinse	–	–	–	X	–
Starch	–	–	–	X	–
Silks 	–	–	–	X	–
Sportswear	X	X	X	X	X
Down Items	X	X	X	X	X
Curtains	X	X	X	X	X
First wash	–	–	X	X	–
Pillows	X	X	X	X	X

Extra options

Steam smoothing

Steam is injected into the drum at the end of the wash process. Reducing the maximum load by 50% will give a better result. For steam smoothing to work properly there needs to be a certain amount of residual moisture still present in the laundry. The final spin speed is therefore adjusted accordingly.

The garments must be suitable for drying in a tumble dryer   and suitable for ironing  .

Soak

For heavily soiled and stained items with protein stains.

A duration of between 30 minutes and 5 hours in 30-minute increments can be chosen for the soak process. See "Settings" for more information.

The factory default setting is 30 minutes.

Short

For light soiling with no visible staining.

The wash duration is reduced.

Rinse hold

The laundry is not spun after the final rinse and remains in the final rinse water. This helps prevent creasing if the laundry is not going to be removed from the drum immediately after the end of the programme.

Pre-wash

For laundry with large amounts of dirt, e.g. dust and sand.

Water plus

The water level in the main wash and the rinses will be increased if the Water plus Extra option is selected.

You can select by how much the water level is increased (see "Settings - Water plus level").




Extra rinse

An additional rinse cycle can be carried out to give a better rinse result.

Not all options are suitable for use with every programme. You can only select options which are compatible with the programme being used. Please refer to the "Wash programme chart - Extra options" on the following page for a list of suitable programmes.

Wash programme chart - Extra options

None of the options can be selected with programmes which are not listed in the chart below.

	Steam smoothing	Soak	Short	Rinse hold	Pre-wash	Water plus	Extra rinse
Cottons 	X	X	X	X	X	X	X
Cottons	X	X	X	X	X	X	X
Minimum iron	X	X	X	X	X	X	X
Delicates	X	X	X	X	X	X	X
Woolens 	-	-	-	X	-	-	-
Denim	X	X	X	X	X	X	X
Shirts	X ¹⁾	X	X	X	X	X	X
Express 20	X	-	X ¹⁾	X	-	-	-
QuickPowerWash	X	-	-	X	-	-	-
Automatic plus	X	X	-	X	X	-	-
Dark garments	X	X	X	X	X	X	X
Down duvets	-	-	-	X	X	X	X
Outerwear	-	X	X	X	X	X	X
Proofing	-	-	-	X	-	-	-
Separate rinse	X	-	-	X	-	-	-
Starch	-	-	-	X	-	-	-
Silks 	-	-	-	X	-	-	-
Sportswear	-	X	X	X	X	X	X
Down Items	-	-	-	X	X	X	X
Curtains	X	-	-	X	X ¹⁾	X	X
First wash	-	-	-	X	-	X	X
Pillows	-	-	-	X	X	X	X

X = Can be selected / - = Cannot be selected / ¹⁾ = Can be deselected

Delay start


With Delay start you can choose when you want the programme to start. You can delay the start of the programme from 15 minutes up to a maximum of 24 hours, allowing you to make use of night-time economy electricity rates, for example.

Selecting Delay start

The current time of day needs to be set for Delay start to work correctly.

- After selecting the programme, touch the Finish at sensor.

Useful tip: Via Settings you can select a start time for the programme instead of a finish time. In this case Start at will light up in the display.



- Use the + and - sensors to enter the hour and confirm your entry with the OK sensor.

The minutes are now highlighted in white and can be set.


The minutes entry moves to 00 and can then be adjusted in 15-minute increments.

- Confirm with the OK sensor.

Beginning Delay start

- Touch the Start/Stop sensor to begin Delay start.

The door will lock and the following will appear in the display:



Changing Delay start

- Touch the Change sensor.
- Select Finish at.
- Select Change the time.
- Now set the time you want and confirm with OK.

Start now


- Touch the Change sensor.
- Select Finish at.
- Select Start now.

The programme will start.

Cancelling Delay start

- Touch the *Start/Stop* sensor.

The Selection menu will appear:



- Select Cancel Delay start.

The basic programme menu will appear and the *Start/Stop* sensor will flash.

Adding or removing laundry after a programme has started

- Touch the *Start/Stop* sensor.
- Touch the Add laundry sensor.

The door will be unlocked.

- Pull open the door.
- Add laundry or remove individual items.
- Close the door.
- Touch the *Start/Stop* sensor.

Delay start will continue.

Favourite programmes

You can save your own customised wash programmes under names of your choice.

The saved favourite programmes will be sorted alphabetically.

Creating a favourite programme

There are two ways of creating a favourite programme.

Option 1

- With the main menu visible in the display, touch the **Favourite programmes sensor**.

The display will change to show the **Favourites menu** **Favourite programmes**.

- Touch the **Create sensor**.

The **Create sensor** will not appear if the maximum number of 10 favourite programmes has already been reached.

The display will change to show the **Select a programme menu**.

- Select the programme you want.

The display will guide you automatically through all the further programme settings.

A summary of the selected parameters will then appear in the display.

Useful tip: If a parameter is not correct, it can be changed. Touch the **↩ sensor** repeatedly until the programme setting you want appears in the display and then change it.

When all the parameters are correct:

- Select **OK**.


Option 2

You can save a programme which has been selected and started as a **Favourite programme**.

- After the programme has started successfully, touch the **Save sensor**.
- Enter a name.

Entering names/Saving favourite programmes

You can enter a name of up to 10 characters.



- Touch the sensor of the first letter of the word you want to enter.
- Add the next characters in exactly the same way.

By selecting one of the following symbols you can select upper or lower case and also delete or change characters:

- = Enter a space
- 123 = Enter numbers
- abc/ABC = Enter letters as lower/upper case
- = Delete all characters
- = Delete the last character

- Touch **Save** to confirm.

The programme will be saved as a favourite.

Changing a favourite programme

You can change a saved favourite programme and then save it again under the same or a different name.

- Select Favourite programmes from the main menu.
- Select the **Change** sensor.
- Select the favourite programme you want to change.
- Select the same programme in order to change a few programme settings or select a new programme.

The display will guide you through all the further programme settings.

Deleting a Favourite programme

If you have already saved ten favourite programmes, you will need to delete one of these before you can save a new one.

- Select Favourite programmes from the main menu.
- Select the **Delete** sensor.
- Select the Favourite programme that you want to delete.
- Confirm with the **Delete** sensor and then with the **OK** sensor.

The Favourite programme is now deleted.

Washing assistant

The Washing assistant guides you step by step so that you can select the optimum wash programme for your laundry.

- Touch the Washing assistant sensor in the main menu.

The display will show a list of types of textile.

Fabric fibre	
Cotton	Synthetic
Cottons + synthetic	Wool
<hr/>	
<	>
↶	

- Touch the sensor for the textile type which matches your laundry.

Cotton	
Light-coloured laundry	Coloured laundry
Dark-coloured laundry	

- Select the colour of the items.

Cotton

Lightly soiled	Normally soiled
Heavily soiled	

- Select the degree of soiling of the items.

Cotton

Laundry not spun	Low spin speed
Normal spin speed	

- Select how you want the items to be spun.

A summary of the selected parameters will then appear in the display.

- Confirm with the OK sensor.

The programme which has been tailored to your laundry is ready to start.

Useful tip: You can add individual programme settings, e.g. TwinDos before you start the programme.

Use this programme if you do not have enough laundry to run a standard programme but you want to wash a few lightly soiled items with different garment care instructions.

The washing machine will use the list of items to put together a suitable wash programme.

Selecting items

- Touch the **Mixed items** sensor in the main menu.

A list of items will appear.

Select items

<input type="checkbox"/> Swimwear	<input type="checkbox"/> Bathrobes
<input type="checkbox"/> Bed linen	<input type="checkbox"/> Bras/Lingerie

< >

↺

- Touch the appropriate sensor for your item of laundry.

The item selected will be marked with ✓. You can select several items.

- Confirm with the **OK** sensor.

Information regarding the programme may appear in the display, e.g. use of detergent.

- Confirm the information with **OK**.

The washing machine has put together the optimum programme for these items.

Useful tip: You can add individual programme settings, e.g. **TwinDos**, before you start the programme.

The list of items selected will be deleted at the end of the programme and you will need to select a new list the next time you use this programme.

Changing / Deleting / Displaying the list of items selected

The **Item** sensor will show how many articles have been selected.

By touching the **Item** sensor you can display the items again, delete or change them.

Making changes

- Confirm an item which you have already selected in order to deselect it.

The tick ✓ will go out.

- Select more items.
- Confirm with the **OK** sensor.
- You can also change other programme settings, e.g. temperature, spin speed or Delay start.

Detergent

The correct detergent

All detergents produced for automatic front loading washing machines are suitable. Follow the manufacturer's instructions and dosage recommendations on the packaging.

The right amount to dispense will depend on the following:

- The soiling level of the laundry.
- The quantity of laundry.

Detergent dispensing aids

Use dispensing aids, (e.g. balls) if these are supplied with the detergent, particularly when using liquid detergent.

Refill packs of detergent

When purchasing detergent, buy refill packs wherever possible. This helps reduce the amount of waste packaging.

Fabric softeners and liquid starch

Fabric softeners

make garments soft to handle and help prevent static cling when tumble drying.

Fabric shapers







are synthetic starches and give an even stiffer hold.

Starch

stiffens and gives body to items of laundry, e.g. shirts, tablecloths and bed linen.

Miele recommended detergents

Miele detergents and care products have been specially designed for Miele washing machines. They are available to order via the internet at www.miele-shop.com (depending on country) or from Miele.

	Miele UltraPhase 1 / 2	Miele Cap 	Miele Cap 	Miele Cap 
Cottons 	✓	–	(E)	(F)
Cottons	✓	–	(E)	(F)
Minimum iron	✓	–	(E)	(F)
Delicates	✓	–	(E)	–
Woollens 	–	(C)	–	–
Denim	✓	–	(E)	–
Shirts	✓	–	(E)	(F)
Express 20	✓	–	(E)	–
QuickPowerWash	✓	–	–	–
Automatic plus	✓	–	(E)	(F)
Dark garments	✓	–	(E)	–
Down duvets	–	(B)	–	–
Outerwear	–	–	–	–
Proofing	–	–	–	–
Silks 	–	(D)	–	–
Sportswear	–	(A)	–	–
Down Items	–	(B)	–	–
Curtains	✓	–	–	(F)
First wash	✓	–	(E)	–
Pillows	✓	–	–	–
Mixed items	✓	–	(E)	–

✓ Recommended

– Not recommended

(A) Sportswear

(B) Down Items

(C) WoolCare




(D) SilkCare

(E) Fabric Softener

(F) Booster

Detergent

The recommendations apply to the temperature ranges given in the Programme chart.

	Universal	Colour	Delicates and woollens	Special
	detergent			
Cottons 	✓	✓	–	–
Cottons	✓	✓	–	–
Minimum iron	–	✓	–	–
Delicates	–	–	✓	–
Woollens 	–	–	✓	✓
Denim	–	✓ ¹⁾	–	✓
Shirts	✓	✓	–	–
Express 20	–	✓ ¹⁾	–	–
QuickPowerWash	✓	✓	–	–
Automatic plus	–	✓	–	–
Dark garments	–	✓ ¹⁾	–	✓
Down duvets	–	–	✓	✓
Outerwear	–	–	✓	✓
Silks 	–	–	✓	✓
Sportswear	–	–	✓	✓
Down Items	–	–	✓ ¹⁾	✓
Curtains	✓ ²⁾	–	–	✓
First wash	–	✓	–	–
Pillows	–	–	✓ ¹⁾	✓
Mixed items	depending on the items selected - observe the information in the display			

✓ Recommended

– Not recommended

¹⁾ Liquid detergent

²⁾ Powder detergent

Dispensing fabric softener and liquid starch at the end of the programme

You can dispense fabric softener either by using automatic dispensing or via the detergent dispenser compartment.

Automatic dispensing

One of the automatic dispensing containers must be filled with fabric softener.


- Select the programme required.
- Select TwinDos.
- Select the degree of soiling level of the load.

The display will change to show the Select agent menu.

- Make sure that *Fabric softener* is marked and confirm the selection with the OK sensor.

Fabric softener will be dispensed in the last rinse.

Manual dispensing





- Add the fabric softener or liquid starch to the ☼ compartment or insert the appropriate capsule. **Do not exceed the maximum level mark.**

It will be automatically dispensed in the final rinse. At the end of the programme a small amount of water will remain in the ☼ compartment.



If starching frequently, thoroughly clean the dispenser compartment, especially the siphon tube, regularly.

Detergent

Adding fabric softener separately

- Add fabric softener to the  compartment or insert the appropriate capsule.
- Select the *Separate rinse* programme.
- Change the spin speed if necessary.
- If using a capsule, activate the *CapDosing* sensor and select  *Cap*.
- Touch the *Start/Stop* sensor.

Adding starch separately

- Add liquid starch to the  compartment and powder or viscous starch to the  compartment.
- Select the *Starch* programme.
- Change the spin speed if necessary.
- Touch the *Start/Stop* sensor.

Colour run and dye removers/dyes



Do not use colour run or dye removers in this washing machine. They can cause corrosion in the machine.

Dyes suitable for use in domestic washing machines can be used. However, please note that the salt used in the dyeing process can cause corrosion to stainless steel components in the machine if you dye frequently. Always observe the manufacturer's instructions carefully.



When using the washing machine to dye fabric it is essential to select the *Water plus* option.

Cleaning the drum (Hygiene info)

Washing at low temperatures and/or using liquid detergent can cause bacteria and unpleasant odours to build up in the washing machine. Use the **Clean machine** programme to clean the machine. Run this programme regularly or at the latest when **Hygiene info**: Start a programme with a minimum temperature of 75°C appears in the display.

External casing and fascia panel

⚠ Disconnect the machine from the mains electricity supply and withdraw the plug from the socket before cleaning the machine.

⚠ The washing machine must not be hosed down.


- Clean the casing with a mild non-abrasive cleaning agent or soap and water using a well wrung-out cloth. Wipe dry with a soft cloth.
- The drum can be cleaned using a suitable proprietary stainless steel cleaning agent following the manufacturer's instructions on the packaging.

⚠ Do not use solvents, abrasive cleaners, glass cleaners or all-purpose cleaning agents. These might damage plastic surfaces and other components because of the chemicals they contain.

Cleaning the detergent dispenser drawer

Washing at low temperatures and the use of liquid detergent can lead to a build-up of mould and bacteria in the detergent dispenser drawer.

- Clean the entire drawer at regular intervals for hygiene reasons, even if you are using the TwinDos system exclusively.




- Pull out the detergent dispenser drawer until a resistance is felt. Press down the release button and at the same time pull the drawer right out of the machine.
- Clean the detergent drawer with warm water.

Cleaning and care


Cleaning the siphon tube and the fabric softener channel

Liquid starch can cause the siphon to become clogged. Make sure that you clean the siphon and siphon tube particularly thoroughly after using liquid starch a few times.




■ Clean the siphon.

1. Remove the siphon from compartment 8 and rinse under warm running water. Clean the siphon tube in the same way.
2. Refit the siphon.



■ Clean the fabric softener channel using a brush and warm water.

Cleaning the detergent dispenser drawer housing



- Use a bottle brush to remove detergent residues and limescale from the jets inside the detergent dispenser drawer housing.

Cleaning the TwinDos system

The washing machine has a cleaning programme for cleaning the TwinDos system containers and the hoses inside the washing machine.


Miele 2 Phase System cartridges do not need to be cleaned.

Cleaning the containers and hoses

Clean the container or containers and hoses every time you change the brand of liquid detergent or fabric softener or if the system has not been used for a long period of time (more than three months).

If the system has not been used for a long time, the detergent in the hoses can become viscous.

The hoses could become blocked and would then need to be cleaned by a service technician.

- Switch on the washing machine.
- Touch the **>** sensor to scroll to the second page of the main menu.
- Touch the **Settings**  sensor.

The display will change to show the Settings menu.

- Select the **TwinDos** setting.
- Select the **Maintenance** option.

Rinse

Container 1	Container 2
Containers 1 + 2	

- Touch the sensor for the container or containers you want to clean.
- Follow the instructions in the display.

After cleaning you can fill one or both containers with new liquid detergent and/or fabric softener.

Cleaning the compartment

Detergent residue can cause clogging.


- Use a damp cloth to clean the compartment interior when you change the cartridge or container.

Cleaning and care

Cleaning the water inlet filter

The washing machine has a filter to protect the water inlet valve. This filter should be checked every six months or so, or more often if there are frequent interruptions to the water supply.

- First turn off the tap.
- Unscrew the inlet hose from the tap.



- Remove the rubber seal **1** from the recess.
- Using pointed pliers, take hold of the plastic filter bar **2** and remove.
- Put the filter and seal back in the reverse order and reconnect the hose.


Turn on the tap and check the connection is watertight. If water drips out, tighten the connection.

Never forget to put the filter back in place after cleaning.


Problem solving guide

With the help of the following guide, minor faults in the performance of the appliance, some of which may result from incorrect operation, can be put right without contacting Miele. This will save time and money.

Please note that a call-out charge will be applied to unnecessary service visits where the problem could have been rectified as described in these operating instructions.





 Repair work to electrical appliances should only be carried out by an authorised Miele service technician. Repairs and other work by unqualified persons could be dangerous. Miele cannot be held liable for unauthorised work.


The programme does not start

Problem	Possible cause and remedy
The display remains dark, and the Start/Stop button indicator light does not come on.	There is no power to the machine. <ul style="list-style-type: none">■ Check whether the mains plug is plugged in and switched on.■ Check whether the fuse or circuit breaker has tripped.
	The washing machine has switched off automatically to save energy. <ul style="list-style-type: none">■ Switch it back on with the ① button.
You are asked to enter a code.	Access via a code has been activated. <ul style="list-style-type: none">■ Enter the code and confirm the entry. Deactivate the code if you do not wish this message to appear in the display the next time the machine is switched on.
The following appears in the display:  Door lock	The door is not closed properly. The door lock could not engage. <ul style="list-style-type: none">■ Close the door again.■ Start the programme again. If the fault message appears again, contact Miele.

Problem solving guide

The following fault message appears in the display and the programme has been cancelled

Problem	Possible cause and remedy
 Drainage fault	The water outlet is blocked or restricted. The drain hose has been fixed too high. <ul style="list-style-type: none">■ Clean the filters and the pumps.■ The maximum drain height is 1.8 m.
 Water intake fault	The water inlet is blocked or restricted. <ul style="list-style-type: none">■ Check whether the tap is turned on properly.■ Check whether the inlet hose is kinked.■ Check whether there is sufficient water pressure.
	The filter in the water inlet is blocked. <ul style="list-style-type: none">■ Clean the filter.
 Technical fault F	There is a fault. <ul style="list-style-type: none">■ Start the programme again. If the fault message appears again, contact Miele.
 Waterproof system reacted	The water protection system has reacted. <ul style="list-style-type: none">■ Turn off the tap.■ Call Miele.

To switch off the fault messages: Switch the washing machine off with the  button.

The following fault message appears in the display at the end of a programme

Problem	Possible cause and remedy
i Check detergent	Excessive foam has built up during washing. <ul style="list-style-type: none">■ Check the amount of detergent dispensed.■ With automatic detergent dispensing, check the dosage amount set.■ Observe the instructions on the detergent packaging and the degree of soiling of the laundry.■ If necessary, reduce the dosage amount by increments of 10%.
i Hygiene info: Start a programme with a minimum temperature of 75°C	A programme using a temperature above 60°C has not been run for a long period of time. <ul style="list-style-type: none">■ In order to prevent bacteria and unpleasant odours building up in the machine, run the <i>Clean machine</i> programme using Miele dishwasher and washing machine cleaner or powder detergent.
The display prompts you to refill one or both detergent containers.	The TwinDos container (or containers) is empty. <ul style="list-style-type: none">■ Fill the container or containers with liquid detergent or fabric softener or replace the cartridge(s).■ Check if the laundry is clean. There may not have been enough detergent used. If necessary, wash the items again.

The messages will appear at the end of the programme and when the washing machine is switched on and need to be confirmed with the OK sensor.

Problem solving guide

The following fault message appears in the display at the end of a programme

Problem	Possible cause and remedy
i Intensive recirculation system: Clean the filter and jet nozzle or remove foreign objects from the pump housing	The pumps are dirty. <ul style="list-style-type: none">■ Clean the pumps as described in "Problem solving guide - Opening the door in the event of a blocked drain outlet and/or power failure".■ Start the programme again after cleaning the pumps.
	The jet in the top of the door ring is blocked with fluff. <ul style="list-style-type: none">■ Remove the fluff with your finger. Do not use any sharp or pointed tools to do this.■ Start the programme again after cleaning the jet.
	If the fault message appears again, contact Miele. The washing machine can still be used but with reduced functionality.
i Align the washing machine	The smoothing process which the laundry undergoes at the end of the programme could not be carried out properly. <ul style="list-style-type: none">■ Check whether the washing machine is aligned correctly as described in "Installation and connection - Levelling the machine".■ Check whether the maximum delivery height has been exceeded.
	If the fault message appears again, contact Miele. The washing machine can still be used but with reduced functionality.



The messages will appear at the end of the programme and when the washing machine is switched on and need to be confirmed with the OK sensor.

Problems with TwinDos

Problem	Possible cause and remedy
There are dark specks in the liquid detergent.	Mould has developed in the detergent. ■ Pour the liquid detergent out of the container and then clean the container thoroughly.
No detergent and/or fabric softener was dispensed.	Automatic dispensing has not been activated. ■ Touch the TwinDos sensor before running the next programme.
	Automatic dispensing will be activated.
	No detergent/fabric softener was dispensed although automatic dispensing was activated. ■ Try again. ■ If detergent is still not dispensed, call Miele.

Problem solving guide

General problems with the washing machine

Problem	Possible cause and remedy
The machine shakes during the spin cycle.	The machine feet are not level. ■ Level the machine and adjust the feet correctly.
The laundry has not been spun properly and the laundry is still wet.	The machine detected an imbalance during the final spin and reduced the spin speed automatically. ■ Include both large and small items in the load as this will give better distribution.
The pump makes strange noises.	This is not a fault. These slurping noises occur at the end of the pump sequence as a normal part of operation.
Large amounts of detergent residue remain in the detergent dispenser drawer.	The water pressure is too low. ■ Clean the filter in the water inlet. ■ It may be useful to select the <i>Water plus Extra</i> option.
	Powder detergent used with water softeners can become sticky. ■ Clean the detergent dispenser drawer and in future add washing powder and then add the water softener.
Fabric softener is not completely dispensed or too much water remains in the  compartment.	The siphon tube is not correctly positioned, or is clogged up. ■ Clean the siphon (see "Cleaning and care - Cleaning the detergent dispenser drawer").
The display is in a different language.	A different language has been selected in "Settings / Language  ". ■ Set the language you want. The flag symbol will guide you.
Noises can be heard while steam is being generated.	This is not a fault. These noises occur when steam is being generated and when steam is being injected into the drum.

General problems with the washing machine


Problem	Possible cause and remedy
At the end of the programme there is still liquid in the capsule.	The small pipe in the detergent dispenser drawer onto which the capsule is placed is blocked. ■ Clean the small pipe.
	This is not a fault. For technical reasons, a small amount of water will remain in the capsule.
There is water next to the capsule in the fabric softener compartment.	The CapDosing sensor was not activated or an empty capsule was not removed at the end of the last programme. ■ Make sure that you remember to activate the CapDosingCap sensor the next time you insert a capsule. ■ Remove and then dispose of the empty capsule at the end of each programme.
	The small pipe in the detergent dispenser drawer onto which the capsule is placed is blocked. ■ Clean the small pipe.
Steam comes out of the detergent dispenser drawer while steam is being generated.	This is not a fault. Steam may emerge from the detergent dispenser drawer, depending on the amount of laundry and the ambient temperature.
The display is dark.	The display has switched off automatically to save energy (Standby mode). ■ Press any button. Standby comes to an end.
When the drum is empty a load appears in the display or when the drum is full the load is displayed as <25%.	There was laundry in the drum when the washing machine was switched on. This decalibrated the load sensor from the zero setting. ■ Empty the drum and switch the washing machine off and back on again.

Problem solving guide

An unsatisfactory wash result

Problem	Possible cause and remedy
Liquid detergent does not give the required result.	<p>Liquid detergents usually contain no bleaching agents. They do not remove fruit, coffee and tea stains.</p> <ul style="list-style-type: none">■ Use the Miele 2 Phase System. The targeted addition of UltraPhase 2 during the wash process removes stains effectively.■ Use a general purpose powder detergent containing a bleaching agent.
White residues which look like powder detergent are seen on dark textiles after washing.	<p>The detergent contained compounds (zeolites) to aid water softening which are not soluble in water. These have ended up on the laundry.</p> <ul style="list-style-type: none">■ Try and brush off the residues with a soft brush once the laundry is dry.■ Wash dark textiles using a detergent which does not contain zeolites. Liquid detergents usually do not contain zeolites.■ Use the <i>Dark garments</i> programme.
Grey, greasy particles cling to washed laundry.	<p>Insufficient amounts of detergent were used to break down the particles of grease in heavily soiled laundry.</p> <ul style="list-style-type: none">■ Use more detergent or liquid detergent.■ Before washing the next load, run the <i>Clean machine</i> programme using Miele dishwasher and washing machine cleaner or a powder detergent.


The door will not open

Problem	Possible cause and remedy
The door cannot be pulled open during a programme.	<p>The drum is locked during a programme.</p> <ul style="list-style-type: none"> ■ Touch the <i>Start/Stop</i> sensor. ■ Select the <i>Cancel programme</i> or <i>Add laundry</i> sensor. <p>The door will unlock and you will be able to pull it open.</p>
	<p>There is still water in the drum and the machine is unable to drain.</p> <ul style="list-style-type: none"> ■ Clean the drain filters and the drain pumps as described in "Opening the door in the event of a blocked drain outlet and/or power failure".
	<p>The water level in the drum is too high.</p> <ul style="list-style-type: none"> ■ Cancel the programme. The water will be pumped away.
Extra cooling appears in the display after a programme has been cancelled.	<p>For safety reasons, the door cannot be opened if the suds temperature is higher than 55°C.</p> <ul style="list-style-type: none"> ■ Wait until the temperature in the drum has decreased and the message has gone out in the display.
The door will not open after the <i>Steam care</i> or <i>Freshen up</i> programme has finished.	<p>The <i>Steam care</i> or <i>Freshen up</i> programme has been started several times one after the other. The steam has caused the temperature in the drum to rise above 55°C and the door is locked to prevent the risk of burning.</p> <ul style="list-style-type: none"> ■ Wait a few minutes until the temperature in the drum has dropped.
The following appears in the display:  Door lock fault. Call Miele	<p>The door lock has jammed.</p> <ul style="list-style-type: none"> ■ Call Miele.

Problem solving guide

Opening the door in the event of a blocked drain outlet and/or power cut

- Switch off the washing machine.



- Press the drain pump access panel.

The panel will spring open.

Blocked drain outlet


If the drain outlet is blocked, a large quantity of water (up to 25 litres) can remain in the washing machine.

⚠ Caution: If laundry has been washed at a high temperature, water draining out of the machine will still be hot. Danger of scalding!

Procedure for draining the washing machine

When draining water from the machine, do not unscrew the filters completely or take them right out.


- Place a suitable container, e.g. a Miele universal oven tray, under the access panel.




- Slowly and carefully unscrew the filters to let the water out. Be careful not to release too much water at once. If the flow of water is too strong, some water can seep into the washing machine base and activate the water protection float switch. This will prevent the washing machine from functioning.
- Tighten the filters back up again if you need to interrupt the flow of water.

Once the flow of water ceases:


Problem solving guide



- Remove the filters completely.



- Clean them thoroughly.
- Remove any foreign objects (e.g. buttons, coins, etc.) and fluff from the filter housing. Turn the impellers by hand to check that they rotate freely.




- Replace the filters correctly (on the right and left) and tighten them securely.

⚠ Make sure the filters are securely tightened. Otherwise there is a risk of water leakage during use.

Opening the door

⚠ Always make sure that the drum is stationary before reaching in to remove laundry. Reaching into a moving drum is extremely dangerous.



- Use a screwdriver to unlock the door.
- Pull open the door.


After sales service

Repairs

In the event of any faults which you cannot remedy yourself, please contact Miele.

The contact details for Miele are given at the back of these instructions.

When contacting Miele, please quote the model and serial number of your machine, both of which are visible on the data plate above the porthole glass when the door is open.



Warranty


The manufacturer's warranty for this appliance is 2 years.

See the warranty card supplied with the washing machine for further details.

Optional accessories

Optional spare parts and accessories for this washing machine are available from Miele.


Front view



- ① Inlet hoses with water protection system for cold water and hot water connection
- ② Electrical connection
- ③ Flexible drain hose (with detachable swivel elbow)
- ④ Control panel
- ⑤ Detergent dispenser drawer
- ⑥ Door
- ⑦ Access to filters, pumps and emergency release
- ⑧ Access panel for TwinDos containers
- ⑨ Four height adjustable feet

Installation and connection

Rear view



- ① Drain hose
- ② Transport clips for electrical connection cable, inlet and drain hoses
- ③ Electrical connection cable
- ④ Protruding lid for holding when moving the machine
- ⑤ Inlet hose with water protection system for cold mains water
- ⑥ Inlet hose with Waterproof system for alternative water supplies
- ⑦ Safety caps for transit bars
- ⑧ Miele@home communication module slot (Feature not available in Australia and New Zealand at time of printing)
- ⑨ Transport clips for inlet and drain hoses and for storing transit bars when not in use

Installation surface

A concrete floor is the most suitable installation surface for a washing machine, being far less prone to vibration during the spin cycle than wooden floorboards or a carpeted surface.

Please note:

- The machine must be level and securely positioned.
- To avoid vibrations during spinning, the machine should not be installed on soft floor coverings.


If installing on a wooden joist floor:

- We recommend a plywood base (at least 59 x 52 x 3 cm). The base should span several joists and be bolted to the joists and not only to the floorboards. Check for the presence of pipes and cables first.


Useful tip: If possible, install the machine in a corner, as this is usually the most stable part of the floor.

Transporting the washing machine to its installation site

To manoeuvre the washing machine out of its packing case to its installation site, hold it by the front feet as well as by the edge of the lid where it protrudes to the rear of the machine.

 Ensure that the machine feet and the floor are dry to prevent the machine from slipping during the spin cycle.


Removing the transit bars




- Remove the left and right covers.

1. Pull off the transit bar covers and
2. then use a screwdriver to release the catches at the top and bottom.


Installation and connection




- Using the spanner supplied, turn the left-hand transit bar 90°, then



- Turn the right-hand transit bar 90°, then




- withdraw the transit bar.




- withdraw the transit bar.

Installation and connection

! To avoid the risk of injury, the holes for the transit bars must be covered after the transit bars have been removed.



- Fit the covers onto the two holes.



- Secure the transit bars to the back of the washing machine. Make sure the top catch is located above the holder.

! The washing machine must not be moved without the transit bars in place. Store them as shown or keep them in a safe place for future use. They must be refitted if the machine is to be moved again (e.g. when moving house).

Refitting the transit bars

Refitting is carried out by reversing the procedure.

Installation and connection


Levelling the machine

The washing machine must stand perfectly level on all four feet to ensure safe and proper operation.

Incorrect installation may increase electricity and water consumption and may cause the machine to move about.


Screwing out and adjusting the feet

The four adjustable screw feet are used to level the machine. All four feet are screwed in when the machine is delivered.




- Use a spirit level to check that the washing machine is standing level.
- Hold foot **1** securely with a pipe wrench. Turn counter nut **2** again using the spanner supplied until it sits firmly up against the housing.

⚠ All four counter nuts must be firmly up against the housing. Please also check this for the feet which did not need adjustment. Otherwise there is a danger of the machine moving about.



- Using the spanner supplied, turn counter nut **2** in a clockwise direction. Then turn counter nut **2** together with foot **1** to unscrew.

Building under a continuous worktop / in a kitchen run

 The washing machine lid cannot be removed.


This washing machine (with lid intact) can be pushed under a worktop if there is space to do so.

Washer and dryer stack

A Miele tumble dryer can be stacked with the washing machine. The appropriate "WTV" stacking kit* to match your tumble dryer is required.

All parts marked * are available from Miele.

Please note the following:



- a** = at least 2 cm
- b** = WTV without drawer: 172 cm
WTV with drawer: 181 cm
- c** = 65 cm

Installation and connection


The Miele water protection system

The Miele water protection system protects all parts of the washing machine and surrounds from water damage.

The system consists of three main components:

- the inlet hose
- the electronic unit and drainage and overflow protection
- the drain hose

The Waterproof system (WPS)



- ① Two solenoid valves
- ② Double-skinned inlet hose
- ③ Sump
- ④ Float switch
- ⑤ Electronic unit
- ⑥ Drain pump

The inlet hoses

- The casing on the inlet hoses contains two solenoid valves ①, which cut off the water intake directly at the tap. These valves provide two-fold protection. In the event that one of the valves is faulty, the other valve will cut off the water intake. Blocking the water intake at the tap means that the inlet hoses are only under pressure whilst water is being taken into the machine. For the remainder of the time, pressure on the inlet hoses is negligible.
- Protection against the solenoid valves bursting. The solenoid valves are pressure tested to between 7000 kPa and 10000 kPa against bursting.
- The double-skinned inlet hoses ② have a pressure-resistant inner hose and a protective sleeve. Any leaking water is fed into the sump ③ through this protective sleeve. A float switch ④ closes the solenoid valves, preventing any more water flowing into the machine and water in the suds container is pumped away.

The electronic unit ⑤ and drainage and overflow protection

- Drainage protection
Any leaking water is collected in the sump ③ in the base of the machine. A float switch ④ closes the solenoid valves ①, preventing any more water from flowing into the machine and water in the suds container is pumped away.
- Overflow protection
If the water level exceeds a certain level, the drain pump ⑥ switches in and pumps the excess water away in a controlled manner. Should the water level rise repeatedly in an uncontrolled way, the drain pump ⑥ will switch on continuously, the washing machine will indicate that there is a fault and a tone will sound.

Drain hose

The drain hose is protected by a ventilation system which prevents the washing machine from being emptied completely.

Installation and connection

Connection to the water supply


IMPORTANT Australia and New Zealand

This appliance must be installed according to AS/NZS 3500.1. Backflow prevention is already integrated in the appliance.

⚠ The safety valves contain electrical components. They must not be connected in areas where there is the risk of water or other liquids reaching them, e.g. bathrooms.



The safety valves must not get wet.



The protective sleeve of the hose must not be damaged or kinked.

The washing machine should be connected to a mains water supply in accordance with current local and national safety regulations.

The machine is designed to operate with a flow pressure of between 100 and 1000 kPa. If it is higher than 1000 kPa, it is essential to fit a reducer valve.

Connection to the water supply should incorporate taps with a $\frac{3}{4}$ " threaded union. The taps should be fitted by a qualified plumber.

⚠ The connection points are subject to mains water pressure. Turn on the taps slowly and check for leaks. Correct the position of the washer and the union if appropriate.

Maintenance and care

Only use a **Miele Waterproof system** hose should you need a replacement.


The union nut on the casing at the end of the water inlet hose contains a dirt filter which protects the solenoid valves.

This dirt filter must not be removed.

Installation and connection


This washing machine can be operated with cold mains water and/or hot water.

Markings of water intake hoses



Cold water (tap water) = Silver label

Hot water = Red label

 For technical reasons, the washing machine **must** always be connected to cold mains water.

Cold water (tap water)

The washing machine is programmed to cold water operation at the factory.

The other water intake hose can be fixed at the back of the appliance.

Hot water

- If you wish to use a hot water connection with the washing machine, it must be reprogrammed as described in "Settings - Water intake".
- The temperature of hot water at the mains water tap must not exceed 60°C. The preferred temperature is 55°C. Consult a plumber if the temperature at the tap exceeds 60°C.
- Before connecting to the mains water tap, check that the outflow of cold water does not exceed 5 litres. Each additional litre of cold water reduces the energy efficiency.
- If the hot water tap is turned off for some time, the washing machine will automatically switch to the cold water connection. This safety measure is not intended for the permanent operation of the appliance. The washing machine continues to wash using hot water operation, but washing results are worsened.
- If the programmed temperature when *Hot water MW + rinses* is selected is too low, the washing machine automatically switches to cold water operation. In a programme without Extra options and without a part load, two rinses with an increased water level are carried out to achieve a good rinsing result.

Drainage

The machine drains via a drain pump with a delivery head of 1.8 m. The drain hose must not be kinked as this restricts drainage. The swivel elbow at the end of the hose can be turned in either direction, or can be detached if required, with a sharp twist and pull. The drain hose can be extended to a length of 2.5 m. The necessary parts can be purchased from Miele.

If required, the drain hose can be extended to a length of 5 m. In this case, the delivery head must not be more than 1 m. The necessary parts can be purchased from Miele.

Drain hose connection:

1. Direct into a sink or basin:

Please note the following:


- Hook the hose over the edge and secure.
- Make sure that the water can drain away freely without hindrance. Otherwise there is a risk of water overflowing or of some of the drained water being sucked back into the machine.

2. Connected securely to a plastic drain pipe with a rubber nipple. There is no need to use a siphon.

3. Connected securely to a floor gully.

4. Connected securely to a standpipe.

Please note the following:



① Adapter

② Nut

③ Hose clip

④ End of the hose

■ Fit the adapter ① to the sink drain outlet using the nut ②.

■ Attach the end of the hose ④ to the adapter ①.


■ Use a screwdriver to tighten the hose clip ③ up close to the nut.

Installation and connection

Electrical connection

The washing machine is supplied with a mains cable with moulded plug for connection to a 230V mains supply. The voltage, rated load and plug rating are given on the data plate. Please ensure these match the household mains supply.

WARNING: THIS APPLIANCE MUST BE EARTHED

 The accessibility of the plug must always be ensured in order to separate the washing machine from the mains. Do not connect the appliance to an extension lead or multi-socket adapter as they do not guarantee the required safety of the appliance (e.g. danger of overheating).

All electrical work should be carried out only by a suitably qualified and competent person, in strict accordance with national and local safety regulations. For extra safety, it is advisable to install a residual current device (RCD), with a trip current of 30 mA. Ensure power is not supplied to the appliance until after installation work has been carried out. Connection should be made via a suitable switched socket.


If the connection cable is damaged, it must be replaced with a Miele cable of the same type by a Miele approved service technician only.

Technical data

Height	850 mm
Width	596 mm
Depth	643 mm
Depth with door open	1077 mm
Height for building under	850 mm
Width for building under	600 mm
Weight	Approx. 96 kg
Capacity	9 kg dry laundry
Voltage	See data plate
Rated load	See data plate
Fuse rating	See data plate
Consumption data	See "Consumption data"
Water flow pressure minimum	100 kPa (1 bar)
Water flow pressure maximum	1000 kPa (10 bar)
Inlet hose length	1.60 m
Drain hose length	1.50 m
Connection cable length	2.00 m
Drain pump head max.	1.80 m
Drain pump length max.	5.00 m
LEDs	Class 1
Test certificates awarded	See data plate
Power consumption when switched off	0.1 W
Power consumption when not switched off	5.0 W

Consumption data

Consumption data for the nominated energy labelling programme according to AS/NZS 2040.1 & AS/NZS 2040.2




	Load	Consumption data		
		Energy in kWh	Water in litres	Duration Normal Cold Water
Cottons 	9.0 kg	0.60	64	3 h 58 min

Notes for test institutes:

Detergent **must** be dispensed via the detergent dispenser drawer.

Consumption data can vary from the nominal values given depending on water pressure, water hardness, water inlet temperature, room temperature, type and volume of load, fluctuations in the electricity supply and any Extra options selected.

Consumption data

		Load	Consumption data		
			Energy in kWh	Water in litres	Duration
Cottons 		9.0 kg	0.80	54	2 h 59 min
Cottons	90°C	9.0 kg	2.4	65	2 h 29 min
	60°C	9.0 kg	1.45	65	1 h 59 min
	40°C	9.0 kg	0.99	72	2 h 39 min
Minimum iron	40°C	4.0 kg	0.60	52	1 h 59 min
Delicates	30°C	3.0 kg	0.40	40	1 h 09 min
Woolens 	30°C	2.0 kg	0.25	44	38 min
Shirts ²⁾	40°C	2.0 kg	0.40	35	1 h 11 min
Express 20 ¹⁾	40°C	3.5 kg	0.34	30	20 min
QuickPowerWash	40°C	5.0 kg	0.90	36	59 min
Automatic plus	40°C	6.0 kg	0.77	55	1 h 59 min

1) Short option activated

2) Steam smoothing option deactivated

Consumption data can vary from the nominal values given depending on water pressure, water hardness, water inlet temperature, room temperature, type and volume of load, fluctuations in the electricity supply and any options selected.

For labelling parameters conforming to AS/NZS 2040.1 & AS/NZS 2040.2, please refer to the previous page of this booklet.

The consumption data shown in the EcoFeedback display can vary from the consumption data quoted here. The variations arise from component tolerances and on-site conditions e.g. fluctuations in the pressure of the water supply, mains voltage and fluctuations in the mains voltage.


Settings

You can use the settings to alter the machine's electronics to suit changing requirements.

Settings can be altered at any time.

Calling up the Settings menu

Before you begin, ensure the following:

- The washing machine is switched on.
- The main menu will appear in the display.
- Touch the \triangleright sensor to scroll to the second page of the main menu.
- Touch the Settings  sensor.

The display will change to show the Settings menu.

Selecting and changing settings

- Touch the \triangleleft or \triangleright sensor until the setting you want appears in the list of options.
- Touch the OK sensor to select the setting displayed.
- Change the value displayed and confirm with OK.

or

- Touch an option to select it or change the value displayed.

An option which is selected will be marked with a tick \checkmark .

The option selected will be saved. The display will change to the Settings menu or back to the previous menu level.


Exiting the Settings menu

- Touch the  sensor.

The display will change to show the main menu.

Language

The display can be set to appear in one of several different languages.

The flag  after the word *Language* (Sprache in German) acts as a guide in case a language which is not understood has been set.

The language selected is saved to memory.

TwinDos

For adjusting the standard setting of the detergent dispensing unit or for activating maintenance of the containers.

Options

- Detergent type / amount
For specifying the type of detergent in the containers and the dosage amount.
- Maintenance
For starting the procedure for cleaning the containers.

Please see "TwinDos" and "Cleaning and care - Cleaning the TwinDos system" for more information.

Degree of soiling

You can select the default setting for the degree of soiling or switch the degree of soiling query on or off.

Options

- Default setting
You can choose between the Light, Normal or Heavy degree of soiling settings.
Factory default setting: Normal
- Query
You can switch the degree of soiling query on or off.
Factory default setting: Off

Time

For adjusting the clock display.

Options

- Clock format
The time of day can be displayed as a 24-hour or 12-hour clock.
- Set the time of day
For setting the current time of day.

Settings

Buzzer volume

You can select one of seven different settings for the buzzer volume.

The settings are represented by a bar chart. At the lowest setting, the buzzer is switched off.

Keypad tone

Each touch of a sensor is confirmed with an audible tone.

Factory default setting: the keypad tone is switched on.

Total consumption

In this setting you can check the saved energy and water consumption values and enter the energy cost.

Options

- Display
Shows the sum of the energy and the sum of the water used by the previous programmes.
- Set the cost
You can enter the cost for energy (electricity) and water.
- Reset function
The energy consumption and water consumption totals are reset to zero.

PIN Code

The PIN code prevents the washing machine being used without your knowledge.

Options

- Activate
The code is 125 and can be activated.
When the code has been activated, you have to enter the code after switching the washing machine on. Otherwise the washing machine cannot be operated.
- Deactivate
For using the washing machine without entering the code. This only appears if the code has been activated previously.
- Change
You can enter a code of your own.

Important! Make a note of your new code. If you forget the code, the washing machine will need to be unlocked by a Miele service technician.

Temperature unit

The temperature can be displayed as degrees Celsius (°C) or Fahrenheit (°F).

Factory default setting: Celsius (°C).

Display brightness

There are seven different display brightness settings.

This will change as soon as a different setting is chosen.

Display switch-off status

To save energy, the display goes out and the indicator light for the *Start/Stop* button will start flashing slowly.

Options

- On
The display will go out after 10 minutes.
- On (not in current programme)
(Factory default setting)
The display will remain on while the programme is running but will go out 10 minutes after the end of the programme.
- Off
The display will remain on.

Appliance switch-off status

The washing machine will switch off automatically after the end of the programme/Anti-crease phase or after being switched on if no further selection is made.

Options

- 15 minutes (Factory default setting)
The washing machine will switch itself off after 15 minutes.
- 20 minutes
The washing machine will switch itself off after 20 minutes.
- 30 minutes
The washing machine will switch itself off after 30 minutes.

Display maximum load

After a programme is selected, the maximum load appears in the display for a short time. You can switch this off.

Factory default setting: *Display maximum load* is switched on.

Memory

The washing machine will save the settings (temperature, spin speed and some of the options) which have been selected for a programme after the programme has started.

When this programme is chosen again, these saved settings will appear in the display.

Factory default setting: the Memory function is switched off.


Settings

Water intake

You can choose between cold water and hot water intake.

Options

- Cold water (default)
The washing machine will be operated with cold mains water only.
- Hot water main wash
To save energy, hot water will be used during the main wash if a temperature of 30°C or higher is selected. To be more energy efficient, you can heat up your water with cheaper, energy-saving options, e.g. gas, solar power, oil. The temperature has to be below 60°C.
- Hot MW + Rinses
Hot water is used in the main wash and during rinses. Rinsing with hot water can reduce water consumption by approx. 10%.

 For technical reasons, the washing machine **must** always be connected to cold mains water.

Longer pre-wash Cottons

If you require a longer pre-wash, you can extend the Cottons programme's standard pre-wash time of 25 minutes.

Options

- No increase (Factory default setting)
25-minute pre-wash
- +6 min.
31-minute pre-wash
- +9 min.
34-minute pre-wash
- +12 min
37-minute pre-wash

Soak duration

You can set a duration for the soak process of between 30 minutes and 5 hours.

You can select the duration in 30-minute increments. When the *Soak Extra* option is selected, the laundry will be soaked for the duration selected.

Gentle action

Activating gentle action reduces the drum action and is suitable for washing lightly soiled items more gently.

Gentle action can be activated for the *Cottons* and the *Minimum iron* programmes.

Factory default setting: Gentle action is switched off.

Reduce temp.

The boiling point for water is lower at altitudes of more than 1000 m above sea level. In order to avoid water boiling, the maximum temperature is reduced to 80°C even when a higher temperature is selected.

Factory default setting: the reduce temperature setting is switched off.

Water plus level

There are four different water levels which can be selected with Water plus.

Level:

- Normal (Factory default setting)
- Plus ∆
- Plus ∆∆
- Plus ∆∆∆

Maximum rinse level

The water level in the rinse cycle can be permanently set to the highest value.

This function is useful for allergy sufferers as it achieves an excellent rinse result. Water consumption will increase.

Factory default setting: the maximum rinse level setting is switched off.

Suds cooling

When this is activated, additional water flows into the drum at the end of the main wash to cool the suds down. Hot suds can damage plastic drainage pipes.

Suds cooling takes place when a Cottons programme with a temperature of 70°C or higher is selected.

Suds cooling should be activated:

- to prevent the danger of scalding if the drain hose is hooked over the edge of a sink or basin.
- where the drainage pipes do not comply with DIN 1986.

Factory default setting: Suds cooling is switched off.

Anti-crease

The Anti-crease function helps prevent creasing if laundry is not going to be removed immediately after the end of the programme.

The drum continues to turn at intervals for up to 30 minutes at the end of the programme. The door can be opened at any time.

Factory default setting: Anti-crease is switched off.

Settings

Delay start

For specifying which time prompt should appear with the Delay start function.

Options

- Start at
With the Delay start function you specify at what time the wash programme should begin.
- Finish at (Factory default setting)
With the Delay start function you specify at what time the wash programme should end.

Detergent, fabric care, additives and machine care products are available for this washing machine. All the products have been designed for Miele washing machines.

These and many other useful products can be ordered via the internet at www.miele-shop.com (depending on country) or from Miele (see end of this booklet for contact details).



Detergent

UltraPhase 1 and UltraPhase 2

- Universal liquid detergent and detergent enhancer dispensed as two components
- Suitable for white and coloured laundry
- No need to refill as the components for the TwinDos system are supplied in single use cartridges

UltraWhite

- Powder detergent
- Suitable for white and light coloured laundry as well as heavily soiled cotton items
- Effective stain removal even at low temperatures


UltraColor

- Liquid detergent for coloured items
- Suitable for coloured and dark/black items
- Protects bright colours from fading
- Effective stain removal even at low temperatures
- Also available as a powder detergent.

Sensitive Skin powder

- High quality detergent formulated for people with sensitive skin
- Contains no dyes and preservatives
- Most suitable for white or light coloured textiles

Specialist detergents

Specialist detergents are available as capsules  in convenient single dose amounts or in a handy bottle.

Sportswear

- Liquid detergent for sportswear and fleece garments
- Neutralises unpleasant odours
- Retains the shape of the textiles

Optional accessories


Down Items

- Liquid detergent suitable for pillows, sleeping bags and down filled items
- Retains the elasticity of down and feather filled items
- Retains the breathability of down filled items
- Prevents down filling clumping together

WoolCare

- Liquid detergent for woollens and delicates
- Includes a special wheat protein conditioning formula
- Helps prevent pilling
- Gentle on colours
- Cleans at temperatures as low as 20°C, helps retain the shape of delicate items and protect colours

SilkCare

- Liquid detergent for silks
- Contains a special silk protein conditioning formula
- Gentle on colours
- Only available as capsules 


Fabric care

Fabric Softener

- Fresh, natural fragrance
- Makes laundry soft to handle

Additives

Booster

- For removing stains
- Suitable for white and coloured laundry
- Available as capsules  in convenient single dose amounts

Machine care products

Dishwasher and washing machine cleaner

- For cleaning the washing machine thoroughly and effectively
- Removes grease, bacteria and unpleasant odours

Descaler for washing machines

- Removes heavy limescale deposits
- Mild and gentle with natural citric acid

Miele Australia Pty. Ltd.

ACN 005 635 398

ABN 96 005 635 398

**Miele Experience Centre and
Head Office Melbourne:**1 Gilbert Park Drive
Knoxfield, VIC 3180**Miele Experience Centre South Melbourne:**206-210 Coventry Street
South Melbourne, VIC 3205**Miele Experience Centre and Office Sydney:**3 Skyline Place
Frenchs Forest, NSW 2086**Miele Experience Centre and Office Brisbane:**39 Harvey Street North
Eagle Farm, QLD 4009**Miele Experience Centre Gold Coast:**131 Ferry Road
Southport, QLD 4215**Miele Experience Centre and Office Adelaide:**83-85 Sir Donald Bradman Drive
Hilton, SA 5033**Miele Experience Centre and Office Perth:**205-207 Stirling Highway
Claremont, WA 6010**Miele****Miele New Zealand Limited**

IRD 98 463 631

Head Office:Level 2, 10 College Hill
Freemans Bay, Auckland 1011**Miele Experience Centre
Auckland:**8 College Hill
Freemans Bay, Auckland 1011
Telephone:
0800 464 353 (0800 4 MIELE)
www.miele.co.nz**Miele (Hong Kong) Limited**41/F - 4101, Manhattan Place
23 Wang Tai Road
Kowloon Bay, Hong Kong
Tel: (852) 2610 1331
Fax: (852) 2610 1013
Email: mielehk@miele.com.hk**Miele Global Headquarters
Germany****Miele & Cie. KG**Carl-Miele-Straße 29
33332 Gütersloh
Federal Republic of Germanywww.miele.com.auwww.miele-shop.com

WMV 960 WPS



en-AU, NZ

M.-Nr. 10 210 140 / 03