


## USER MANUAL



## REFRIGERATION

Top Mount, Bottom Mount, French Door & Single Door

## CONGRATULATIONS

### Dear customer,

Congratulations and thank you for choosing our refrigerator. We are sure you will find your new refrigerator a pleasure to use. Before you use the refrigerator we recommend that you read through the relevant sections of this manual, which provides a description of your refrigerator and its functions.

To avoid the risks that are always present when you use an electric appliance, it is important that the refrigerator is installed correctly and that you read the safety instructions carefully to avoid misuse and hazards.

We recommend that you keep this instruction booklet for future reference and pass it on to any future owners.

After unpacking the refrigerator, please check it is not damaged. If in doubt, do not use the refrigerator but contact your local customer care centre.

The symbols you will see in this booklet have these meanings:

## 

This symbol indicates information concerning your personal safety.

## 

This symbol indicates information on how to avoid damaging the refrigerator

## (i) IMPORTANT

This symbol indicates tips and information about use of the refrigerator

## 

This symbol indicates tips and information about economical and ecological use of the refrigerator

### Conditions of use

This refrigerator is designed and intended to be used in normal domestic applications only.

Record model and serial number here:

Model number:....

Serial number:.....

## CONTENTS

| Important safety instructions                           |
|---|
| Refrigerator Features                                   |
| Top mount refrigerator features4                        |
| Bottom mount refrigerator features5                     |
| French door features6                                   |
| Bottom mount with ice & water<br>refrigerator features7 |
| French door with ice & water features8                  |
| Single door refrigerator features9                      |
| Single door freezer features10                          |
| Installing your new refrigerator                        |
| Unpacking your refrigerator11                           |
| Locating your refrigerator11                            |
| Installing your refrigerator11                          |
| Fitting the handles12                                   |
| Ice and Water Installation                              |
| Water filter  |
| Water supply & plumbing12                               |
| Replacing the water filter14                            |
| Using your refrigerator                                 |
| Removing Features15                                     |
| Crisper Bin15   |
| SpillSafe™ glass shelves15                              |
| Freezer Shelves15                                       |
| Drawers with telescopic slides15                        |
| Twist & Serve ice16                                     |
| LED Lighting  |
| Temperature control17                                   |
| About the User Interface                                |
| Top mount & single door models18                        |
| Bottom mount/French Door models20                       |
| All freezer models21                                    |
| Bottom mount/French Door Ice & Water22                  |
| General information                                     |
| Error Codes23   |
| Cleaning the refrigerator24                             |
| Food storage guide25                                    |
| Troubleshooting26                                       |
| Ice & water troubleshooting28                           |
| Warranty  |

## IMPORTANT SAFETY INSTRUCTIONS

Note: You must read these warnings carefully before installing or using the refrigerator. If you need assistance, contact your customer care centre. The manufacturer will not accept liability, should these instructions or any other safety instructions incorporated in this book be ignored.



- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- It is essential the power point is properly earthed to ground. Consult a qualified electrician if you are unsure.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- Unplug the refrigerator before cleaning or moving it to avoid electric shock.
- Never unplug the refrigerator by pulling the electrical cord as this may damage it. Grip the plug firmly and pull straight out.
- If the power cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Don't use a steam cleaner. If live components come into contact with condensing steam, they may short-circuit or cause an electric shock.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance. If pressurised aerosol containers bear the word 'flammable' and/or a small flame symbol, do not store them inside any refrigerator or freezer. If you do so you may cause an explosion.
- Do not damage the refrigerant circuit.
- This appliance contains insulation formed with flammable blowing gases. Avoid safety hazards by carefully disposing of this appliance.
- If you wish to discard this refrigerator, please contact your local authorities and ask for the correct method of disposal.
- When you dispose of your old refrigerators and freezers, remove any doors. Children can suffocate if they get trapped inside.
- The plug must be accessible when the appliance is in position.
- Never try to repair the refrigerator yourself, only use a qualified or authorized service person for repairs.



### R600a refrigerant warning

This appliance contains flammable R600a refrigerant. Avoid safety hazards by carefully installing, handling, servicing and disposing of this appliance.

- Ensure that the tubing of the refrigerant circuit is not damaged during transportation and installation.
- Leaking refrigerant may cause eye injuries or ignite.
- The room for installing appliance must be at least 1m<sup>3</sup> per 8g of refrigerant. The amount of refrigerant in the appliance can be found on the rating plate inside the appliance.
- If you are unsure of the refrigerant check the rating plate inside the refrigerator compartment.
- It is hazardous for anyone other than an Authorised Service Person to service this appliance. In Queensland Australia the Authorisation Service Person MUST hold a Gas Work Authorisation for hydrocarbon refrigerants to carry out servicing or repairs which involve the removal of covers.
- Keep ventilation openings in the appliance enclosure or in the built-in structure, clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.

### TOP MOUNT REFRIGERATOR FEATURES

 $\rightarrow$ 

### Freezer temperature

control Refer to the section "Temperature control" for

details on using this feature.

### Twist & Serve Ice

Refer to the section "Using your Refrigerator" for details on removing, relocating and using this feature.

### LED lighting

Your refrigerator is fitted with LED lighting.

### Deli drawer

Use the deli drawer to store foods like small goods, fresh or cooked meat and cheese or as an additional crisper. The drawer will prevent strong food odours from impacting the rest of the refrigerator. To remove the deli drawer, pull it forward, then lift it up and pull it further forward.

#### Humidity control

Change the humidity by sliding the humidity control. Less humid conditions are recommended for fruit, while more humid conditions are recommended for vegetables.

### FlexFresh crisper

Use the crisper to store vegetables, fruit or small goods. Change the humidity by sliding the humidity control.

### Crisper divider

Use the crisper divider to organise and separate fruit and vegetables.

### SpillSafe<sup>™</sup> glass shelves

1

The glass shelves improve visibility and isolate leakspreventing spills from dripping down to the shelves below

## Quick Chill Colder Mid Less Cold Temp

### **Refrigerator control panel**


From this panel you can control the temperature of the refrigerator compartment as well as setting the quick chill function or resetting the door alarm.

For further information on how to use this feature refer to the section "About the User Interface"

### Freezer control

This is a simple slide control to adjust the temperature of your freezer compartment.

For further information on how to use this feature refer to the section "Using your Refrigerator".



### Adjustable freezer bin divider

Use the dividers to organise stored items by twisting to lock into the holes provided

#### FamilySafe lockable compartment

This compartment can be used to store dairy and is also lockable for storing items like cosmetics and medicines. To operate the lock, turn the knob located on the front of the bin.

### FlexStor door bins

Slide FlexStor bins to meet different storage needs. To remove, lift and tilt. To replace, tilt the top and push down until locked in place.

### Door storage bin

The door bin can be removed by lifting it up over the support lugs. To replace, push down over the support lugs to lock in place

### Bottle storage bin with fingers

Use the bottle bin for tall bottle storage. The bottle bin can be removed by lifting it up over the support lugs. To replace, push down over the support lugs to lock in place.

### BOTTOM MOUNT REFRIGERATOR **FEATURES**

LED lighting

Your refrigerator is fitted with LED lighting.

> Bottle rack (Available in selected

models only) FlexFresh crisper Use the crisper to store vegetables, fruit or small goods. Change the humidity by sliding the humidity control.

### Pull out shelf

A convenient shelf on runners, the pull out shelf allows for easier access to those items which can be difficult to place or access on the shelf, such as cakes and jars.

### Humidity control

Change the humidity by sliding the humidity control. Less humid conditions are recommended for fruit, while more humid conditions are recommended for vegetables.

### Crisper divider

Use the crisper divider to organise and separate fruit and vegetables.

#### Twist & Serve Ice Refer to the section "Using your Refrigerator" for


details on removing and using this feature.

### Freezer storage bin /

Refer to the section "Using your Refrigerator" for details on removing, and using this feature

### SpillSafe<sup>™</sup> glass shelves

The glass shelves improve visibility and isolate leakspreventing spills from dripping down to the shelves below



### Refrigerator/freezer control panel


From this panel you can control the temperature of the refrigerator and freezer compartments as well as setting the quick freeze function or resetting the door alarm.

For further information on how to use this feature refer to the section "About the User Interface".

Features may vary depending on model. Not all models will have features listed.



WTB4604S illustrated



WBE5304S illustrated

### FamilySafe lockable compartment

This compartment can be used to store dairy and is also lockable for storing items like cosmetics and medicines. To operate the lock, turn the knob located on the front of the bin.

### FlexStor bins

Slide FlexStor bins to meet different storage needs. To remove, lift and tilt. To replace, tilt the top and push down until locked in place.


### Door storage bin

The door bin can be removed by lifting it up over the support lugs. To replace, push down over the support lugs to lock in place.

### Bottle storage bin with fingers

Use the bottle bin for tall bottle storage. The bottle bin can be removed by lifting it up over the support lugs. To replace, push down over the support lugs to lock in place.

### FRENCH DOOR REFRIGERATOR FEATURES



**Refrigerator/freezer** control panel

resetting the door alarm.

"About the User Interface".

From this panel you can control the

temperature of the refrigerator and

setting the quick freeze function or

For further information on how to

use this feature refer to the section

freezer compartments as well as

### FamilySafe lockable compartment

This compartment can be used to store dairy and is also lockable for storing items like cosmetics and medicines. To operate the lock, turn the knob located on the front of the bin.

### FlexStor door bins

Slide FlexStor bins to meet different storage needs. To remove, lift and tilt. To replace, tilt the top and push down until locked in place.

### Door storage bin

The door bin can be removed by lifting it up over the support lugs. To replace, push down over the support lugs to lock in place.


### Bottle storage bin with fingers

Use the bottle bin for tall bottle storage. The bottle bin can be removed by lifting it up over the support lugs. To replace, push down over the support lugs to lock in place.

### SpillSafe<sup>™</sup> glass shelves

The glass shelves improve visibility and isolate leakspreventing spills from dripping down to the shelves below.

### **BOTTOM MOUNT ICE & WATER REFRIGERATOR FEATURES**



(Available in selected models only)

### FlexFresh crisper

Use the crisper to store vegetables, fruit or small goods. Change the humidity by sliding the humidity control.

### Humidity control

Change the humidity by sliding the humidity control. Less humid conditions are recommended for fruit, while more humid conditions are recommended for vegetables.

Crisper divider

Use the crisper divider to organise and separate fruit and vegetables.

#### Automatic Ice maker

Refer to the section "Using your Refrigerator" for details on using this feature.

#### Freezer storage bin Refer to the section "Using

your Refrigerator" for details on using this feature.

Fridge/ Freezer

Quick
 Freeze

Select Mode

Replace Filter

Icemaker Off Water Off


Ice & Water On/Off

Replace Filter Hold 3sec

Drinks Chill

\_

Display Lock





### Refrigerator/freezer control panel

From this panel you can control the temperature of the refrigerator and freezer compartments as well as setting the quick freeze function. controlling the Ice Maker or resetting the door alarm.

For further information on how to use this feature refer to the section "About the User Interface".

#### Features may vary depending on model. Not all models will have features listed.

6 FEATURES

Quick Freeze

-23° 🔵 0°

.

-18° 🔴 3°

-14° 🔴 7°

Temp

•

Zone

WBE5360S illustrated

### FamilySafe lockable compartment

This compartment can be used to store dairy and is also lockable for storing items like cosmetics and medicines. To operate the lock, turn the knob located on the front of the bin.

### FlexStor door bins

Slide FlexStor bins to meet different storage needs. To remove, lift and tilt. To replace, tilt the top and push down until locked in place.

#### Door storage bin

The door bin can be removed by lifting it up over the support lugs. To replace, push down over the support lugs to lock in place.

### Bottle storage bin with fingers

Use the bottle bin for tall bottle storage. The bottle bin can be removed by lifting it up over the support lugs. To replace, push down over the support lugs to lock in place.

### SpillSafe<sup>™</sup> glass shelves

The glass shelves improve visibility and isolate leakspreventing spills from dripping down to the shelves below

Features may vary depending on model. Not all models will have features listed.

### FRENCH DOOR ICE & WATER REFRIGERATOR FEATURES

°.0

### SINGLE DOOR REFRIGERATOR FEATURES

Your refrigerator is fitted with LED lighting. Water filter **Bottle Rack** (Available in selected models only) FlexFresh crisper Use the crisper to store vegetables, fruit or small goods. Change the humidity by sliding the humidity control.

LED lighting

### Humidity control

Change the humidity by sliding the humidity control. Less humid conditions are recommended for fruit, while more humid conditions are recommended for vegetables.

#### **Crisper divider**


Use the crisper divider to organise and separate fruit and vegetables.

### Automatic ice maker

Refer to the section "Using your Refrigerator" for details on using this feature

#### Freezer storage bin

Refer to the section "Using your Refrigerator" for details on using this feature.



WHE5260S illustrated

### Door storage bin

FamilySafe lockable

The door bin can be removed by lifting it up over the support lugs. To replace, push down over the support lugs to lock in place.

### Bottle storage bin with fingers

Use the bottle bin for tall bottle storage. The bottle bin can be removed by lifting it up over the support lugs. To replace, push down over the support lugs to lock in place

### SpillSafe<sup>™</sup> glass shelves

The glass shelves improve visibility and isolate leakspreventing spills from dripping down to the shelves below.

LED Lighting

Your refrigerator is fitted with LED lighting.

### Deli drawer

Use the deli drawer to store foods like small goods, fresh or cooked meat and cheese, or as an additional crisper. The drawer will prevent strong food odours from penetrating the rest of the refrigerator. To remove the deli drawer, pull it forward, then lift it up and pull it further forward.

FlexFresh crisper

Use the crisper to store vegetables, fruit or small goods.

### Humidity control

Change the humidity by sliding the humidity control. Less humid conditions are recommended for fruit, while more humid conditions are recommended for vegetables.

### Crisper divider

Use the crisper divider to organise and separate fruit and vegetables.

### SpillSafe<sup>™</sup> glass shelves

The glass shelves improve visibility and isolate leakspreventing spills from dripping down to the shelves below


Quick Chill

Colder

Mid

Less Cold

Temp



Fridge/ Freezer Shopping Quick Holiday Display Lock Select Mode Drinks Chill Replace Filter cemaker Off Water Of Ice & Water On/Off 

### **Refrigerator/freezer** control panel

From this panel you can control the temperature of the refrigerator and freezer compartments as well as setting the quick freeze function, controlling the Ice Maker or resetting the door alarm.

For further information on how to use this feature refer to the section "About the User Interface".

Features may vary depending on model. Not all models will have features listed.

**Refrigerator control panel** 

door alarm.

From this panel you can control

the temperature of the refrigerator

compartment as well as setting the

quick chill function or resetting the

For further information on how to

use this feature refer to the section

"About the User Interface".

### FamilySafe lockable compartment

This compartment can be used to store dairy and is also lockable for storing items like cosmetics and medicines. To operate the lock, turn the knob located on the front of the bin.

### FlexStor bins

Slide FlexStor bins to meet different storage needs. To remove, lift and tilt. To replace, tilt the top and push down until locked in place.


### Door storage bin


The door bin can be removed by lifting it up over the support lugs. To replace, push down over the support lugs to lock in place.

### Bottle storage bin with fingers

Use the bottle bin for tall bottle storage. The bottle bin can be removed by lifting it up over the support lugs. To replace, push down over the support lugs to lock in place.

### SINGLE DOOR FREEZER FEATURES





### Freezer control

From this panel you can control the temperature of the freezer as well as setting the quick freeze and drinks chill functions or reset the door alarm.

For further information on how to use this feature refer to the section "Controlling your Refrigerator".

Features may vary depending on model. Not all models will have features listed.

# INSTALLING YOUR NEW APPLIANCE

Unpacking



Most of the packing materials are recyclable. Please dispose of those materials through your local recycling depot or by placing them in appropriate collection containers.

Important – check for any damages or marks. If you find the refrigerator is damaged or marked, you must report it within 7 days should you wish to claim for damage/ marks under the manufacturers warranty. This does not affect your statutory rights.

Clean your refrigerator thoroughly following the instructions in the "Cleaning" section and wipe off any dust that has accumulated during shipping.

#### Locating the refrigerator



Automatic aerosol systems (such as insect control) should not be located adjacent to the product as the spray may cause long term damage to the external plastics of the appliance.


Do not put the refrigerator in a location that is too cold or is unprotected, for example in a garage or on a veranda. The ambient temperature should be above 10°C.

Put the refrigerator in a dry place avoiding areas of high moisture or humidity.

Ensure the refrigerator is located on an even surface.

### Adequate ventilation around your refrigerator

The diagram below shows the recommended airspace to allow for ventilation of your refrigerator.



If you have a cupboard above the refrigerator with a rear gap of less than 100 mm (Y), recommended clearance at the top of the refrigerator increases from 50mm to 90mm (X) minimum.

When positioned in a corner area, spacing of at least 350mm (300mm for multi-door models) on the hinge side will allow the doors to open enough to enable the removal of bins and shelves.

NOTE: Doors are designed to sit proud of cabinetry (not flush). The clearances shown above are the recommended minimum clearances.


The clearance at the rear must not exceed 75mm.

### Installing your refrigerator


1. Roll the refrigerator into place.

The rollers are designed for forward or backward movement only. They are not castors. Moving the refrigerator sideways may damage your floor and the rollers. Before moving your refrigerator ensure height adjusting nut and the stability foot are fully wound up off the floor.

2. Wind the large height adjusting nut under door hinge down until the refrigerator is tilted back by 10mm (see diagram).




3. Wind the large height adjusting nut on the handle side down until the refrigerator is level and stable. If you have difficulty winding the nut or height adjusting foot down, have someone tilt the refrigerator back so you have better access.



stability foot wound up


4. Check the alignment of the refrigerator to the surrounding cupboards to see if it is level. You can adjust the level as detailed in step 2 and 3.



# INSTALLING YOUR NEW APPLIANCE

- 5. If you find your refrigerator rocks from corner to corner, it means your floor is uneven. Find a piece of plastic or hardboard etc. and pack it firmly under the roller.
- 6. You may now need to fine-tune the installation by repeating steps 3, 4 and 5.
- 7. When you have the appliance in its final position, it needs to be stabilised. Wind the stability foot under the door hinge down to the floor until it just makes contact with the floor. Lift the front of the appliance to take the weight off the stability foot, then turn it half a turn further to ensure firm contact with the floor. Wind the large height adjusting nut back up to ensure all the weight is now on the front stability foot.
- 8. Repeat step 7 for the stability foot on the handle side. Whenever you need to move the appliance, be sure to wind the feet back up so that the appliance can roll freely and be sure to reset it when reinstalling.

front view



- 9. Plug your refrigerator straight into its own power point and never use a double adapter. If you need to roll the refrigerator to get to the plug, remember to raise the stability foot first.
- 10. Before you put any food in your refrigerator, it's recommended you leave it on for 2 or 3 hours to check it is running properly.

#### Fitting the handles

For models with 'Pole' handles, the handles are supplied prepackaged inside your refrigerator and will require fitting. Refer to the instructions provided in the pack.

Congratulations! You have successfully installed your new refrigerator.

### ICE AND WATER INSTALLATION



Connect to potable water supply only. If using tank or bore water it is recommended to also use an external filter (not supplied).

The new hose-sets supplied with the appliances must be used and old hose-sets should not be reused.

Never connect the appliance to a hot water supply.

#### Water Filter

It should not be used on water that is micro biologically unsafe or with water of unknown quality. The service life of the filter may be reduced in water supplies that contain an excess of particles or other impurities. Reduced flow rate is an indication that a new filter is required. Failure to replace the filter when required can affect the function of the ice maker. Service calls caused by a failure to replace the filter are not covered by warranty. Replacement water filters are available from Electrolux Home Products Spare Parts Centres and can be posted to you for your convenience (refer to spare parts contact numbers on the warranty page).

### Contents of installation kit



4 metres of water tubing



1 x 1/2" tap fitting

### Water supply and plumbing

A drinkable water supply to suit a 1/2" tap fitting is required adjacent to the refrigerator. It is recommended that a licensed plumber install a new water supply outlet nearer to the appliance should the tubing supplied not be long enough. It is not recommended that the tubing be extended as this could adversely affect the flow of water to the ice maker or water dispenser. The water dispenser and automatic ice maker require a drinkable water supply with a pressure range of between 206kPa and 689kPa (30PSI and 100PSI). If the water supply is above 100psi a pressure limiting valve should be installed.

It is recommended that a noise reduction valve also be fitted in the water supply line. This will reduce water hammer and its effects from quick action household taps and fast acting valves on appliances.

The refrigerator water valve is pre-fitted with a push-fit connector for inserting the water tube. When the tap connection is other than 1/2", adapters can be purchased from plumbing supply stores or good hardware stores.


Please read before beginning installation.

The water connection to your ice and water product can be self installed. However, it is recommended that you seek advice from a licensed plumber before commencing the installation.

## () IMPORTANT

Check for water leaks at all water connection points in the first 2 to 3 hours after installation, and correct it in case of any water leak. Recheck after 24 hours; if leak still occurs, it is recommended to contact a licensed plumber for advice.


Water is to be connected as per diagram below.



(WHE5160SAD shown)

### Step 1.

Ensure that the refrigerator is disconnected from power supply.



#### Step 2.

Connect tap fitting to water supply tap. Tap must be close to the refrigerator.

Step 3.

Push the tube into tap fitting past insertion mark.

Step 4.

Connect other end of tube to inlet on rear of refrigerator.

### Step 5.

Turn on water and check all joints and tubes for leaks.

### Step 6.

Reconnect the power.

### Step 7.


Move the refrigerator back into place being careful not to kink or split the tubing.


### Step 8.

Switch ON Water Dispenser.

Using a large container, run the water dispenser to clear air from lines. This may take a few minutes. Purge and dispense a minimum of 2 litres of water. Initial water may be black in colour. This is residual carbon dust from the filter and is non-toxic. If the water is slow to shut off or the dispenser is dripping, air may still be in the lines. Either purge more water through the system to remove this air or allow some time for the air to be removed over subsequent dispensing.







## (i) IMPORTANT

As the water cut off is not instant, leave glass under dispenser briefly until water has stopped flowing to avoid spills.

Clean and empty the dispenser drip tray regularly to avoid overflow.

If you have not used the dispenser for some time, discard the first seven or eight cups of water (contaminants could have settled in the water pipes).

### Step 9

Switch ON Ice Maker.

Once the refrigerator has been running for at least 24 hours remove the ice bin and dispose of the first few batches of ice to ensure that impurities have been flushed from the system.

### Party Ice

When the Ice Bin is removed from the cabinet the Auto Ice Maker will continue to dispense ice into the top freezer drawer.

## ICE AND WATER INSTALLATION

## (i) IMPORTANT

- Always fit the filter as per manufacturer's instructions.
- If you need to replace water tube, only use approved water quality piping that meets the pressure requirements.
- Make sure your refrigerator is level to avoid uneven ice cubes.
- Replace filter at suggested intervals to avoid water/ice reduction and irregularities in taste.
- Remove and clean ice bin once a month, discarding unused ice cubes. This will ensure fresh, clean ice and smooth operation of your ice maker.
- Clean and empty the dispenser drip tray regularly to avoid overflow.

## 

If you have not used the dispenser for some time, discard the first seven or eight cups of water and any ice that the ice maker produces in the first 24 hours (contaminants could have settled in the water pipes).

### Water filter

The water filter is located at the top left side of the fresh food compartment.

### Replacing the water filter

You should change the water filter every six months to ensure the highest possible water quality.

If your refrigerator has not been used for a period of time (during a house move for example), change the filter before reinstalling the refrigerator.

It is not necessary to turn the water supply off to change the filter. Be ready to wipe up any small amounts of water released during the filter replacement.

- 1. Ensure that the ice maker is turned off (Diagram 1).
- 2. Remove the filter by turning anti-clockwise 180°
- 3. Slide the old water filter cartridge straight out of the housing and discard it. (Diagram 2).
- 4. Unwrap the new filter cartridge and using the alignment guide, slide it gently into filter housing until it stops against the filter connection at the back of the housing. (Diagram 3).
- 5. Engage the filter by firmly rotating clockwise until the filter snaps into position (once engaged the filter cannot be rotated further). (Diagram 4).
- 6. Press a drinking glass against the water dispenser while checking for any leaks at the filter housing. Any spurts and sputters that occur as the system purges air out of the dispenser system are normal.
- 7. After filling one glass of water, continue flushing the system for about four minutes.
- 8. Turn on the ice maker. (Diagram 5).
- 9. When the filter has been replaced press and hold the 'Ice and Water' button for three seconds to reset the filter replace timer.



Diagram 2




Diagram 3




Diagram 4



Diagram 5

## USING YOUR REFRIGERATOR

Refrigerators work by transferring heat from the food inside to the outside air. This operation makes the back and sides of the refrigerator feel warm or even hot particularly at start-up and on warm days - this is normal.

Avoid placing food against the air vents in the refrigerator as it affects efficient circulation. If the door is opened frequently, a light frosting will occasionally occur on the freezer's interior. This is normal and will clear after a few days. If the freezer door is accidentally kept open, a heavy frost will coat the inside walls and should be removed. 2. 3.

Your new refrigerator uses a high-speed compressor, along with other energy-efficient components, which may make unusual sounds and be more noticeable at night and quieter times. These sounds simply indicate your refrigerator is working how it should. They include:

- Compressor running noises;
- Air movement noise from the small fan motor;
- A gurgling sound, similar to water boiling;
- A popping noise, heard during automatic defrosting; and
- A clicking noise, prior to compressor start-up.

Further details can be found in the Troubleshooting Guide.



## For top mount refrigerators (where the freezer is on top of the fresh food compartment).

• Don't place food forward of the ribs on the freezer floor, as it will keep the door open.



For bottom mount refrigerators (where freezer is below the fresh food compartment):

• Ensure all freezer drawers and shelves are pushed back completely to prevent them from keeping the door open.




## **REMOVING FEATURES**

### **Crisper Bin**


Removal (standard Crisper Bins):

- 1. Empty food from the crisper. On some models it will be necessary to remove the bottle storage bins.
- 2. Remove the crisper bin(s) by pulling forward, then up and forward again.
- For top mount and single door, remove the crisper shelf by lifting the catches on the left and right underside of the shelf and pulling the shelf forward.




### SpillSafe<sup>™</sup> glass shelves

To remove the shelves, gently pull them forward until the shelf comes clear of the shelf guides. To return the shelf, make sure there is nothing behind that may obstruct movement. Gently push the shelf, into the cabinet and back into position.



### Freezer shelf

Remove the freezer shelf by lifting the catches on the right and left underside of the shelf to release the shelf then pull the shelf toward you.



## **REMOVING FEATURES**

### Drawers fitted with telescopic slides

To remove the drawer for cleaning.

- 1. Empty food from the drawer.
- 2. Remove the drawer by pulling it forward and lifting the front to unhook it from the slides. Once you have removed the drawer, ensure the slides are pushed back so they are fully closed.

## 

Never close the door while the telescopic slides are extended. This may damage the slide and/or refrigerator or cause the slide to become disengaged from the refrigerator.


To replace the drawer:

- 1. Ensure the telescopic slides are pushed in all the way.
- 2. Slide the drawer into place over the slides and push the bin in until it stops.
- 3. Drop drawer into position.

### Freezer bottom bin

To remove the bin, pull the drawer out until it is open all the way then lift bin out from the front of the bin. When refitting insert the rear of the bin first then lower into position.


When replacing the bins after cleaning, we recommend fitting the lower bin first.




Never close the door while the telescopic slides are extended. It may damage the slide and/or the refrigerator or cause the slide to become disengaged from the refrigerator.

### **Twist and Serve Ice**

- Mounting the twist & serve dispenser to the other side of the freezer.
- NOTE: this is only possible on Top mount models.
- 1. Remove the ice bin and ice cube tray. If the ice tray assembly is frozen to the carriage, simply squeeze the tray and shelf together to break the ice.
- 2. Before you remove the ice carriage, remember to disengage it from the glass shelf as it may result in damage to the assembly.



- 3. Remove the centre runner by disengaging it at the front of the shelf, and removing it from the rear.
- 4. Refit the runner into the rear of the shelf on the right hand side and then engage the front.



Insert into the slot at the rear of the shelf

5. Fit the carriage by sliding it into the runners until the front if the carriage engages with the shelf.

the shelf


6. Refit the ice tray and ice bin.



Fill the ice cube tray with potable water only.


### **Pullout shelf**

- To remove shelf:
- 1. Extend the tray fully outward.
- 2. Lift the tray up gently and then pull forward to remove the tray from the frame.



To remove the frame:

1. Push the rear tabs gently inwards on both sides of the frame, pull the frame towards you to remove.





Your appliance is fitted with long life LED lighting. In the unlikely event the LED lights should fail, then the LED lights should be serviced by the manufacturer.

Refer to the warranty page for contact details.

## **TEMPERATURE CONTROL**

The factory default settings;

- Top mount
  - Refrigerator Mid
- Freezer Mid

Bottom mount & French door

| Refrigerator     | 3°C   |
|------------------|-------|
| Freezer          | -18°C |
| All Refrigerator | Mid   |

All Freezer -18°C

If you want to change the temperature, follow the instructions in the section about the user interface for your model. Ensure that you make only small adjustments and wait 24 hours to see if it's correct to your liking.

# (i) IMPORTANT

NOTE: When you set a temperature, you set an average temperature for the whole refrigerator cabinet.

Checking the softness of ice cream is a good indication that your freezer is the right temperature, while checking the temperature of water kept in the refrigerator is a good way of checking the temperature of the food compartment.

Temperatures inside each compartment may vary, depending on how much food you store and where you place it.

High or low room temperature may also affect the actual temperature inside the refrigerator.


### Top mount freezer temperature adjustment

- 1. Select the freezer control.
- 2. Slide the control to the right (as per image below).
- 3. Slide the control to the left (as per image below).

| FREEZER TEMPERATURE SETTING RECOMMENDATION |                            |                  |  |  |
|--|----------------------------|------------------|--|--|
|  | Freezer Temp               |                  |  |  |
| Summer (>35°c)                             |                            | Set to less cold |  |  |
|  | Colder Less<br>Colder Cold |                  |  |  |
| Normal                                     | Freezer Temp               |                  |  |  |
|  | Freezer Temp               |                  |  |  |
| Winter (<15°c)                             |                            | Set to colder    |  |  |
|  | Colder Cold                |                  |  |  |

## ABOUT THE USER INTERFACE

### Controls - Top mount and single door refrigerator models




| DESCRIPTION                          | OPERATION / PRIMARY FUNCTION  |  |
|--------------------------------------|---|--|
| Refrigerator temperature scale icons | Indicates the temperature setting of the refrigerator compartment.  |  |
| Quick Chill On/ Off icon             | Indicates the status of the Quick Chill function  |  |
| Temperature adjust/ quick chill on/  | Temperature Control   |  |
| off button                           | Touch the 'Temp' button to awaken control.  |  |
|                                      | • Touch the 'Temp' button to decrease the refrigerator temperature. There are 8 temperature settings indicated by the illumination sequence on the display. Once the coldest temperature is reached the display will return to the warmest setting with the next press. |  |
|                                      | Quick Chill   |  |
|                                      | <ul> <li>Use the quick chill function when you add a large amount of food to the<br/>refrigerator compartment.</li> </ul>   |  |
|                                      | • Press and hold the 'Temp' button for 3 seconds. The Quick Chill icon will flash indicating that the Quick Chill is active.  |  |
|                                      | • Your refrigerator will run at 2°C for 90 minutes, then automatically return to normal mode.   |  |
| 0                                    | • The Quick Chill function can be cancelled anytime by pressing the<br>'Temp' button again.   |  |

## (i) IMPORTANT

The factory default settings for the refrigerator is "Mid". If you want to change the temperature, remember to make only small adjustments and wait 24 hours to see if it's correct.

### **Controls - Bottom mount and French door**



| DESCRIPTION                          | OPERATION / PRIMARY FUN  |
|--------------------------------------|--|
| Quick Freeze on/ off icon            | Indicates the status of the  |
| Quick Freeze button                  | Use the Quick Freeze functio freezer compartment.  |
|                                      | <ul> <li>Press the 'Quick Freeze' I<br/>the quick freeze is active<br/>90 minutes.</li> </ul>                                      |
|                                      | • After 90 minutes the free  |
|                                      | The Quick Freeze function button again.  |
| Refrigerator / Freezer               | Indicates the temperature  |
| temperature scale icons              | Indicates the temperature  |
| Temperature adjust button            | • Touch any button to awa  |
|                                      | <ul> <li>Touch the 'Temp' button<br/>There are 8 temperature<br/>display. Once the coldest<br/>warmest setting with the</li> </ul> |
| Refrigerator/Freezer indication icon | Indicates the selected zo  |
| Compartment select button            | • Press to select the desire   |
|                                      | • The refrigerator / freezer   |
| $\bigcirc$                           |  |

## (i) IMPORTANT

The factory default settings for the refrigerator is "3°C" and "-18°C" for the freezer. If you want to change the temperature, remember to make only small adjustments and wait 24 hours to see if it's correct.

### NCTION

the Quick Freeze function.

ion when you add a large amount of food to the

e' button. The Quick Freeze icon will flash indicating that we and the compressor will run continuously for

eezer will automatically return to normal mode.

tion can be cancelled anytime by pressing the

ure setting of the refrigerator compartment.

ure setting of the freezer compartment.

vaken control.

n to decrease the selected compartment temperature. re settings indicated by the illumination sequence on the est temperature is reached the display will return to the he next press.


zone.

red compartment.

er indication icon will show which zone is selected.

### **ABOUT THE USER INTERFACE**

### Controls - Bottom mount ice & water and French door ice & water models



| BUTTON /<br>ICON | DESCRIPTION  | PRIMARY FUNCTION   |
|------------------|--|--|
| 1                | Compartment Selector button                          | Selects controllable compartment.  |
| 2                | Lock Icon  | Indicates if the user interface is locked.                                 |
| 3                | Compartment Icon                                     | Indicates controllable compartment.  |
| 4                | ECO Icon   | Indicates if the appliance is operating in its most energy efficient mode. |
| 5                | Digital display                                      | Indicates temperature of selected compartment.                             |
| 6                | Increase button                                      | Increases temperature of selected compartment.                             |
| 7                | Decrease button                                      | Decreases temperature of selected compartment.                             |
| 8                | Mode indicators (Shopping, Quick<br>Freeze, Holiday) | Indicates appliance operation mode.  |
| 9                | Display Lock button                                  | Selects lock state of user interface.                                      |
| 10               | Mode select button                                   | Selects operation mode of appliance.                                       |
| 11               | Drinks Chill button                                  | Selects drinks chill timer.  |
| 12               | Filter status indicators                             | Indicates filter replacement timing.                                       |
| 13               | Icemaker and Water on off indicators                 | Shows operational status .   |
| 14               | Ice & Water on/off button                            | Selects operational status.  |
| 15               | Door sensor  | Senses door state (open or closed).  |

## FUNCTIONS OF THE USER INTERFACE

#### Bottom mount ice and water models

| FUNCTION   | ICON                           | OPE    |
|--|--------------------------------|--------|
| Setting the freezer temperature  |                                | •      |
| Setting the refrigerator temperature   |                                | •      |
| Shopping mode<br>Increases the chill rate of the<br>refrigerator for 90mins before returning<br>to pre-set mode.                         | •<br>Shopping                  | •      |
| Quick freeze mode<br>Decreases the freezer temperature to<br>-23°C for 12 hours before returning to<br>pre-set mode.                     | Quick<br>Freeze                | •      |
| Holiday mode<br>The refrigerator minimises defrosting to<br>save energy when doors remain closed<br>for an extended period.              | •<br>Holiday                   | •      |
| Display Lock<br>Deactivates the user interface controls.   | Ť                              | •      |
| Drinks Chill<br>Sets a timer for between 1 and 30<br>minutes as a reminder for when drinks<br>are placed in the freezer for quick chill. |                                |        |
| Ice & Water on/off<br>Enables/disables ice maker and water<br>dispensing features.   | Icemaker Off Water Off         | •      |
| Ice Cube Size<br>Ice cube size can be adjusted to suit<br>supply water pressure.   |                                | •      |
| Sabbath Mode<br>Disables all lights and other electrical<br>activity from occurring when the<br>refrigerator door is opened.             |                                | •<br>• |
| INDICATOR  | ICON                           | OPE    |
| Eco Mode<br>Enabled when appliance set to energy<br>efficient operating temperatures.  | Ø                              | •      |
| Order Filter<br>Reminder when the water filter<br>periodically requires replacement.   | Order Filter<br>Replace Filter | •      |
| Replace Filter<br>Reminder when the water filter requires<br>replacement.  | Order Filter<br>Replace Filter |        |
|  |                                |        |

### i IMPORTANT

The factory default settings for the refrigerator is "3°" and "-18°C" for the freezer. If you want to change the temperature, remember to make only small adjustments and wait 24 hours to see if it's correct.

### RATION

- Press button 1 until freezer is displayed on icon 3. Press buttons 6 or 7 to adjust temperature up or down.
- Press button 1 until the refrigerator is displayed on icon 3.
- Press buttons 6 or 7 to adjust temperature up or down.
- Press button 10 until the shopping icon is illuminated.
- Shopping mode can be deselected using button 10.

Press button 10 until the freeze icon is illuminated. Quick freeze mode can be deselected using button 10.

Press button 10 until the holiday icon is illuminated. Holiday mode can be deselected using button 10 or opening the door.

To turn on/off press and hold button 9 for 3 seconds, the lock icon is illuminated when activated.


- To turn on press button 11 and initial time of 20 mins will appear on digital display. To adjust time use buttons 6 and 7. Alarm will sound when time is finished.
- Press button 11 to turn off during or after countdown. The time taken to chill depends on the size of your bottle. Do not leave the bottle inside the freezer longer than the time needed for chilling.
- To enable/disable press button 14 to cycle through on/off modes.
- Indicator 13 will illuminate when either the ice maker or water dispenser are deactivated.
- Press and hold buttons 10 and 14 for 3 seconds.
- Press button 6 to cycle through cube sizes, small (S), medium (M), large (L) & extra large (EL). Medium symbol shown.
- To confirm the setting press button 10.
- To enable and disable Sabbath mode, press and hold buttons 7 and 9 for 3 seconds.
- When enabled/disabled an alarm will beep 4 times and "Sb" will appear on digital display when active.

### RATION

- ECO icon automatically appears when refrigerator is set between +3°C and +7°C and freezer is set between -14°C and -18°C
- Order filter icon will appear as a reminder to order a replacement water filter.
- When the filter has been replaced press and hold button 14 for 3 seconds to reset the filter replacement timer.
- Replace filter icon and alarm will activate as a reminder to replace the water filter.
- Mute alarm for 1 week by pressing any button on the user interface.
- When the filter has been replaced press and hold button 14 for 3 seconds to reset the filter replacement timer.

## ABOUT THE USER INTERFACE

### Controls - Single door freezer models



| DESCRIPTION                      | OPERATION / PRIMARY FUNCTION  |
|----------------------------------|---|
| Quick Freeze on/off icon         | Indicates the status of the Quick Freeze function.  |
| Drinks Chill on/ off icon        | Indicates the status of the Drinks Chill function.  |
| Quick Freeze/Drinks Chill button | Use the Quick Freeze function when you add a large amount of food to the freezer compartment;   |
|                                  | <ul> <li>Press the 'Quick Freeze/Drinks Chill' button. The Quick Freeze icon will<br/>flash indicating that the quick freeze is active. and the compressor will run<br/>continuously for 90 minutes.</li> </ul>   |
|                                  | After 90 minutes the freezer will automatically return to normal mode.  |
|                                  | • The Quick Freeze function can be cancelled anytime by pressing the button again.  |
|                                  | Use the "Drinks Chill" function when you need to chill drinks in the freezer compartment;   |
|                                  | <ul> <li>Press and hold the 'Quick Freeze'/Drinks Chill button for 3 seconds.<br/>The Drinks Chill icon will activate indicating that the Drinks Chill is active.</li> </ul>                                      |
|                                  | • An alarm will sound and LED will flash after 15 mins.   |
|                                  | <ul> <li>Drinks Chill can be cancelled at anytime by pressing Drinks Chill again for 3<br/>seconds. The time taken to chill depends on the size of your bottle.</li> </ul>  |
|                                  | • Do not leave the bottle inside the freezer longer than the time needed for chilling.  |
| Freezer temperature scale icons  | Indicates the temperature setting of the freezer compartment.   |
| Temperature adjust button        | Press any button to awaken control.   |
| •                                | <ul> <li>Press the 'Temp' button to decrease the selected compartment temperature.<br/>Once the coldest temperature is reached the display will return to the warmest<br/>setting with the next press.</li> </ul> |

### **(i)** IMPORTANT

The factory default settings for the freezer is "-18°C". If you want to change the temperature, remember to make only small adjustments and wait 24 hours to see if it's correct.


### **ERROR CODES & ALARMS**

| Alarms    |   |  |  |
|-----------|---|--|--|
| ALARM ICO | N                                       | WHAT IT MEANS  | OPERATION  |
|           | Temp<br>Zone<br>Non I&W                 | Freezer Temperature Alarm<br>Activates if the freezer temperature is<br>10°c over set temperature for a period<br>of 50 minutes (except during a defrost).<br>An alarm will sound the temperature<br>icons will flash.                       | <ul> <li>To deactivate the alarm for 50 minutes press any button.</li> <li>To deactivate alarm for 12 hrs on the ice &amp; water model press and hold Select Mode for 10 seconds for non ice and water models press and hold any button for 10 seconds.</li> </ul> |
|           | ● 3°<br>● 7°<br>Temp<br>Zone<br>Non I&W | Door Alarm<br>Activates if the refrigerator or freezer<br>doors are left open for longer than<br>2 minutes.<br>An alarm will sound and the affected<br>compartment icon will flash and the<br>temperature and icons will fade on<br>and off. | <ul> <li>Alarm will sound and icon will flash indicating which door is open. (Ice &amp; water models)</li> <li>To silence the alarm for 8 minutes while the door is open press any button (the icons will continue to flash until door is closed).</li> </ul>      |

### Error codes

| Error codes                              |   |  |
|--|---|--|
| ERROR CODE                               | WHAT IT MEANS   | WHAT TO DO   |
| Communication Error                      | If you see this icon displayed (Ice & Water<br>model) or the top temperature icon is<br>flashing it means that the control has lost<br>contact with the main control board.<br>The appliance will operate at its last<br>known setting, all auxillary functions will<br>not work. | Turn the unit off at the power<br>point for 5 minutes and then turn<br>it back on.<br>Under most circumstances this will<br>reset the display enabling normal<br>function to continue.<br>If the error re-occurs then call<br>for service. |
| Sensor - Open Circuit /<br>Short Circuit | If you see this icon displayed (Ice & Water<br>model) or any combination of the second<br>and fourth temperature icons are flashing<br>it means that an error has been detected<br>on a sensor.<br>The refrigerator will run in a default cycle<br>to prevent food spoilage.      | Call for service.  |
| Ice cube tray water fill not detected    | This error indicates that when an ice<br>harvest occurred and a tray water fill was<br>attempted, that the tray sensor did not<br>get above 0°C.  | Check the following:<br>Water turned on at tap, water filter<br>not blocked, no kinks in water tube.<br>If after checking these items and<br>they do not appear to be the cause<br>of the error, call for service.                         |







## **CLEANING YOUR REFRIGERATOR**

# 

BEFORE CLEANING: Turn the refrigerator off at the power point and unplug the cord to prevent any chance of electrocuting yourself.

### Doors and exterior (white and silver):

You should only clean the doors with lukewarm soapy water and a soft cloth.

### **Stainless Steel:**

Your stainless steel refrigerator is manufactured from mark-resistant stainless steel. This stainless steel has a special advanced protective coating that eases the removal of marks such as fingerprints and water spots. To keep its appearance, clean it regularly with lukewarm soapy water and a soft cloth.

## 

Never use stainless steel cleaners, abrasive pads or other cleaners that will scratch the surface. Damage to the appliance after delivery is not covered by your warranty.

### Interior

Clean the inside of your refrigerator regularly with a soft cloth, unscented mild soap and lukewarm water. Thoroughly dry all surfaces and removable parts and avoid getting water on the controls. Replace removable parts, plug power cord in and switch the power on before returning the food.

### Door seals

Always keep door seals clean by washing them with a mild detergent and warm water, followed by a thorough drying. Sticky food and drink can cause seals to stick to the cabinet and tear when you open the door.

Never use hot water, solvents, commercial kitchen cleaners, aerosol cleaners, metal polishes, caustic or abrasive cleaners, or scourers to clean your refrigerator. Many commercially available cleaning products and detergents contain solvents that will damage your refrigerator. Use only a soft cloth with an unscented mild soap and lukewarm water.

## $\angle$ CAUTION

To clean a crisper or freezer bin with telescopic extension slides, simply wipe with a damp cloth and warm soapy water. Never immerse the cover in water, as this could affect the operation of the slide.

### Switching off your refrigerator

If you switch off your refrigerator for an extended period, follow these steps to reduce the chances of mould:

- 1. Remove all food.
- 2. Remove the power plug from the power point.
- 3. Thoroughly clean and dry the Interior.
- 4. Ensure that all the doors are wedged open slightly for air circulation.

### FOOD STORAGE GUIDE

| CATEGORY | PRODUCT            | REFRIGERATOR |
|----------|--------------------|--------------|
| MEAT     | Sausages and Mince | 1-2 Days     |
|          | Chops and Steak    | 3-4 Days     |
|          | Cold Meats         | 3-5 Days     |
|          | Roasts             | 3-5 Days     |
| POULTRY  | Chicken            | 1-2 Days     |
|          | Roast Chicken      | 3-5 Days     |
|          | Eggs               | 6 Weeks      |

| CATEGORY   | PRODUCT  | REFRIGERATOR          | FREEZER  | STORAGE TIPS   |  |
|------------|--|-----------------------|--|--|--|
| MEAT       | Sausages and Mince   | 1-2 Days              | 2-3 Months   | Keep cold meat at the back of the  |  |
|            | Chops and Steak  | 3-4 Days              | 4-6 Months   | refrigerator where it is coldest.  |  |
|            | Cold Meats   | 3-5 Days              | 4-6 Months   | Plastic can cause meat to sweat if<br>stored in refrigerator for more than<br>a day.   |  |
|            | Roasts   | 3-5 Days              | 12 Months  | Roast can take up to 48 hours to<br>defrost properly, transfer frozen<br>roast to the refrigerator 2 days<br>before use.       |  |
| POULTRY    | Chicken  | 1-2 Days              | 2 Months   | If poultry takes on a smell or colour  |  |
|            | Roast Chicken  | 3-5 Days              | 12 Months  | you are unsure about it is best to throw it out.   |  |
|            | Eggs   | 6 Weeks               | Not Suitable   |  |  |
|            |  |                       |  | Whole eggs are not suitable for<br>freezing, slightly beaten eggs may<br>be frozen for four months.                            |  |
| SEAFOOD    | Whole fish and fillets   | 2-3 Days              | 2 Months   | Store in an airtight container or foil.  |  |
|            | Lobster and Crab   | 1-2 Days              | 2 Months   | Never freeze prawns in salty water   |  |
|            | Prawns   | 1-2 Days              | 2 Months   | as this will dehydrate the flesh.  |  |
| DAIRY      | Milk   | Until Expiry Date     | Not Suitable   | If dairy takes on a smell or colour  |  |
|            | Yoghurt  | 7- 10 Days            | Not Suitable   | and you are unsure about it, it is best to throw it out.   |  |
|            | Hard Cheeses   | 2 Weeks - 2<br>Months | 2 Months<br>(Grated)                                   |  |  |
|            | Soft Cheeses   | 1-2 Weeks             | Not Suitable   | Depending on the variety hard  |  |
|            | Butter   | 8 Weeks               | 12 Months  | cheese can last from 2 weeks to 2 months.  |  |
| FRUIT &    | Every fruit and veget  | able has a different  | 8-12 Months  | Keep vegetables in the crisper and   |  |
| VEGETABLES | shelf life. Some stay f<br>of days e.g beans, ot<br>couple of months e.g | hers can last for a   | When freezing<br>chop and blanch<br>in small portions. | away from the air vents to avoid freezing.   |  |
|            |  |                       |  | Don't wash fruit and vegetables<br>before storing them in the<br>refrigerator as this can make them<br>susceptible to rotting. |  |
| LEFT OVERS | Homemade meals   | 3-4 Days              | 2-6 Months   | Store in sealed container.   |  |
|            |  |                       |  | Freeze meals in small portion sizes to limit wastage.  |  |



Please note, use this information as a guide only, actual storage times will vary depending on how you use your refrigerator, climatic conditions and the freshness of the food.

## TROUBLESHOOTING

### Appliance does not operate at desired temperature

In a modern frost free refrigerator / freezer, cold air is circulated around the various compartments through air vents using a high efficiency fan.

| CONCERN                               | WHAT TO DO   |
|---------------------------------------|--|
| Refrigerator is too warm              | Ensure food is allowed to cool before placing inside the refrigerator.   |
|                                       | Ensure the appliance is set up as per instructions on page 11.   |
|                                       | Ensure that contents are not obstructing the cooling vents.  |
|                                       | Ensure the door is not held open or is being opened too frequently.  |
| Freezer is too warm                   | Adjust temperature to a colder setting.  |
|                                       | Ensure food is allowed to cool before placing inside the freezer.  |
|                                       | Ensure the appliance is set up as per instructions on page 11.   |
|                                       | Ensure that contents are not obstructing the cooling vents.  |
|                                       | Ensure the door is not held open or is being opened too frequently.  |
| Food is freezing in the refrigerator  | Adjust temperature to a warmer setting.  |
|                                       | Ensure that fruit and vegetables are stored in the crisper. Items with a high water content should not be placed near the cooling vents. |
| Unable to change temperature settings | Refer to Refer to sections "temperature control" and "about the user interface".   |
|                                       | Ensure that user interface is in "awake" mode before trying to adjust temperature settings.  |

### Appliance noise

Your new refrigerator may make sounds that your old one didn't make. Because the sounds are new to you, you might be concerned about them. Most of the new sounds are normal. Hard surfaces, like the floor, walls and cabinets, can make the sounds seem louder than they actually are. The following describes the kinds of sounds and what may be making them.

| CONCERN   | WHAT TO DO  |
|---|---|
| Motor noise (compressor)                                  | Nothing. This is normal as your new refrigerator uses a high-speed compressor which switches on and off during operation.   |
|   | Note that the compressor noise may seem louder at the start of the on cycle.  |
| A clicking noise heard just before the compressor starts. | Nothing. This is normal as your new refrigerator has an automatic switching action of the temperature control, turning the compressor on and off.                                 |
| Occcasional gurgling, similar to water boiling.           | Nothing. As each cycle ends, you may hear a gurgling sound due to the refrigerant flowing in your refrigerator system.  |
| Airflow noise.  | Nothing, this is normal as your new refrigerator uses high efficiency fans<br>to circulate air. Fan speed and noise may increase during periods of heavy<br>usage or hot weather. |
| Rattling and other noises.                                | Ensure that the cabinet is level and stable, refer to Installation Instructions on page 11.   |
|   | Check the surrounds of the appliance to ensure there is nothing touching or placed on top of the appliance.   |
|   | Ensure that contents of the appliance are not placed in such a way that they are vibrating (such as bottles).   |

### **Crisper Operation**

| CONCERN   | WHAT TO DO  |
|---|---|
| Excess moisture build up in crisper   | Ensure that the crisper is not over packed.   |
| It is normal for there to be some moisture and humidity in the crisper bin. | Adjust crisper humidity slides.   |
| Crisper bin can not be removed  | If crisper bin interferes with the door bins, remove door bins before removing crisper. |
|   | Position cabinet so that the door can be fully opened.                                  |
| Freezing items in the crisper   | Adjust temperature to a warmer setting.   |

### **Refrigerator operation**

| CONCERN  | WHAT TO DO                                       |
|--|--|
| Appliance will not run   | Ensure that the cord switched on.                |
| It is normal for the freezer fan not to<br>operate during the automatic defrost<br>cycle, or for a short time after the                      | Ensure that the hous has not blown.              |
| appliance is switched on.  | The appliance maybe                              |
| Compressor motor seems to run  | Ensure that the door                             |
| oo long<br>At normal room temperatures, expect   | Check that large amo<br>the appliance.           |
| our motor to run about 40% to 80%<br>of the time. Under warmer conditions,<br>expect it to run even more often.                              | Note that the appliar<br>when adjusting to te    |
| The exterior of the appliance is warm<br>or hot to touch   | Ensure the appliance section "Installing yo      |
| This is normal because the appliance<br>cransfers heat from the inside out<br>chrough the outer panels and the<br>divider between the doors. | The exterior of the ca<br>even feel hot to touc  |
| Jser interface will not respond  | Check that the user i user interface".           |
| To ensure settings are not accidentally<br>changed the user interface will go into<br>sleep mode when not in use. Press any                  | Check that the user i user interface".           |
| button to wake user interface  | If the user interface is<br>memory to clear, the |
|  | Check that the user i instructions. (I&W me      |
| Alarms Sounding  | Check that all doors                             |
|  | Ensure that the over placed in the freezer.      |
|  | Check if the drinks ti                           |
|  | Check if the Filter Re<br>(I&W models only)      |
| Frost build up   | Check that all doors                             |
|  | Ensure that the door                             |
|  | Ensure that the retur                            |
|  | Ensure the seals are                             |
| Odours   | The interior may nee                             |
|  | Ensure that food is si<br>wrapping can produc    |
|  | Check appliance for                              |
| _ights not working   | Ensure that the cord switched on.                |
| The LED lighting is designed to turn on gradually.   | Ensure that the hous has not blown.              |
|  | Check that the user i instructions.              |
|  | Check the appliance for your model.              |

rd is plugged into a live power outlet and outlet is

usehold circuit breaker has not tripped or that the fuse

be in defrost mode, check again in half an hour.

ors are not held open

mounts of warm food have not just been placed inside

iance will run more than normal just after you install it or temperature setting changes.

ce has the external clearances recommended in the your new appliance".

cabinet will be much warmer on warmer days it may uch, as the appliance is working harder.

er interface is in awake mode, refer to section "About the

er interface is not locked, refer to section "About the

e is frozen turn the appliance off for five minutes for the nen turn back on.

r interface is not in Sabbath Mode, refer to control models only).

rs are fully closed.

er temperature alarm is not being activated by hot food er.

timer has ended, refer control instructions.

Replacement alert is activated, refer control instructions.

rs are fully closed.

ors are not opened too often.

urn air vents are not blocked with packaging.

re clean and not obstructed.

eed cleaning, refer to cleaning guide.

s stored correctly as some food, containers and duce odours.

or old or unusual food.

rd is plugged into a live power outlet and outlet is

usehold circuit breaker has not tripped or that the fuse

r interface is not in Sabbath Mode, refer to control

ce features section to determine lighting configuration

## TROUBLESHOOTING

### Door operation

| CONCERN                          | WHAT TO DO   |
|----------------------------------|--|
| Freezer door pops open.          | This is normal and should re-close. This happens when the refrigerator door is closed too quickly.   |
|                                  | If the freezer door stays open, it indicates that the appliance needs to<br>be tilted backwards a little further. Refer to section "Installing your<br>new appliance". |
| Self close not working.          | Check if your appliance has self closing hinges as not all models do.  |
|                                  | It indicates that the appliance needs to be tilted backwards a little further.<br>Refer to section "Installing your new appliance".                                    |
| Door not sealing properly        | Ensure there is nothing that is preventing the door from closing such as appliance contents or items placed near the appliance.  |
|                                  | Ensure that the crisper/freezer bin is closed completely. Refit if required as referred to in the section "Using your refrigerator".                                   |
|                                  | Ensure the appliance is set up as per recommendations.   |
| Door difficult to open and close | If the door is difficult to open just after you have closed it this is due to the pressure equalising, the door will open normally after a few minutes.                |

### Ice & Water system

| CONCERN   | WHAT TO DO   |
|---|--|
| Ice maker does not produce ice or not enough ice  | Ensure that the cord is plugged into a live power outlet and outlet is switched on.  |
| The icemaker is designed to produce a tray of ice approximately every 3 hours, depending on the conditions. | Ensure that water is connected and turned on and there are no kinks in the water line.   |
|   | Ensure that the Ice Maker is switched on at the user interface refer to "About the User Interface" for details.  |
|   | Check that the water filter is not blocked or out of date.   |
|   | Check the water supply flow rate.  |
|   | If the freezer compartment is too warm, refer to "freezer is too warm" then wait 24 hours for the freezer to reach ideal temperature.                                |
|   | Turn the unit off at the mains and leave for 2 minutes then turn the appliance back on (this will reset the icemaker unit). Check for ice production after 24 hours. |
|   | Check that there is no obstruction under the ice maker and ensure the ice bin is fitted correctly.   |
| Water dispenser not functioning   | Ensure that the cord is plugged into a live power outlet and outlet is switched on.  |
|   | Ensure that water is connected and turned on and there are no kinks in the water line.   |
|   | Ensure that the Water Dispenser is switched on at the user interface refer to "About the User Interface" for details.  |
|   | Ensure water line is purged refer to "Ice & Water installation".   |
|   | Check that the water filter is not blocked or out of date.   |
|   | Check the water pressure, refer to "Ice & Water installation".   |
| Ice or water has bad odour or taste   | Cover food to ensure ice does not absorb foreign odours.   |
|   | Check that the water filter is not out of date.  |
|   | Interior of appliance or ice bin may require cleaning, refer to "Cleaning your refrigerator".  |
|   | Discard stale ice monthly and allow ice maker to produce a fresh supply.   |

### If you still require service

If you have a problem, and the problem persists after you have made the checks mentioned, contact your nearest Electrolux approved Service Centre or the dealer you bought the refrigerator from. Be ready to quote the model number, the 9-digit PNC and 8-digit serial number, which is stated on the label inside the refrigerator compartment.

### NOTES



### Electrolux Warrantv FOR SALES IN AUSTRALIA AND NEW ZEALAND APPLIANCE: REFRIGERATION

This document sets out the terms and conditions of the product warranties for Electrolux Appliances. It is an important document. Please keep it with your proof of purchase documents in a safe place for future reference should you require service for your Appliance.

#### 1. In this warranty:

- (a) 'acceptable quality' as referred to in clause 10 of this warranty has the same meaning referred to in the ACL;
- (b) 'ACL' means Schedule 2 to the Competition and Consumer Act 2010;
- (c) 'Appliance' means any Electrolux product purchased by you and accompanied by this document;
- (d) 'ASC' means Electrolux authorised service centres;
- (e) 'Electrolux' means Electrolux Home Products Pty Ltd of 163 O'Riordan Street, Mascot NSW 2020, ABN 51 004 762 341 in respect of Appliances purchased in Australia and Electrolux (NZ) Limited (collectively 'Electrolux') of 3-5 Niall Burgess Road, Mount Wellington, in respect of Appliances purchased in New Zealand;
- (f) 'major failure' as referred to in clause 10 of this warranty has the same meaning referred to in the ACL and includes a situation when an Appliance cannot be repaired or it is uneconomic for Electrolux, at its discretion, to repair an Appliance during the Warranty Period;
- (g) 'Warranty Period' means the Appliance is warranted against manufacturing defects in Australia and New Zealand for 24 months and for the Appliance's compressor, condenser, evaporator and drier, an additional 36 months parts only warranty applies, following the date of original purchase of the Appliance;
- (h) 'you' means the purchaser of the Appliance not having purchased the Appliance for re-sale, and 'your' has a corresponding meaning.
- 2. This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand.
- 3. During the Warranty Period Electrolux or its ASC will, at no extra charge if your Appliance is readily accessible for service, without special equipment and subject to these terms and conditions, repair or replace any parts which it considers to be defective. Electrolux or its ASC may use remanufactured parts to repair your Appliance. You agree that any replaced Appliances or parts become the property of Electrolux. This warranty does not apply to light globes, batteries, filters or similar perishable parts.
- 4. Parts and Appliances not supplied by Electrolux are not covered by this warranty.
- 5. To the extent permitted by law, you will bear the cost of transportation, travel and delivery of the Appliance to and from Electrolux or its ASC. If you reside outside of the service area, you will bear the cost of:
  - (a) travel of an authorised representative:
- (b) transportation and delivery of the Appliance to and from Electrolux or its ASC.

In all instances, unless the Appliance is transported by Electrolux or an Electrolux authorised representative, the Appliance is transported at the owner's cost and risk while in transit to and from Electrolux or its ASC.

6. Proof of purchase is required before you can make a claim under this warranty.

### Important Notice

| FOR SERVICE<br>or to find the address of your nearest<br>state service centre in Australia<br>PLEASE CALL 13 13 49<br>For the cost of a local call (Australia only) | SERVICE AU<br>Electrolux HON<br>www.electrolu       |
|---|---|
| FOR SERVICE<br>or to find the address of your nearest<br>authorised service centre in New Zealand<br>FREE CALL 0800 10 66 10<br>(New Zealand only)                  | SERVICE NEW<br>Elect<br>ELECTROLUX (<br>www.electro |

GFR\_Warr\_Aug13

NOTES

- 7. You may not make a claim under this warranty unless the defect claimed is due to faulty or defective parts or workmanship. Electrolux is not liable in the following situations (which are not exhaustive):
  - (a) the Appliance is damaged by:
  - (i) accident
  - (ii) misuse or abuse, including failure to properly maintain or service
  - (iii) normal wear and tear
  - (iv) power surges, electrical storm damage or incorrect power supply
  - (v) incomplete or improper installation
  - (vi) incorrect, improper or inappropriate operation
  - (vii) insect or vermin infestation
  - (viii) failure to comply with any additional instructions supplied with the Appliance;
  - (b) the Appliance is modified without authority from Electrolux in writing;
  - (c) the Appliance's serial number or warranty seal has been removed or defaced:
  - (d) the Appliance was serviced or repaired by anyone other than Electrolux, an authorised repairer or ASC.
- 8. This warranty, the contract to which it relates and the relationship between you and Electrolux are governed by the law applicable where the Appliance was purchased. Where the Appliance was purchased in New Zealand for commercial purposes the Consumer Guarantee Act does not apply.
- 9. To the extent permitted by law and subject to your non-excludable statutory rights and warranties. Electrolux excludes all warranties and liabilities (other than as contained in this document) including liability for any loss or damage whether direct or indirect arising from your purchase, use or non use of the Appliance.
- 10. For Appliances and services provided by Electrolux in Australia, the Appliances come with a guarantee by Electrolux that cannot be excluded under the ACL. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the Appliance repaired or replaced if the Appliance fails to be of acceptable quality and the failure does not amount to a major failure. The benefits to you given by this warranty are in addition to your other rights and remedies under a law in relation to the Appliances or services to which the warranty relates.
- 11. At all times during the Warranty Period, Electrolux shall, at its discretion, determine whether repair, replacement or refund will apply if an Appliance has a valid warranty claim applicable to it.
- 12. For Appliances and services provided by Electrolux in New Zealand, the Appliances come with a guarantee by Electrolux pursuant to the provisions of the Consumer Guarantees Act, the Sale of Goods Act and the Fair Trading Act.
- 13. To enquire about claiming under this warranty, please follow these steps:
- (a) carefully check the operating instructions, user manual and the terms of this warranty:
- (b) have the model and serial number of the Appliance available;
- (c) have the proof of purchase (e.g. an invoice) available;
- (d) telephone the numbers shown below.
- 14. You accept that if you make a warranty claim, Electrolux and its ASC may exchange information in relation to you to enable Electrolux to meet its obligations under this warranty.

Before calling for service, please ensure that the steps listed in clause 13 above have been followed.

| <b>JSTRALIA</b><br>ctrolux<br>ME PRODUCTS<br>lux.com.au | FOR SPARE PARTS<br>or to find the address of your nearest<br>state spare parts centre in Australia<br><b>PLEASE CALL 13 13 50</b><br>For the cost of a local call (Australia only) |
|---|--|
| V ZEALAND   | FOR SPARE PARTS  |

trolux (NZ) Limited lux.co.nz

#### state spare parts centre in New Zealand FREE CALL 0800 10 66 20 (New Zealand only)

or to find the address of your nearest

For more information on all Westinghouse appliances, or for dimension and installation information, call into your retailer, phone or email our customer care team or visit our website:

### AUSTRALIA

phone: 1300 363 640fax: 1800 350 067email: customercare@electrolux.com.auweb: westinghouse.com.au

### **NEW ZEALAND**

phone: 0800 436 245fax: 0800 225 088email: customercare@electrolux.co.nzweb: westinghouse.co.nz



### TOP SERVICE

Top Service encompasses the after sales service provided by The Electrolux Group to consumers including delivery, home service and spare parts.

Westinghouse. We are part of the Electrolux family. Share more of our thinking at electrolux.com.au

(2) and WESTINGHOUSE are trademarks of Westinghouse Electric Corporation. Used under license. All Rights Reserved.

P/No. 811948423

© 2015 Electrolux Home Products Pty Ltd. ABN 51 004 762 341 WMAN\_TFBF\_Aug15