Always there to help you

Register your product and get support at
www.philips.com/welcome

Question? Contact Philips

HTL2150



User manual

PHILIPS

Downloaded from www.Manualslib.com manuals search engine

Contents

1 Important 3
Help and support 3
Safety 3
Care for your product 4
Care of the environment 4

2 Your SoundBar 5
Assemble your Soundbar 5
Main unit 5
Remote control 5
Connectors 6

3 Connect 7
Placement 7
Connect audio from TV and other devices 7

4 Use your SoundBar 9
Adjust the volume 9
Choose your sound 9
MP3 player 9
Auto standby 9
Apply factory settings 9

5 Wall mount 10

6 Product specifications 11

7 Troubleshooting 12

8 Notice 13
Compliance 13
Trademarks 13

Downloaded from www.Manualslib.com manuals search engine

1 Important

Read and understand all instructions before you use your product. If damage is caused by failure to follow instructions, the warranty does not apply.

Help and support

Philips provides extensive online support. Visit our website at www.philips.com/support to:

- download the user manual and the quick start guide
- watch video tutorials (available only for selected models)
- find answers to frequently answered questions (FAQs)
- email us a question
- chat with our support representative.

Follow the instructions on the website to select your language, and then enter your product model number.

Alternatively, you can contact Philips Consumer Care in your country. Before you contact Philips, note down the model number and serial number of your product. You can find this information on the back or bottom of your product.

Safety

Risk of electric shock or fire!

- Never expose the product and accessories to rain or water. Never place liquid containers, such as vases, near the product. If liquids are spilt on or into the product, disconnect it from the power outlet immediately. Contact Philips Consumer Care to have the product checked before use.
- Never place the product and accessories near naked flames or other heat sources, including direct sunlight.
- Never insert objects into the ventilation slots or other openings on the product.
- Where the mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
- Disconnect the product from the power outlet before lightning storms.
- When you disconnect the power cord, always pull the plug, never the cable.

Risk of short circuit or fire!

- Before you connect the product to the power outlet, ensure that the power voltage matches the value printed on the back or bottom of the product. Never connect the product to the power outlet if the voltage is different.

Risk of injury or damage to the SoundBar!

- For wall-mountable products, use only the supplied wall mount bracket. Secure the wall mount to a wall that can support the combined weight of the product and the wall mount. Koninklijke Philips Electronics N.V. bears no responsibility for improper wall mounting that results in accident, injury or damage.
- Never place the product or any objects on power cords or on other electrical equipment.
- If the product is transported in temperatures below 5°C, unpack the product and wait until its temperature matches room temperature before connecting it to the power outlet.
- Parts of this product can be made of glass. Handle with care to avoid injury and damage.

Risk of overheating!

- Never install this product in a confined space. Always leave a space of at least four inches around the product for ventilation. Ensure curtains or other objects never cover the ventilation slots on the product.

Downloaded from www.Manualslib.com manuals search engine

Risk of contamination!

- Do not mix batteries (old and new or carbon and alkaine, etc.).
- Danger of explosion if batteries are incorrectly replaced. Replace only with the same or equivalent type.
- Remove batteries if they are exhausted or if the remote control is not to be used for a long time.
- Batteries contain chemical substances, they should be disposed of properly.

Risk of swallowing batteries!

- The product/remote control may contain a coin/button type battery, which can be swallowed. Keep the battery out of reach of children at all times! If swallowed, the battery can cause serious injury or death. Severe internal burns can occur within two hours of ingestion.
- If you suspect that a battery has been swallowed or placed inside any part of the body, seek immediate medical attention.
- When you change the batteries, always keep all new and used batteries out of reach of children. Ensure that the battery compartment is completely secure after you replace the battery.
- If the battery compartment cannot be completely secured, discontinue use of the product. Keep out of reach of children and contact the manufacturer.



This is CLASS II apparatus with double insulation, and no protective earth provided.

Care for your product

Use only microfiber cloth to clean the product.

Care of the environment



Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



When this crossed-out wheeled bin symbol is attached to a product it means that the product is covered by the European Directive 2002/96/EC. Please inform yourself about the local separate collection system for electrical and electronic products.
Please act according to your local rules and do not dispose of your old products with your normal household waste.
Correct disposal of your old product helps to prevent potential negative consequences for the environment and human health.



Your product contains batteries covered by the European Directive 2006/66/EC, which cannot be disposed with normal household waste. Please inform yourself about the local rules on separate collection of batteries because correct disposal helps to prevent negative consequences for the environmental and human health.

Downloaded from www.Manualslib.com manuals search engine

2 Your SoundBar


Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your SoundBar at www.philips.com/welcome.

Assemble your Soundbar

Assemble your SoundBar as described in the quick start guide (Step 1).

Main unit

This section includes an overview of the main unit.



1 ⏻
Switch the SoundBar on or to standby.

2 VOLUME +-
Increase or decrease volume.

3 SOURCE
Select an audio source for the SoundBar.

4 Power
Lights up when you switch on the SoundBar.


5 Source indicators
Source indicator lights up when a source is selected.

- COAX/OPT: Lights up when you switch to coaxial input or optical input source.
- AUX: Lights up when you switch to analog input source.
- AUDIO-IN: Lights up when you switch to audio input source.

6 SURR
Lights up when you select Virtual Surround sound.

Remote control

This section includes an overview of the remote control.



Downloaded from www.Manualslib.com manuals search engine

① ⏻ (Standby-On)
Switch the SoundBar on or to standby.

② COAX
Switch your audio source to the coaxial connection.

③ OPTICAL
Switch your audio source to the optical connection.

④ TREBLE +/-
Increase or decrease treble.

⑤ SURR
Toggle between stereo and virtual surround sound.

⑥ 🔇
Mute or restore volume.

⑦ BASS +/-
Increase or decrease bass.

⑧ VOLUME +/-
Increase or decrease volume.


⑨ AUDIO-IN
Switch your audio source to the audio input connection.

⑩ AUX
Switch your audio source to the AUX connection.

Connectors


This section includes an overview of the connectors available on your SoundBar.

Top connectors



① AUDIO-IN
Audio input from an MP3 player (3.5mm jack).

Rear connectors



① AUDIO IN
Connect to an analog audio output on the TV or an analog device.

② DIGITAL IN-COAXIAL
Connect to a coaxial audio output on the TV or a digital device.

③ DIGITAL IN-OPTICAL
Connect to an optical audio output on the TV or a digital device.

④ SUBWOOFER
Connect to the supplied subwoofer.

⑤ AC MAINS~
Connect to the power supply.

Downloaded from www.Manualslib.com manuals search engine

3 Connect


This section helps you connect your SoundBar to a TV and other devices.
For information about the basic connections of your SoundBar and accessories, see the quick start guide.

Note

- For identification and supply ratings, refer to the type plate at the back or bottom of the product.
- Before you make or change any connections, make sure that all devices are disconnected from the power outlet.

Placement

Place the subwoofer at least 1 meter (3 feet) away from your SoundBar, and ten centimeters away from the wall.
For best results, place your subwoofer as shown below.




Connect audio from TV and other devices

Play audio from TV or other devices through your Soundbar speakers.
Use the best quality connection available on your TV, Soundbar, and other devices.

Option 1: Connect audio through a digital optical cable


Best quality audio



1 Using an optical cable, connect the **OPTICAL** connector on your SoundBar to the **OPTICAL OUT** connector on the TV or other device.
   - The digital optical connector might be labeled **SPDIF** or **SPDIF OUT**.

Option 2: Connect audio through a digital coaxial cable

Good quality audio



1 Using a coaxial cable, connect the **COAXIAL** connector on your SoundBar to the **COAXIAL/DIGITAL OUT** connector on the TV or other device.


Downloaded from www.Manualslib.com manuals search engine

- The digital coaxial connector might be labeled **DIGITAL AUDIO OUT**.

Option 3: Connect audio through analog audio cables

Basic quality audio

1 Using an analog cable, connect the **AUX** connectors on your SoundBar to the **AUDIO OUT** connectors on the TV or other device.



Downloaded from www.Manualslib.com manuals search engine

4 Use your SoundBar

This section helps you use the SoundBar to play audio from connected devices.

Before you start

- Make the necessary connections described in the quick start guide or download the user manual from www.philips.com/support.
- Switch the SoundBar to the correct source for other devices.

Adjust the volume

1 Press **VOLUME +/-** to increase or decrease a volume level.
   - To mute sound, press (**MUTE**).
   - To restore the sound, press (**MUTE**) again or press **VOLUME +/-**.

   ↳ All **Source indicators** on the main unit blink twice when a volume is set to the maximum or minimum value.

Choose your sound

This section helps you choose the ideal sound for your video or music.

Surround sound mode

Experience an immersive audio experience with surround sound modes.

1 Press **SURR** to select a surround mode.
   - **[Virtual Surround]**: Creates a highly surround listening experience The **SURR** indicator on the main unit lights up.
   - **[Stereo]**: Two-channel stereo sound. Ideal for listening to music.

Equalizer

Change the high frequency (treble) and low frequency (bass) settings of the SoundBar.

1 Press **TREBLE +/-** or **BASS +/-** to change the frequency.

   ↳ All **Source indicators** on the main unit blink twice when treble or bass is set to the maximum or minimum value.

MP3 player

Connect your MP3 player to play your audio files or music.

What you need

- An MP3 player.
- A 3.5mm stereo audio cable.

1 Using the 3.5mm stereo audio cable, connect the MP3 player to the **AUDIO-IN** connector on your SoundBar.

2 Press **AUDIO-IN**.

3 Press the buttons on the MP3 player to select and play audio files or music.

Auto standby

When playing media from a connected device, the SoundBar automatically switches to standby if:

- no button is pressed for 30 minutes, and
- no audio play from a connected device.

Apply factory settings

You can reset your SoundBar to the default settings programmed at the factory.

1 In mute mode, quickly press **AUX** twice.

   ↳ The factory settings is restored.

Downloaded from www.Manualslib.com manuals search engine


5 Wall mount

Note

- Koninklijke Philips Electronics N.V. bears no responsibility for improper wall mounting that results in accident, injury or damage. If you have any query, contact Philips Consumer Care in your country.
- Before wall mounting, make sure the wall can support the weight of your SoundBar.

Screw length/diameter

Depending on the type of wall mounting your SoundBar, make sure that you use screws of a suitable length and diameter.



For information about how to wall mount your SoundBar, see the quick start guide.

Downloaded from www.Manualslib.com manuals search engine

6 Product specifications

Note

- Specifications and design are subject to change without notice.

Amplifier

- Total output power: 60W RMS (+/- 0.5 dB, 10% THD)
- Frequency response: 20 Hz-20 kHz / ±3 dB
- Signal-to-noise ratio: > 65 dB (CCIR) / (A-weighted)
- Input sensitivity:
  - AUX: 2 V
  - AUDIO-IN: 1V

Audio

- S/PDIF Digital audio input:
  - Coaxial: IEC 60958-3
  - Optical: TOSLINK

Main unit

- Power supply: 220-240 V~, 50 Hz - 60 Hz
- Power consumption: 30 W
- Standby power consumption: ≤ 0.5 W
- Speaker impedance: 6 ohm (Tweeter), 4 ohm (Woofer)
- Frequency response: 160 Hz-20 kHz
- Dimensions (WxHxD): 800 x 75.6 x 52.4 mm
- Weight: 1.2 kg

Subwoofer

- Impedance: 8 ohm
- Speaker drivers: 130 mm (5.25") woofer
- Frequency response: 45 Hz-200 Hz
- Dimensions (WxHxD): 165 x 240 x 295 mm
- Weight: 2.6 kg
- Cable length: 3 m

Remote control batteries

- 1 x CR2025

Downloaded from www.Manualslib.com manuals search engine

7 Troubleshooting

Warning

- Risk of electric shock. Never remove the casing of the product.

To keep the warranty valid, never try to repair the product yourself.
If you have problems using this product, check the following points before you request service.
If you still have a problem, get support at www.philips.com/support.

Main unit

The buttons on the SoundBar do not work.

- Disconnect the SoundBar from the power supply for a few minutes, then reconnect.

Sound

No sound from SoundBar speakers.

- Connect the audio cable from your SoundBar to your TV or other devices.
- Reset your SoundBar to its factory settings.
- On the remote control, select the correct audio input.
- Make sure that the SoundBar is not muted.

Distorted sound or echo.

- If you play audio from the TV through the SoundBar, make sure that the TV is muted.

Downloaded from www.Manualslib.com manuals search engine

8 Notice

This section contains the legal and trademark notices.

Compliance

CE

This product complies with the radio interference requirements of the European Community.

Trademarks

DOLBY DIGITAL

Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.

Downloaded from www.Manualslib.com manuals search engine

Philips Consumer Lifestyle

HK-1242- HTL2150/12 | Year 2012

(Report No. / Numéro du Rapport) | *(Year in which the CE mark is affixed / Année au cours de laquelle le marquage CE a été apposé)*

EC DECLARATION OF CONFORMITY

(DECLARATION DE CONFORMITE CE)

We / Nous, PHILIPS CONSUMER LIFESTYLE B.V.
(Name / Nom de l'entreprise)

TUSSENDIEPEN 4, 9206 AD DRACHTEN, THE NETHERLANDS
(address / adresse)

Declare under our responsibility that the electrical product(s):
(Déclarons sous notre propre responsabilité que le(s) produit(s) électrique(s):)

PHILIPS — *(brand name, nom de la marque)*

HTL2150/12 — *(Type version or model, référence ou modèle)*

SOUNDBAR SPEAKER
(product description, description du produit)

To which this declaration relates is in conformity with the following harmonized standards:
(Auquel cette déclaration se rapporte, est conforme aux normes harmonisées suivantes)

(title, number and date of issue of the standard / titre, numéro et date de parution de la norme)

EN60065:2002+A1:2006+A11:2008+A2:2010+A12:2011
EN 55013:2001+A1: 2003+A2: 2006
EN 55020:2007+A11:2011
EN61000-3-2:2006+A1:2009+A2:2009
EN61000-3-3:2008
EN50564:2011
EN62311:2008

Following the provisions of :
(Conformément aux exigences essentielles et autres dispositions pertinentes de:)

2006/95/EC (Low Voltage Directive)
2004/108/EC (EMC Directive)
2011/65/EU (RoHS Directive)
2009/125/EC (ErP Directive)
- EC/1275/2008

And are produced under a quality scheme at least in conformity with ISO 9001 or CENELEC Permanent Documents

(Et sont fabriqués conformément à une qualité au moins conforme à la norme ISO 9001 ou aux Documents Permanents CENELEC)


The Notified Body (L'Organisme Notifié) DEKRA *(Name and number/ nom et numéro)* performed (a effectué) CB (description of intervention / description de l'intervention)

NL-24698

And issued the certificate, *(et a délivré le certificat)* *(certificate number / numéro du certificat)*


Remarks:
(Remarques:)

Drachten, Netherlands, October 23, 2012
(place,date / lieu, date)



A.Speelman, CL Compliance Manager
(signature, name and function / signature, nom et fonction)

Downloaded from www.Manualslib.com manuals search engine



Specifications are subject to change without notice
© 2013 Koninklijke Philips Electronics N.V.
All rights reserved.

HTL2150_12_UM_V3.0



Downloaded from www.Manualslib.com manuals search engine