

# Tuff Dome® Twin

## PITCHING YOUR TENT

1. Choose a flat site, clear away any sharp sticks or stones that may damage your tent floor.
2. Lay out the inner tent and peg it out at the corners.
3. Assemble the poles ensuring each section locks together to form continuous lengths.
4. The poles are colour coded to match the coloured tape on the pole sleeves, thread the poles through the pole sleeves and secure in the eyelets in the tapes.
5. Attach the plastic c-clips on the inner tent to the poles. The inner is pitched.
6. Unroll the fly and lay it over the tent. Use the coloured tapes to orientate the fly and line up the windows and doors. Attach Velcro loops on inside of the fly to the poles. Clip the corners to the buckles on the corner tapes.
7. Thread the fly pole through the sleeve in the fly and insert the pole ends into the eyelets in the tapes at the front corners. Peg out the front and back to create the vestibules.
8. Guy Ropes are already attached to your tent. It is important to securely peg out all guy ropes as the weather can change at any time.


Please Note:

Your tent is not fire-proof, be vigilant around flames and fire. Avoid cooking inside on open flames.


This tent is not designed or intended to be used as permanent accommodation.

## Tuff Dome® Twin

### Pole assembly guide



### GUSSETED WINDOWS



The gusseted windows on your tent can be used for ventilation in almost any weather. Maximising ventilation will help to minimise condensation inside your tent.

# BLACK WOLF

ESCAPE | EXPLORE | DISCOVER

### COMPONENT CHECKLIST

- Inner tent and Fly
- Flexible Aluminium poles, 5 assemblies and pole bag
- 46 Steel pegs and peg bag
- Guy ropes (already attached to tent)

### DISASSEMBLY AND TENT CARE

Remove all pegs and clean them before they are put away. Unclip the fly from the inner and remove. Remove all the frames by pushing them out, rather than pulling. Clean any dirt from the pole ends. Fold these up and return to their bag. Turn the inner over to expose the floor - if this is damp or dirty, clean and allow to dry.

Flip the inner the right way up and lay the fly evenly out on top. Fold it up, folding into the centre, until the width is the size of the carry bag. Then roll up from the rear to the front, including the pole and peg bags in the roll.

If you must pack your tent up when wet, dry out as soon as possible to avoid mildew damage.

The specifications of your tent may vary from what is shown as we are always working to improve and update our products.

Made in China