

# CS6010

## MODELS



## Folding Booster Seat



### FORWARD FACING:

To be used with a lap-sash seat belt by children whose shoulders are above the lower shoulder height marker (approximately 4 years of age) until the child's shoulders reach the upper shoulder height marker (approximately 6 to 8 years of age)



**Australian Standard**

AS/NZS: 1754:2010  
Licence No. 25324  
SAI Global

## IMPORTANT

**KEEP THIS BOOKLET IN THE PLACE PROVIDED ON THE CHILD RESTRAINT**

\*All references to age are to an average proportioned child. Children vary in shapes and sizes. The ages outlined above is an approximation only.

# CS6010 MODELS

## Folding Booster Seat

### SUITABILITY OF THE CHILD RESTRAINT

The CS6010 Booster Seat is suitable for toddlers to older children as a booster seat.

### **BOOSTER SEAT** (Type E Forward Facing)

To be used with a lap-sash seat belt by children whose shoulders are above the lower shoulder height marker (approximately 4 years of age) until their shoulders reach the upper shoulder height marker (approximately 6 to 8 years of age)

Continue to use this child restraint until the child reaches this limit.

Children are safest in a booster seat until their shoulders reach the upper shoulder height marker of the booster seat.

Do not use this restraint until child's shoulders are above the lower shoulder height marker.

Just using a seat belt is not recommended for children that have outgrown this seat. Use a larger booster seat.

**THIS RESTRAINT MUST BE USED IN CARS WITH FORWARD FACING SEATS WITH A LAP-SASH SEATBELT.**

**THIS BOOSTER SEAT IS NOT SUITABLE FOR USE WITH A CHILD HARNESS.**

## **IMPORTANT**

### **PLEASE READ AND FOLLOW THESE INSTRUCTIONS EXACTLY**

BEFORE INSTALLATION PLEASE READ CAREFULLY THE WHOLE OF THE INSTRUCTIONS FOR INSTALLATION AND IF IN THE EVENT OF DOUBT ABOUT THE METHOD OF INSTALLATION TO CONSULT INFASECURE OR A CHILD RESTRAINT FITTING STATION AUTHORISED BY THE RELEVANT TRANSPORT AUTHORITY. IN NEW ZEALAND, CONSULT THE AGENT FOR THE VEHICLE.



## **WARNING**

**DO NOT LEAVE CHILDREN UNATTENDED IN THE CAR.**

# Contents

|                                                 |          |
|-------------------------------------------------|----------|
| Suitability of the child restraint .....        | Page 1   |
| Contents & Warnings .....                       | Page 2   |
| <b>BOOSTER SEAT</b>                             |          |
| - Restraint Guide .....                         | Page 3   |
| - CS6010 Child Restraints (Itemised list) ..... | Page 4   |
| - Shoulder Height Marker .....                  | Page 5-6 |
| <b>INSTALLATION</b>                             |          |
| - Installing in Vehicle .....                   | Page 7   |
| <b>USE</b>                                      |          |
| - Using Lap-Sash Seat Belt .....                | Page 7-9 |
| - To Release Child .....                        | Page 9   |
| <b>CARE OF RESTRAINT</b> .....                  |          |
| - Cover Removal / Replacement .....             | Page 10  |
| - Cleaning / Care and Maintenance .....         | Page 10  |



## WARNING

- Use the restraint exactly as shown in the instructions.
- Supervision of children is needed because they may be able to undo buckles.
- DO NOT LEAVE CHILDREN UNATTENDED IN THE CAR.
- Do not alter or modify this restraint.
- Repairs must only be done by the manufacturer or agent.
- Do not allow the restraint to come into contact with polishes, oils, bleach and other chemicals.
- Destroy the restraint if it has been in a severe crash, even if no damage is visible.
- DO NOT USE WITH JUST A LAP BELT. You must use with a lap-sash seatbelt.
- The lap part of the seatbelt must be firmly across the thighs and the sash strap fitted diagonally across the chest and on the shoulder.
- DO NOT USE THIS RESTRAINT WITHOUT THE COVER.
- IF AN AIRBAG IS FITTED IN THE SEATING POSITION WHERE THE CHILD RESTRAINT IS TO BE FITTED, FOLLOW THE VEHICLE MANUFACTURER'S WARNINGS AND INSTRUCTIONS.
- When used in this mode the restraint must be used in conjunction with a lap-sash seat belt.
- Seat belt extenders should not be used if the seat belt is not long enough.

# RESTRAINT GUIDE

**BOOSTER**  
WITH LAP-SASH SEAT BELT

**INFANT SEAT**

**CHILD SEAT**

**BOOSTER SEAT**

**MODE**

BIRTH

2

4

6

8

10

12+

**REARWARD-FACING  
RESTRAINT (TYPE A1)**  
BIRTH TO APPROX  
6 MONTHS



REARWARD FACING

0 to 6 (months)



**CONVERTIBLE  
REARWARD/  
FORWARD-FACING  
RESTRAINT (TYPE A2/B)**  
BIRTH TO 4 YEARS




REARWARD FACING  
FORWARD FACING

Approx 0 to 4 years



**ZERO TO 8  
CONVERTIBLE  
RESTRAINT (TYPE A1/B/E)**  
BIRTH TO 8 YEARS



REARWARD FACING  
FORWARD FACING

BOOSTER SEAT

Approx  
0 to 8 years



**FORWARD-FACING  
RESTRAINT (TYPE B)**  
APPROX 6 MONTHS  
TO 4 YEARS



FORWARD FACING

Approx 6 months to 4 years



**CONVERTIBLE  
BOOSTER SEAT (TYPE B/E)**  
APPROX 6 MONTHS  
TO 8 YEARS



FORWARD FACING

BOOSTER SEAT

Approx 6 months  
to 8 years



**BOOSTER SEAT (TYPE E)**  
FROM APPROX  
4 YEARS 8 YEARS



BOOSTER SEAT

BOOSTER SEAT

Approx 4 years  
to 8 years



**CHILD SAFETY HARNESS (TYPE C)**  
FROM APPROX  
4 TO 7 YEARS



**CHILD HARNESS  
SHOULD ONLY BE USED  
IF A LAP ONLY SEAT  
BELT IS AVAILABLE**

Approx 4 to 7 years  
(with Booster seat and lap-belt only)

Approx 7 to 10 years  
(without Booster seat  
and lap-belt only)

FROM APPROX  
7 TO 10 YEARS

**SECUREFIT (ACCESSORY)**  
SAFETY RETAINING DEVICE  
FROM APPROX  
4 TO 7 YEARS



**ONLY USE WITH  
INFA SECURE  
BOOSTER SEATS**

Approx 4 to 7 years  
(with Infa Secure Booster seat)  
\*Not applicable for 2004 Standard models

**SEAT BELT**  
FROM APPROX 7 YEARS  
AND OVER



7 +

10 +

Allowable by law

More Appropriate




## IMPORTANT

Research has shown that the likelihood of an accessory child safety harness being used incorrectly is very high and the risk of injuries when incorrectly used is much higher compared to a lap-sash seat belt. InfaSecure recommend that an accessory child safety harness should only be used if a lap-only seat belt is all that is available.

# MODEL CS6010

**BOOSTER**  
WITH LAP-SASH SEAT BELT




- |                                                                               |                                                   |
|-------------------------------------------------------------------------------|---------------------------------------------------|
| 1. HEADREST                                                                   | 4. COMFORT COVER<br>A - SEAT BASE<br>B - BACKREST |
| 2. VEHICLE SEAT BELT                                                          | 5. ARM REST (EACH SIDE OF THE RESTRAINT)          |
| 3. "BOOSTER SEAT BELT PATH" MARKER<br>(EACH SIDE OF RESTRAINT - COLOURED RED) | 6. SHOULDER HEIGHT MARKER                         |

# SHOULDER HEIGHT MARKER

BOOSTER  
WITH LAP-SASH SEAT BELT


## SMALLER CHILD



**Smaller Child from  
approximately 4 years of age**

Do not use this booster seat if the child's shoulders are below the lower shoulder height marker, (Lower label)

### LOWER LABEL




## IMPORTANT

If moving a child from forward facing child restraint with an inbuilt harness, the child's shoulders will need to be inline or above the lower label. If the child's shoulders are below the lower label the child should continue to use the forward facing child restraint with an inbuilt harness

# SHOULDER HEIGHT MARKER


**BOOSTER**  
WITH LAP-SASH SEAT BELT

## TALLER CHILD



Continue to use this booster seat until the child's shoulders reach the upper shoulder height marker, (Upper Label).

### UPPER LABEL



If the child's shoulders reach the shoulder height markers, the child should move to the next type of restraint (See page 3). Use a larger (Type F) booster seat, if available, otherwise use seat belt assembly.

# INSTALLATION

**BOOSTER**  
WITH LAP-SASH SEAT BELT

## INSTALLING IN VEHICLE

**Step 1:** Unfold the booster seat and place the booster in the car in a forward facing position (refer Figure 1 & 2).




Figure 1




Figure 2

## USE

**BOOSTER**  
WITH LAP-SASH SEAT BELT

## USING LAP-SASH SEAT BELT

**Step 1:** Sit your child in the restraint with their back against the backrest.



### IMPORTANT

Ensure that you use the **BOOSTER SEAT BELT PATH** indicators, marked in "red".

**Step 2:** Position the lap section of the vehicle seat across the child's lap then insert the buckle tongue in the belt buckle (A).



Figure 1



### IMPORTANT

Refer to shoulder height marker (As shown on pages 5 and 6)



# USE

**BOOSTER**  
WITH LAP-SASH SEAT BELT

## USING LAP-SASH SEAT BELT

**Step 3:** Remove the seat belt slack by first pulling on the lap belt in the direction of arrow 1 (refer figure 1) then pull the sash belt in the direction of arrow 2. Ensuring the lap portion is positioned under the armrests and over the child's thighs.

**Step 4:** The shoulder strap passes diagonally across the child's chest and depending on your child's height passes either under the headrest for a smaller child (refer Figure 3) or above the headrest for a larger child (refer Figure 4).



Figure 2



### WARNING

**DO NOT LEAVE CHILDREN UNATTENDED IN THE CAR.**

**SMALLER CHILD**

Buckle & Tongue Assembly



Figure 3

**LARGER CHILD**

Buckle & Tongue Assembly





Figure 4

## SAFETY WARNING



### WARNING

**A sash belt under the arm or behind the back is dangerous**

# USE

BOOSTER  
WITH LAP-SASH SEAT BELT

## TO RELEASE CHILD

**Step 1:** To release your child from the restraint simply press the belt buckle and carefully remove your child from the seat. It is not necessary to release the red belt clamp, to remove your child.

**Note:** When the restraint is not in use, the seat belt should be fastened around it and engaged.




## WARNING

- Do not use on any vehicle seat which faces sideways or rearwards.
- IF AN AIRBAG IS FITTED IN THE SEATING POSITION WHERE THE CHILD RESTRAINT IS TO BE FITTED, FOLLOW THE VEHICLE MANUFACTURER'S WARNINGS AND INSTRUCTIONS.
- **DO NOT USE WITH JUST A LAP BELT. You must use with a lap-sash seat belt.**
- Ensure the lap belt is correctly positioned on the child's thighs and hips.
- Do not place the seat belt sash under the arm or behind the back of the child.
- Seat belt extenders should not be used if the seat belt is not long enough.

## CARE OF RESTRAINT

The CS6010 Booster Seat cover has been manufactured to meet the Australian Standards requirements for flammability and toxicity to ensure your child's safety. The cover has also been designed to provide your child with comfort and support.



1. BACKREST
2. BASE COVER

# CARE OF RESTRAINT



## VERY IMPORTANT

**Only use this child restraint with the cover supplied or a manufacturer-Authorised replacement cover with identical shoulder height markers**

### COVER REMOVAL

#### 1. BACKREST COVER

**Step 1:** Disconnect elastic loops

**Step 2:** Remove cover

#### 2. BASE COVER

**Step 1:** Disconnect plastic hooks

**Step 2:** Remove cover

### COVER REPLACEMENT

**Step 1:** Replace the seat covers, in the reverse of the removal procedure.

Ensure you have correctly reattached all elastic loops & hooks.

### CLEANING



## IMPORTANT

Use only mild soap and water to clean all parts of the CS6010 Child Seat.

Do not use chemicals or cleaning agents

Cold water only to be used and to be rinsed well

Do not dry clean or tumble dry

Do not bleach.

### COVERS

Only machine wash on gentle cycle (hand washing is recommended)

When washing the covers, ensure the hook and loop attachment strips

are connected to eliminate other materials or garments being caught.

Ensure that the hook and loop attachment strips are free of lint, this will ensure a positive engagement

### CARE AND MAINTENANCE

Regular care of the restraint will ensure safety of your child.

- Ensure there are no cracks in moulding or the plastic moulding.

## Infasecure Warranty Details

Infasecure Pty Ltd warrants this product for twelve months from the date of purchase against failure due to manufacturing faults or faulty materials. Misuse, accidental damages, normal wear and tear or defect are not covered by this warranty. When used for commercial use the period is limited to six months.

"Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure."

Refer to website for details  
[www.infasecure.com.au](http://www.infasecure.com.au)

### **INFASECURE PTY LTD**

ABN: 52 149 173 660

#### **Head Office and Registered Address**

110-114 Old Bathurst Rd, Emu Plains, NSW 2750  
P.O. Box 487, Emu Plains, NSW 2750

Phone No: 02 4728 8080

Fax: 02 4728 8040

#### **Customer Service**

Phone No: 02 4728 8090

[www.infasecure.com.au](http://www.infasecure.com.au)

ISSUE: A\_1



**infasecure**

caring for the wellbeing of infants

We reserve the right to alter this product without notice.