Baby Monitor

Secure 50

ADVANCED DECT 1.8 GHz TECHNOLOGY

User Guide

Thank you for choosing this monitor from Oricom.

Your Secure 50 Baby Monitor offers the best Digital Technology.

INTERFERENCE FREE FREQUENCY

DECT (Digital Enhanced Cordless Telecommunications) is the most widely used worldwide digital cordless technology, offering amazingly clear sound, long range and maximum voice security.

DECT operates on the 1.8Ghz frequency which eliminates potential interference from other common wireless devices such as cordless telephones, wireless networks (Wi-Fi), Bluetooth and cordless computer devices.

Pack Contents

- Parent unit (receiver)
- Baby unit (sender)
- Mains adaptor with charger pod
- 2 x NiMH rechargeable batteries (type AAA, 800mAh)
- Mains adaptor with power cord

Installation

For the Parent Unit



1 Remove the Belt Clip by lifting the clip at the top and sliding it downwards.

2 Then remove the battery cover on the back of the Parent Unit by switching the OPEN switch. Insert the rechargeable batteries (supplied) as marked on the unit and close the cover again.

3 Place the Parent Unit into the Charger Pod.

4 Plug the mains adaptor into a mains power socket.

The red charger light on the charger pod will illuminate indicating that the Parent Unit is charging.

(the light will remain on to ensure optimum charge is maintained).

WARNING

DO NOT USE STANDARD/ALKALINE BATTERIES IN THE PARENT UNIT, AS THERE IS A RISK OF EXPLOSION AND/OR INJURY. USE ONLY Ni-MH RECHARGEABLE BATTERIES AS SUPPLIED.

- To stop the Page alert, press any button on the Parent Unit, or press [•))] again on the Baby Unit.

Note:
If no button is pressed, the paging tone will stop after 30 seconds.
If the Parent Unit volume is off, the Parent Unit volume will reset to mid volume.

Night light

The Baby Unit has a one touch night light which emits a soft starry glow, providing comfort and reassurance for your baby and allowing you to see them in a darkened room.

Press [💡] on the top of the baby unit. A soft light will turn on gently. Press again and the light will fade away.

Out of Range

When the baby and parent units have no link with each other (eg. Out of range, parent unit or Baby unit is not powered on), the green Link light flashes. The link break alert will be heard from the Parent Unit once only. When the units are linked, the green Link light will be steadily lit.

Low Battery

Baby Unit

When the battery power is low, the power light will ßash.

Parent Unit

When the batteries are low, the red power light will ßash. And also the battery low warning beep will be heard. The unit still can be used for 30 minutes. You should put the parent unit on the charger pod to recharge the batteries.

Note:
Low battery alert can be suppressed by pressing any button.

Charging the Battery

The Parent Unit will work for up to 10 hours with fully charged batteries. If a battery low warning beep is heard and the red Power light on the Parent Unit is ßashing, you should put the parent unit on the Charger Pod to recharge the batteries. You can still use your Parent Unit from the Charger Pod. When charging, the red power light on the charger will light steadily.

When you switch on your Parent Unit, the green and red sensor lights will brießy indicate the current charge level of the batteries in the following way: