

ACCESSORY ORDER FORM

Article		Part No.	Price each AUD	Price each NZD	Qty	Amount
Replacement Shaving Head & Cutters for XR1391AU		SPR-XRAU	\$37.95 AUD	\$49.95 NZD		\$
Beard Trimmer Attachment for XR1391AU		SPR-XTAU	\$37.95 AUD	N/A		\$
Shaver Saver: Aerosol Spray Cleaner		SP4	\$11.95 AUD	\$14.95 NZD		\$
Face Saver: Pre-shave Powder Stick		SP5	\$11.95 AUD	\$14.95 NZD		\$
IMPORTANT: Pricing in effect at time of publication, inclusive of GST. Subject to change without notice. Postage & handling \$7.50 standard for Australia & New Zealand.						\$
For help or to place an order on the phone call Remington Customer Service: ① Australia: 1800 623 118 (toll free) ① New Zealand: 0800 736 776 (toll free)						\$
						\$ 7.50
						\$



Remington is a Registered Trademark
of Spectrum Brands, Inc., or one
of its subsidiaries.



MAIL YOUR ORDER FORM TO:

AUSTRALIAN RESIDENTS:

Spectrum Brands Australia Pty Ltd
Locked Bag 3004
Braeside, VIC 3195
Australia

NEW ZEALAND RESIDENTS:

Spectrum Brands New Zealand Pty Ltd
PO BOX 9817
Newmarket, 1149, Auckland
New Zealand

CLEANING & MAINTENANCE

The shaver is a washable appliance. The head and body may be cleaned under warm water.

NOTE: When cleaning your shaver, make sure the shaver is turned off and disconnected from the power cord.

CAUTION:

- When cleaning the external surfaces of the shaver, do not use strong detergents or other chemicals.
- To dry, wipe the surface of the shaver with a dry towel. Do not use a hair dryer or heater to dry the shaver.

NOTE: The shaver head and neck assembly is designed to be detachable from the shaver body. Simply pull upwards from the neck of the shaver for easy release. To reattach neck, align it with the neck attachment cavity so that it clips back into position.








1. Head & cutter (hair pocket) assembly
2. Detachment grooves
3. Neck assembly
4. Neck attachment cavity

Daily Cleaning:

1. Locate the detachment grooves on the head & cutter assembly. Gently pull to detach the hair pocket from the neck assembly. (Diagram L)
2. Tap out excess hair shavings.
3. Rinse the head of the shaver in running water.
4. Gently reattach the hair pocket to the neck assembly until it locks in place on all three sides. The hair pocket may be reattached in any configuration.

Weekly Cleaning:

1. Perform the daily cleaning steps 1 and 2.
2. Remove the hair pocket from the head & cutter assembly. (Diagram L) Place the body of the shaver aside.
3. Slide the blue cutter support frame upwards towards the direction of the two cutters to release it from the assembly. (Diagram M)
4. Lift and remove the cutter support frame away from the cutters.
5. Remove the cutters. (Diagram N)
6. Thoroughly rinse away any debris from inner and outer cutters with warm water.
7. Replace the inner cutters. (Diagram O) The inner and outer cutters are colour coded (grey, blue and black) to ensure each cutter is returned to its original and most effective position on the cutter assembly.
8. Hold the cutter support frame with the raised center section facing upwards. Place it over the cutters so that the centre mouth opening is facing the blue cutter. Slide the cutter carrier towards the blue cutter until the locking tab locks under the centre triangle. (Diagram P)
9. Lubricate each cutter with Remington Shaver Saver (SP4).
10. Gently reattach the hair pocket to the neck assembly until it locks in place on all three sides. The hair pocket may be reattached in any configuration. (Diagram Q)



REPLACING THE HEAD & CUTTERS

Please refer to the shaver grid on page 5 of this manual that lists the correct replacement part number for your shaver.

It is very important to replace your head and cutters when necessary to ensure a close, comfortable shave without irritation. We recommend they be replaced every 12 months. Here are some signs of head and cutter wear, indicating that replacement is needed:

- **Irritation:** As the heads get excessively worn you may experience some skin irritation. This would be especially noticeable when you apply moisturizing lotion.
- **Pulling:** When the cutters wear you may feel a sense of pulling and a loss of closeness when you shave. This is an indication that it is time to replace your heads and cutters.

Replacement heads & cutters may be obtained from your local retailer, or directly from Remington®. Simply fill out the enclosed accessory order form - refer to page 8 & 9, or alternatively your order can be processed over the phone via the Remington® Service Hotline - refer to page 14.



Suitable for use in bath and shower.

This product conforms to radio frequency interference requirements.

Any product purchased and used commercially carries a limited 90 Day Warranty.



MONEY BACK OFFER – AUSTRALIA / NEW ZEALAND ONLY

If within 60 days you are not fully satisfied with your Remington® shaver, just return the shaver with this completed coupon and a copy of your Australian/New Zealand purchase receipt to Remington®. In return, we will send you a cheque for the full purchase price of the shaver. Please allow 6-8 weeks for your cheque to arrive.

Name:

Address:

City:

State: Postcode:

Contact No: Area Code: Ph:

Product Model number:

Is this the first Remington shaver you have owned/purchased? Yes ☐ No ☐

What is the reason you are returning this product?

Spectrum Brands Australia Pty Ltd and Spectrum Brands New Zealand Limited
WARRANTY AGAINST DEFECTS

In this warranty:

Australian Consumer Law means the Australian consumer law set out in Schedule 2 to the Competition and Consumer Act 2010;

CGA means the New Zealand Consumer Guarantees Act 1993;

Goods means the product or equipment which was accompanied by this warranty and purchased in Australia or New Zealand, as the case may be;

Manufacturer, We or us means:

1. for Goods purchased in Australia, Spectrum Brands Australia Pty Ltd
ACN, 007 070 573; or
2. for Goods purchased in New Zealand, Spectrum Brands New Zealand Limited,
as the case may be, contact details as set out at the end of this warranty;

Supplier means the authorised distributor or retailer of the Goods that sold you the Goods in Australia or in New Zealand; and

You means you, the original end-user purchaser of the Goods.

1. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law, or the CGA. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
2. The benefits provided by this Warranty are in addition to all other rights and remedies in respect of the Goods which the consumer has under either the Australian Consumer Law or the CGA. The original purchaser of the Goods is provided with the following Warranty subject to the Warranty Conditions:
3. We warrant the Goods for all parts defective in workmanship or materials for the period of two (2) years from the date of purchase (**Warranty Period**). If the Goods prove defective within the Warranty Period by reason of improper workmanship or material, we may, at our own discretion, repair or replace the Goods without charge.

Warranty Conditions

4. The Goods must be used in accordance with the manufacturer's instructions. This Warranty does not apply should the defect in or failure of the Goods be attributable to misuse, abuse, accident or non-observance of manufacturer's instructions on the part of the user. As far as the law permits, the manufacturer does not accept liability for any direct or consequential loss, damage or other expense caused by or arising out of any failure to use the Goods in accordance with the manufacturer's instructions.
5. Exhaustible components (such as shaver heads, cutters and foils) of the Goods are included under this Warranty only where there is a defect in workmanship or materials used.
6. The warranty granted under clause 3 is limited to repair or replacement only.
7. Any parts of the Goods replaced during repairs or any product replaced remain the property of the manufacturer. In the event of the Goods being replaced during the Warranty Period, the warranty on the replacement Goods will expire on the same date as for the Warranty Period on the original Goods which are replaced.

8. In order to claim under the warranty granted under clause 3 you must:
 - (a) Retain this warranty with your receipt/proof of purchase; and
 - (b) Return the Goods to us at the relevant address below or to the Supplier by prepaid freight within the Warranty Period accompanied with (i) the legible and unmodified original proof of purchase, which clearly indicates the name and address of the Supplier, the date and place of purchase, the product name or other product serial number and (ii) this warranty.
9. This warranty is immediately void if:
 - (a) Any serial number or appliance plate is removed or defaced;
 - (b) The Goods have been serviced or otherwise repaired by a person not authorised to do so by us or where non approved replaced parts are used.
10. The Goods are designed for domestic use only. A limited 90-day Warranty applies to any industrial or commercial use of the Goods. The Goods must be connected to the electrical voltage requirements as specified in the ratings label located on the Goods.
11. This warranty does not cover the cost of claiming under the warranty or transport of the Goods to and from the Supplier or us.
12. This warranty is only valid and enforceable in Australia against Spectrum Brands Australia Pty Ltd and in New Zealand against Spectrum Brands New Zealand Limited.

Contact us or the Supplier for further details.

Spectrum Brands Australia Pty Ltd

Locked Bag 3004

Braeside, VIC 3195

AUSTRALIA

Customer service in Australia: 1800 623 118

E-mail: consumer.enquiry@remington-products.com.au

Website: www.remington-products.com.au

Spectrum Brands New Zealand Limited

PO Box 9817

Newmarket, Auckland 1149

NEW ZEALAND

Customer service in New Zealand: 0800 736 776

E-mail: info@remington.co.nz

Website: www.remington.co.nz

REMINGTON®

REMINGTON SERVICE HOTLINE

📞 Australia 1800 623 118 (toll free)

📞 New Zealand 0800 736 776 (toll free)

® Registered Trade Mark of Spectrum Brands, Inc., or one of its subsidiaries

Made in China to the Specifications of Spectrum Brands, Inc.

© 2017 Spectrum Brands Inc.

REV: 03/17

PART NO: T22-0004973



REMINGTON®

WETech HYPERFLEX ROTARY SHAVER

**USE & CARE
MANUAL**

PLEASE READ
PRIOR TO USE



To register your product go to
remington-products.com.au
remington.co.nz

2 YEAR WARRANTY

XR1391AU

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic precautions should always be observed, including the following.

READ ALL INSTRUCTIONS BEFORE USING

For additional protection, the installation of a residual current device (rCD) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.

WARNING: TO REDUCE THE RISK OF BURNS, ELECTROCUTION AND FIRE OR INJURY TO PERSONS

DANGER: As with most electrical appliances, electrical parts are electrically live even when the switch is off.

- The appliance should never be left unattended when plugged into a power outlet, except when charging the appliance.
- This appliance should not be used by children or other persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge unless they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Never operate this appliance if it has a damaged cord or plug, if it is not working correctly, if it has been dropped or damaged, or dropped into water. If the supply cord or plug of the appliance is damaged it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. It cannot be repaired. Keep the cord away from heated surfaces.
- Charge, use and store the product at a temperature between 0°C and 32°C.
- Do not use outdoors or where aerosol (spray) products are being used, or where oxygen is being administered.
- Do not use this appliance with damaged or broken tracks, foils or cutters, as injury may occur.

- For use on facial hair only. Not intended for shaving the hair on your head.
- Do not plug or unplug the appliance with wet hands.
- For household use only.
- Do not place or store the appliance or charging adaptor where it can fall or be knocked into a sink or bath.
- Do not place in or drop into water or any other liquid for extended periods of time.
- If an appliance falls into water, “unplug it” immediately. Do not reach into the water.
- Unplug the charging adaptor from the electrical outlet immediately after fully charging.
- Unplug and switch off this appliance before cleaning it.
- Use this appliance only for its intended use as described in this manual.
- Do not use attachments not recommended by Remington.
- Never drop or insert any object into any opening of this appliance.
- Always store the charging adaptor in a moisture-free location.
- Do not use on people who are asleep.
- Do not use an extension cord or a voltage converter with this appliance.
- Do not wrap the cord around the appliance.

Remington strongly recommends that an approved Safety Switch (residual current device) be installed to protect all bathroom power outlets. Ask an electrical contractor for advice.

SAVE THESE INSTRUCTIONS

XR1391AU WETech HYPERFLEX

USE & CARE INSTRUCTION MANUAL

Thank you for purchasing your new Remington® WETech HYPERFLEX shaver.
Inside this manual you will find tips on using and caring for your shaver.



KEY PARTS

1. On/Off Button
2. Shaving Head
3. Hairpocket
4. Pivoting neck & cutter assembly
5. Pop Up Trimmer (not shown)
6. LED Indicators
7. Charging Pins (not shown)

Also Includes:

- Travel friendly charging stand
- Head guard
- Cleaning brush
- Power adaptor

FEATURE	XR1391AU
Power System	Cordless
Initial Charge Time	24 Hours
Full Charge Time	90 Minutes
Cordless Shave Time	60 Minutes
Quick Charge	Yes
Indicators	LED
Voltage Type	Worldwide
Charging Stand	Yes
Travel Lock	Yes
Replacement Head & Cutters Part No.	SPR-XRAU

Power System: Cordless – shaver can only be used without the power cord. The shaver will not run while it is charging on its charging stand.

Quick Charge: Shaver will charge long enough for one shave in 5 minutes.

Indicator: LED Panel – displays the number of minutes of remaining battery power.

Voltage Type: Worldwide Voltage – shaver automatically adapts to an outlet voltage between 100V and 240V.

NOTE: Some countries will require the use of a plug adaptor that is not included with your shaver.



Travel Lock: To engage travel lock, press and hold the On/Off button for 3 seconds. To disengage travel lock, press and hold the On/Off button for 3 seconds.

CHARGING

1. Plug power adaptor into the charging stand. (Diagram A)
2. Plug power adaptor into wall outlet. (Diagram B)
3. Charge shaver for 24 hours before its first use. This first charge is important to the shaver's battery life.

NOTE: During initial charge ignore the electronic indicators as they are in "start up cycle". (Diagram C)

4. Use shaver until recharge is required.




CAUTION:

- Make sure the shaver and your hands are dry when charging the shaver.
- Always charge the shaver in a cool, dry place.

SHAVING

1. Press power button to turn on. (Diagram D)
2. Shave face and neck using short, circular strokes. (Diagram E)




3. After shaving, turn the shaver off. (Diagram D)

SHAVING TIPS

- The Remington® WETech HYPERFLEX is waterproof. You may use shaving foam or cream with your shaver. You may also shave in the shower.
- Wait at least 15 minutes after getting up before shaving, to ensure your face is free of puffiness that may be present from sleeping.
- Always hold the shaver at a right angle to the skin so that all three heads are touching the skin with equal pressure.
- Stretch skin with the free hand so hairs stand upright, making it easier for them to enter the cutting chamber.
- Use moderate to slow, circular stroking movement.
- The use of short, circular motions in stubborn areas may obtain a closer shave, especially along the neck and chin line.
- Do not press hard against the skin to avoid skin irritation and/or damage to the rotary heads.
- As with every shaver, your shave will improve over time. Allow up to four weeks of daily shaving to develop effective shaving style and for your skin to adjust to the new shaver. The adaptation period may take a little longer if your skin is sensitive, if you are switching from a different method of shaving, or if you alternate between shaving methods.

TRIMMING



Pop-up Trimmer:

1. Push trimmer release button to engage trimmer. (Diagram F)
2. Trim long, difficult hairs and side burns.
3. Close trimmer by pressing down. (Diagram G)

NOTE: Lubricate teeth with oil every 6 months.

PLEASE USE BLOCK LETTERS

*** INDICATES REQUIRED INFORMATION**

***NAME:**

***ADDRESS:**

5. _____

*CITY:

***STATE:**

***POSTCODE:**

***POSTCODE:**

***CONTACT NUMBER:**

AREA CODE		

Ph:

[illegible]

***PAYMENT INSTRUCTIONS:**

☐ I enclose my cheque/money order (make payable to Spectrum Brands Australia Pty Ltd or Spectrum Brands New Zealand Limited)

OR

☐ Please charge this purchase to my credit card account: ☐ Mastercard ☐ Visa

Card Number

Expiry Date

101

CARD HOLDER NAME:

ADDRESS:

CITY:

STATE:

SIGNATURE:

POSTCODE:
